






NELLCOTE
STUDIO
www.NellcoteStudio.com
RIVOLI SCONCE

IMPORTANT SAFETY INSTRUCTIONS

- Consult certified electrician before installation that familiar with commercial type of applications.
- To reduce risk of fire, use 40 Watt Compact Fluorescent smaller lamp and do not exceed the recommended wattage.
- The manufacturer and distributor accepts no liability for incorrect installation.
- Wall must have at least the capacity of 5 times the weight of the wall sconce. For this light at least a wall capacity of 30 kg is required.
- Maximum Supply Current 1 A

NO	DESCRIPTION	QTY
1	 LAMP	1
2	 PLAIN WASHER	6
3	 PHILLIPS HEAD BOLT	2

WARNING

- Turn-off electricity supply at main circuit panel before installing. All wires are connected. Do not remove the wall sconce from its packaging by pulling on the power cord, as a bad connection may result.
- To reduce the risk of fire, electrical shock, or personal injury, always turn off the wall sconce and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- Deviation from instructions may result in a risk of fire or electric shock.
- Suitable for indoor use only
- The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.
- Terminal block not included. Installation may require advice from a qualified person.
- Only to be installed outside arms reach.

ASSEMBLY INSTRUCTIONS

1. Remove the mounting nuts to separate the mounting bracket from the lamp. See FIGURE 01.
2. Through the electric wire from the outlet box to the center hole of the mounting bracket. Attach the mounting bracket to the outlet box by using the Phillips head bolts (3) together with lock washers (2). See FIGURE 02.
3. At the back of the wall lamp attach the fixture ground wire (green wire) and house ground wire (usually green or bare wire) to the green grounding screw attached on the mounting bracket. Connect fixtures to corresponding house wire. Carefully tuck the wires back into the outlet box. **IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.**

Connect the neutral wire (white wire) to the neutral outlet wire (usually white).

Connect the hot wire (black wire) to the hot outlet box wire (usually black). **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.** Please see **FIGURE 03.**

4. Install the lamp on the mounting bracket by using the mounting nuts.

FIGURE 01




FIGURE 02





FIGURE 03



THANK YOU FOR YOUR PURCHASE
www.nellcotestudio.com