


**momax** *smart*

## **2 Healthy MAX**

IoT Air Purifying Dehumidifier

IoT 智能 2-in-1 空氣淨化抽濕機

IoT 智能 2-in-1 空气净化除湿机




**AP11S**

**Product Information** p.2 - 29

產品資料 p.30 - 52

产品资料 p.53 - 75



## Introduction

### IoT Air Purifying & Dehumidifier (AP11S)

- Purifies air with H11 HEPA, Activated carbon filters and Antibacterial Coating.
- Works with low-temperature dehumidification up to 5°C.
- Smart control with MOMAX Smart APP and trigger automation based on environment.
- Dehumidification up to 12L per day.

### Before Using

1. Please make sure the electric power supply of your region meets the product's requirement.
2. An independent 13A switch must be used for this product.
3. Make sure there are no broken parts of the power cord and the product.
4. This product cannot replace daily air ventilation and dust collection.
5. Do not insert your fingers or objects into the air outlet or the air inlet to prevent physical injury or malfunctioning of the appliance.

## Quick Start Guide

### 1. Download 'MOMAX Smart' APP

Download "MOMAX Smart" from iOS App Store, Android Google Play Store or other platforms.

### 2. Register

Register an account and log in using your mobile number or email address.

### 3. Wireless Pairing

Click "+", then tap "MOMAX Smart Air Purifying & Dehumidifier" to add device.

Press and hold the Timer button for about 5 seconds until you hear a beep sound and the Wifi indicator rapidly blink. Tap "Confirm indicator rapidly blink". Then, tap 'Next' to proceed.

- This product cannot be paired directly through the Bluetooth list of the mobile phone.
- The pairing process may take 2 minutes, please do not perform other operation.

### 4. Successfully connected

Once the connection is completed, you can edit the name of the Air Purifying Dehumidifier.

Find "AP11S" in MOMAX's channel

[helpdesk.momaxsmart.com](https://helpdesk.momaxsmart.com)


Get step-by-step setup and support.

Watch the latest video tutorial to learn to setup and operate your AP11S.

Keep up to date with the latest updates.




## Product Overview



1. Control Panel
2. Portable Handle
3. Body
4. Wheels


5. Air Inlet Cover
6. Air Purifying Filter
7. Water Tank
8. Drainage Hole

## Control Panel









	Power Button
	Humidity Setting Button
	Timer Button
	Fan Speed/ Child Lock Button

## LED Control



1. Wi-Fi Indicator
2. Relative Humidity Display
3. Child Lock Indicator
4. Water Tank Full Indicator
5. Power Indicator
6. Relative Humidity Indicator
7. Timer Indicator
8. Windspeed Indicator

	Function
	<p><b>Power Button</b></p> <ul style="list-style-type: none"> <li>• Touch the button to control the device power on/off.</li> <li>• Once the machine is turned on, the power indicator will turn on.</li> </ul>
	<p><b>Humidity Setting Button</b></p> <ul style="list-style-type: none"> <li>• Touch the button to set the target environmental humidity between 40%, 60%, 80% and Cont. (Continuous dehumidification).</li> </ul>
	<p><b>Timer Button</b></p> <ul style="list-style-type: none"> <li>• Touch the button to set the timer of 2H, 4H and 8H.</li> <li>• Long press the timer button to enter pairing mode.</li> </ul>
	<p><b>Fan Speed/ Child Lock Button</b></p> <ul style="list-style-type: none"> <li>• Touch the button to set the fan speed of the machine between High (H), Low (L) and Sleep.</li> <li>• Long press 3 seconds to activate or cancel child lock function.</li> </ul>
Cont	<p><b>Relative Humidity Display</b></p> <ul style="list-style-type: none"> <li>• Display the ambient humidity value of the machine.</li> </ul>
	<p><b>Child Lock Indicator</b></p> <ul style="list-style-type: none"> <li>• Display when Child lock is on, all buttons are locked.</li> </ul>
	<p><b>Water Tank Full Indicator</b></p> <ul style="list-style-type: none"> <li>• When the water tank is full, the indicator is on and the machine will stop.</li> </ul>

#### **Air Quality Indicator:**

After the machine is powered on for 30s, it will be in the reservation state. At this time, the color lights at the bottom of the control panel will gradually change for 30s (in the order of blue, cyan, green, yellow, orange, red and purple).

Air quality control results are as follows:

- The ambient light turns blue when the air quality is good.
- The ambient light turns yellow when the air quality is normal.
- The ambient light turns red when the air quality is poor.

When the machine is in sleep mode, the full-color lights go out and the machine enters sleep mode.


#### **Dehumidification Humidity Setting:**

When the relative humidity setting is switched, the corresponding relative humidity indicator will be turned on, and the machine will dehumidify according to the set relative humidity value (40%, 60%, 80%, Cont).

### Continuous Drainage:

When the machine needs to drain continuously, use a proper flexible rubber pipe (not included in this product) to connect to the drainage hole to the hole at the back of device. Water will not be stored in the water tank when the machine is running on continuous drainage.

- Extend the continuous drainage pipe from the continuous drainage outlet into the machine, and then insert the pipe from the tank port into the drainage hole.
- When using continuous drainage, the pipe should be placed flat on the ground. Any part of the pipe should not be folded or warped, and the outlet end of the pipe should not extend below the liquid level of other containers.



## Safety Features

### Water Tank Full Automatic Protection:

- When the machine is working, if the tank is full, the compressor and the fan motor will stop working, and the tank full indicator will be on.
- Take out the tank and pour out the water.
- Put the tank back, and the machine will restart according to the state before the tank is full (Dehumidification will not start until 3 mins later).

### Filter Replacement Reminder:

- When the whole machine has been running for 2,200hr in total, the power indicator will flash at the frequency of 1s/time, reminding that the filter needs to be replaced. If the filter has been replaced, you can long press the power button to reset.


## Maintenance

Ensure the machine is unplugged before maintenance.

### Cleaning:

Wipe the tank and the body with a soft. (Do not use corrosive detergents.)

Clean the filter with a vacuum cleaner every 2 weeks to ensure a good dehumidification effect.



## Specification

Model No.	: AP11S
Rated Voltage	: AC 220~240V, 50Hz
Rated Power	: 158W
Maximum Power	: 205W
Filter Type	: HEPA H11 Filter With Activated Carbon & Anti-Bacterial Technology
Effective Area	: Up to 24m <sup>2</sup> (Ceiling Height 2.3m)
CADR	: Approx. 55.8m <sup>3</sup> /Hr
Water tank Volume	: 3.2L
Humidity Setting	: 40%, 60%, 80%, Cont
Dehumidification Capacity	: 12L/Day (30°C, RH80%), 6.9L/Day (27°C, RH60%)
Work Temperature	: 5°C - 35°C
Noise Level	: <45dB
Maximum Refrigerant Charge	: R290/45g
Allowable Working Pressure	: 4.52MPa (Maximum)
Discharge Pressure	: 2.6MPa (Maximum)
Wireless Frequency	: 2.4GHz
Size	: 295 x 295 x 560mm
Weight	: 12kg ± 100g

## Contains

1. 2 Healthy MAX IoT Air Purifying Dehumidifier
2. HEPA Filter With Activated Carbon & Anti-Bacterial Technology (1pc)
3. Wheels (4pcs)
4. Instruction Manual And Warranty Card

## Safety Precautions

This page records the main topics of safety precautions to prevent personal injury or property loss of users and others. Please read them carefully and observe the precautions recorded here.

1. Do not operate this machine with wet hands, or flush the dehumidifier directly with water, or place this machine near the water source.
2. Do not put your hands into the air outlet or the inside of it; Do not place heavy weights at the air outlet of this machine or sit directly at the air outlet.
3. Do not throw or place any objects into the dehumidifier.
4. Do not put flammable and explosive gases in the place where the dehumidifier is used, and please keep this machine away from any heat source.
5. It is forbidden to turn off the machine directly through the power switch; and when the machine is not in use in a long term, please turn off the power switch.
6. In case of anything untoward (e.g., the machine gives off burning smell), the machine must be stopped from running with the power supply cut off.
7. The power supply must be cut off during thunderstorms.
8. It is forbidden to replace the power cord without authorization, or connect the power cord midway or use it in parallel with other high-power electrical appliances.
9. It is forbidden to disassemble, modify, repair or clean internal devices without authorization.
10. When cleaning the machine, please stop it and turn off the power switch.
11. The appliance is for indoor use only.
12. Do not use the unit on a socket under repairs or not installed properly



13. Do not use the unit, follow these precautions:
  - A: Near to source of fire.
  - B: An area where oil is likely to splash.
  - C: An area exposed to direct sunlight.
  - D: An area where water is likely to splash.
  - E: Near a bath, a laundry, a shower or a swimming pool.
14. Never insert your fingers, rods into the air outlet. Take special care to warn children of these dangers.
15. Keep the unit upward while transport and storage, for the compressor locates properly.
16. Children should be supervised to ensure that they do not play with the appliance.
17. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
18. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
19. The appliance shall be installed in accordance with national wiring regulations.
20. Details of type and rating of fuses : T, 250V AC,6.3A.
21. Recycling.

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of

material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

22. Contact authorized service technician for repair or maintenance of this unit.
23. Do not pull, deform. or modify the power supply cord or immerse it in water. Pulling or misuse of the power supply cord can result in damage to the unit and cause electrical shock.
24. Compliance with national gas regulations shall be observed.
25. Keep ventilation openings clear of obstruction.
26. Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
27. Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
28. Do not operate or stop the unit by inserting or pulling out Die power plug, it may cause electric shock or fire due to heat generation.
29. Unplug the unit if strange sounds, smell, or smoke comes from it.
30. Do not lean the machine against obstacles or walls.
31. Please keep a distance of more than 20cm from the machine to its rear and to its left and right, and a distance of more that 50cm from the machine to its top and to its front.

Notes:

1. If any parts damage, please contact the dealer or a designated repair shop.
2. In case of any damage, please turn off the air switch, disconnect the power supply, and contact the dealer or a designated repair shop;
3. In any case, the power cord shall be firmly grounded.
4. To avoid the possibility of danger, if power cord is damaged, please turn off the air switch and disconnect the power supply. It must be replaced from the dealer or a designated repair.



**Checks to the area**

Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized.

For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system.

a) Work procedure

Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed.

b) General work area

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided. The area around the workspace shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.

c) Checking for presence of refrigerant

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.

Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.

d) Presence of fire extinguisher

If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available at hand.

Have a dry powder or CO2 fire extinguisher adjacent to the charging area.

e) No ignition sources

No person carrying out work in relation to a refrigeration system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion.

All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space.

Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. No Smoking signs shall be displayed.

f) Ventilated area

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

g) Checks to the refrigeration equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using flammable refrigerants:

The charge size is in accordance with the room size within which the refrigerant containing parts are installed; The ventilation machinery and outlets are operating adequately and are not obstructed; If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant; Marking to the equipment continues to be visible and legible.

Markings and signs that are illegible shall be corrected; Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

h) Checks to electrical devices

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used.

This shall be reported to the owner of the equipment so all parties are advised. Initial safety checks shall include: That capacitors are discharged; this shall be done in a safe manner to avoid possibility of sparking; That there no live electrical components and wiring are exposed while charging, recovering or purging the system; That there is continuity of earth bonding.

**Repairs to sealed components**

a) During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.

b) Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

Ensure that apparatus is mounted securely. Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.

The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

#### 1. Repair to intrinsically safe components

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use. Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating. Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

#### 2. Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

#### 3. Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

#### 4. Leak detection methods

The following leak detection methods are deemed acceptable for systems containing flammable refrigerants.

Electronic leak detectors shall be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area).

Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed.

Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

If a leak is suspected, all naked flames shall be removed/ extinguished.

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

Oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

#### 5. Removal and evacuation

When breaking into the refrigerant circuit to make repairs or for any other purpose conventional procedures shall be used.

However, it is important that best practice is followed since flammability is a consideration.

The following procedure shall be adhered to:

- Remove refrigerant;
- Purge the circuit with inert gas;
- Evacuate;
- Purge again with inert gas;
- Open the circuit by cutting or brazing.

The refrigerant charge shall be recovered into the correct recovery cylinders.

The system shall be flushed with OFN to render the unit safe.

This process may need to be repeated several times.

Compressed air or oxygen shall not be used for this task.

Flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.

This process shall be repeated until no refrigerant is within the system. When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.

This operation is absolutely vital if brazing operations on the pipe-work are to take place.

Ensure that the outlet for the vacuum pump is not close to any ignition sources and there is ventilation available.

## 6. Charging procedures

In addition to conventional charging procedures, the following requirements shall be followed.

Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them. Cylinders shall be kept upright.

Ensure that the refrigeration system is earthed prior to charging the system with refrigerant. Label the system when charging is complete (if not already).

Extreme care shall be taken not to overfill the refrigeration system. Prior to recharging the system it shall be pressure tested with OFN.

The system shall be leak tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving

the site.

## 7. Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely.

Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure ensure that:
  - Mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  - All personal protective equipment is available and being used correctly;
  - The recovery process is supervised at all times by a competent person;
  - Recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with manufacturer's instructions.
- h) Do not overfill cylinders. (No more than 80 % volume liquid charge).

- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

#### 8. Labelling

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

#### 9. Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and

in good condition.

Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release.

Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged. Do not mix refrigerants in recovery units and especially not in cylinders. If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

## Storage And Disposing Of The Unit

- Please recycle or dispose of the packaging material for product in an environmentally responsible manner.
- Never store or ship the air conditioner upside down or sideways to avoid damage to the compressor.
- Dispose of this appliance in accordance with Federal and Local regulations. Refrigerants must be evacuated before disposal.
- Risk of Fire or Explosion. This unit contains flammable
- Refrigerant. Additional safety precautions must be followed.
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater.
- Do not pierce or burn refrigerant tubing. Be aware that refrigerants may not contain odor.
- Keep ventilation openings clear of obstruction.
- When handling, installing, and operating the appliance, care should be taken to avoid damage to the refrigerant tubing.
- Do not drill holes in the unit.
- Maintenance, cleaning and service should only be performed by technicians properly trained and qualified in the use of flammable refrigerants.
- Dispose of air conditioner in accordance with Federal and Local Regulations. Flammable refrigerants require special disposal procedures. Contact your local authorities for the environmentally safe disposal of your air conditioner.

## Transportation, marking and storage for units that employ flammable refrigerants.

### Transport of equipment containing flammable refrigerants.

Attention is drawn to the fact that additional transportation regulations may exist with respect to equipment containing flammable gas. The maximum number of pieces of equipment or the configuration of the equipment, permitted to be transported together will be determined by the applicable transport regulations.

### Marking of equipment using signs.

Signs for similar appliances used in a work area generally are addressed by local regulations and give the minimum requirements for the provision of safety and/or health signs for a work location.

All required signs are to be maintained and employers should ensure that employees receive suitable and sufficient instruction and training on the meaning of appropriate safety signs and the actions that need to be taken in connection with these signs.

The effectiveness of signs should not be diminished by too many signs being placed together.

Any pictograms used should be as simple as possible and contain only essential details.

### Disposal of equipment using flammable refrigerants.

See national regulations.

### Storage of equipment/appliances

The storage of equipment should be in accordance with the manufacturer's instructions.

### Storage of packed (unsold) equipment

Storage package protection should be constructed such that mechanical damage to the equipment inside the package will not cause a leak of the refrigerant charge.

The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations.

## Service Agreement of Smart Mobile Application Platform

Please reference Mobile Apps content: Before accepting the Agreement, you are supposed to thoroughly read all the contents of the Agreement, and fully understand its terms, especially restrictive clauses or exceptions and Privacy Notice. Restrictive clauses or exceptions are bold or highlighted in other forms to catch your attention. In case of any doubt about the terms of the Agreement, please contact the relevant business department of Tuya. You are not allowed to use the service before you have read and accepted all the terms of the Agreement, relevant agreements, and rules, etc. Once you select “agree and submit the Agreement” (see registration page for detailed wordings) and complete the registration procedure, or you use the service in any form, it will be deemed that you have read and agreed with the restriction of the Agreement and rules above. In case of any breach of the Agreement, Tuya has the right to unilaterally restrict, suspend or terminate the service for you, and has the right to investigate your relevant responsibilities.

## Disposal of Electronic Products

1. Do not place the product as household waste;
2. Please dispose of discarded electronic products properly according to local regulations;
3. MOMAX encourages you to participate in the electronic recycling program.

## Warranty Conditions

1. For any defect, in the judgment of our technician, caused under normal use, we are responsible for repairing free of charge 12 months commencing from the date of purchase at the discretion of our company;
2. A valid warranty card and original purchase invoice must be presented upon request of warranty service;
3. This warranty card shall not apply to the product if:
  - (a) It is consumable part(s), such as Filter, or;
  - (b) it has explicitly modified or repaired in any way by persons other than technicians of this company, or;
  - (c) it has been damaged through misuse, malicious acts, negligence, the inflow of any liquid, or;
  - (d) losses or damages are caused by force majeure or natural disasters.
4. No alteration to this warranty card will be allowed;
5. The warranty terms and conditions are subject to change without prior notice;
6. Please retain your proof of purchase for warranty service;
7. Please consult the dealer about the product compatibility with your cell phone/ PDA before purchase. Product specifications are subject to change without prior notice;
8. Please visit [www.momax.net](http://www.momax.net) for the latest product information.



## 簡介

### IoT 智能2-in-1空氣淨化抽濕機 (AP11S)

- 通過H11 HEPA，活性碳濾網及抗菌塗層淨化空氣。
- 環境溫度低至5度仍能有效抽濕
- 通過MOMAX Smart APP進行遙距控制，並可根據環境觸發自動化。
- 每天最多抽濕量可達12L

### 使用之前

1. 請確保你所在地區的電源供應符合產品需求。
2. 本產品必需使用獨立13A電源插座。
3. 確保電源線和產品沒有破損。
4. 本產品不能代替日常通風，日常除塵。
5. 請勿將手指或其他物體插入出風口或入氣口，以免造成人身傷害或設備故障。

搜尋“AP11S” in [helpdesk.momaxsmart.com](https://helpdesk.momaxsmart.com)

獲取有關設定和支援。

觀看最新的視頻教學，學習設置和操作您的 AP11S。

隨時了解最新資訊。



## 快速入門指南

### 1. 下載“MOMAX Smart”應用程式

在iOS或Android或任何平台上下載“MOMAX Smart”應用程式。

### 2. 註冊

註冊一個帳戶，然後使用您的手機號碼或電子郵件地址登錄。

### 3. 無線配對

按“+”（添加設備），選取“MOMAX 智能2-in-1空氣淨化抽濕機”以添加設備。


打開設備，按住定時鍵約5秒直到聽到一聲提示聲及看到Wifi提示燈在快閃。按“確定提示燈正在快閃”，再按“下一步”。

- 不能透過手機的藍牙清單直接配對本產品。
- 搜索過程可能需要兩分鐘。請在此期間不要執行任何操作。

### 4. 成功連接

如果配對成功，你會在應用程式中看到本產品的圖標。你可以修改此 AP11S的名稱。確保您的設備已連接，結果將發送到手機的應用程式。


## 產品總覽



1. 控制面板
2. 手提把手
3. 機身
4. 輪子

5. 空氣淨化濾網蓋
6. 濾網
7. 水箱
8. 排水口

## 控制面板




LED  
顯示器


控制鍵

	電源開關鍵
	濕度設定鍵
	定時鍵
	風速鍵/童鎖鍵

## LED 顯示器



- |              |          |
|--------------|----------|
| 1. Wi-Fi 指示燈 | 5. 電源指示燈 |
| 2. 相對濕度顯示    | 6. 濕度指示燈 |
| 3. 童鎖指示燈     | 7. 定時指示燈 |
| 4. 水滿指示燈     | 8. 風速指示燈 |

	功能
	<b>電源開關鍵</b> <ul style="list-style-type: none"> <li>• 控制設備開機/關機</li> <li>• 當設備開機後，電源指示燈會亮起來</li> </ul>
	<b>濕度設定鍵</b> <ul style="list-style-type: none"> <li>• 設定環境的目標濕度，可設為40%，60%，80%或連續抽濕</li> </ul>
	<b>定時鍵</b> <ul style="list-style-type: none"> <li>• 設定機器定時關機時間，可設為2H，4H或8H</li> <li>• 長按定時鍵進入配網模式</li> </ul>
	<b>風速鍵/童鎖鍵</b> <ul style="list-style-type: none"> <li>• 設定機器的風速，可設為高風，低風和睡眠模式</li> <li>• 長按3秒可開啟和關閉童鎖功能</li> </ul>
Cont	<b>相對濕度顯示</b> <ul style="list-style-type: none"> <li>• 顯示機器附近的環境相對濕度值</li> </ul>
	<b>童鎖指示燈</b> <ul style="list-style-type: none"> <li>• 童鎖模式下會亮起，所有按鍵會被鎖定</li> </ul>
	<b>水滿指示燈</b> <ul style="list-style-type: none"> <li>• 當水箱滿的時候，指示燈會亮起，而機器會停止運作</li> </ul>

### 空氣質量指示燈：

設備開機後會有約30秒的預備狀態，此時控制面板底部的顏色燈會漸變（順序為藍青綠黃橙紅紫）

空氣質量對照如下：

- 空氣質量良好時，燈光顯示為藍色。
- 空氣質量正常時，燈光顯示為黃色
- 空氣質量差時，燈光顯示為紅色。

當機器進入睡眠模式時，全部燈光會關閉。


### 抽濕濕度設定：

當按下濕度設定鍵時，其相應的濕度指示燈會亮起，而機器亦會根據設定的濕度值(40%, 60%, 80%, 連續抽濕)來進行抽濕工作，將環境濕度降至設定值。

### 連續排水：

當機器需要連續排水時，用一根合適的軟膠管通過進水箱的孔位連接到排水孔上。當機器連續排水運行時，水箱不會盛水。

- 將連續排水管從連續排水口伸到機器內部，然後從水箱口處將排水管插到排水孔。
- 連續排水時，排水管需平放於地面。排水管的任何部位不可有折疊和上翹的情況，以及排水管的出口端不能放入其他容器的水平面下。



## 保護功能

### 水滿自動保護：

- 機器在工作時，若水箱水滿的話，壓縮機和風扇摩打會停止工作，此時水滿指示燈會亮起。
- 取出水箱後將水倒掉。
- 放回水箱，機器將按水滿前的狀態重新啟動工作(3分鐘後才會重新啟動抽濕功能)。

### 濾網更換提醒功能：

- 當整機累計運行滿2200小時，電源指示燈會以每秒1次的頻率閃爍，提示需要更換濾網。如已更換可長按電源鍵進行重設。


## 清潔保養

保養前，請確保拔掉電源插頭。

### 清潔：

用一塊軟布擦拭水箱及主機外殼。(請勿使用有腐蝕性的清潔劑)

每兩星期左右用吸塵機清潔一次濾網。



## 產品規格

型號	: AP11S
額定電壓	: AC 220~240V, 50Hz
額定功率	: 158W
最大功率	: 205W
過濾網種類	: HEPA附活性碳及抗菌塗層
適用面積	: 可達24m <sup>2</sup> (天花高度2.3m)
空氣潔淨量	: 大約55.8m <sup>3</sup> /小時
水箱容量	: 3.2公升
濕度設定	: 40%, 60%, 80%, Cont
抽濕能力	: 12公升/日 (30°C, 相對濕度80%) 6.9公升/日 (27°C, 相對濕度60%)
工作溫度	: 5°C - 35°C
噪音量	: <45dB
最大的製冷劑容量	: R290/45g
最大允許工作壓力	: 4.52MPa
最大排氣壓力	: 2.6MPa
無線頻率	: 2.4GHz
尺寸	: 295 x 295 x 560mm
重量	: 12kg±100g

### 包裝內容

1. 2 Healthy MAX IoT 智能 2-in-1 空氣淨化抽濕機
2. HEPA濾網附活性碳及抗菌塗層 (1片)
3. 輪子 (4個)
4. 使用說明書及保用證

## 安全預防措施

本頁記錄了防止用戶和其他人的人身傷害或財產損失的安全預防措施的主要主題。請仔細閱讀，並遵守這裏記錄的預防事項。

1. 請勿用濕手操作本機器，或直接用水沖洗除濕機，或將本機器放置在水源附近。
2. 請勿把手放入出風口或其內部，請勿將重物放在本機器的出風口處或直接放在出風口處。
3. 請勿將任何物體扔入除濕機。
4. 請勿在使用除濕機的地方放置易燃易爆氣體，請遠離任何熱源。
5. 嚴禁通過電源開關直接關閉機器，當機器長期不使用時，請關閉電源開關。
6. 如果出現任何不良情況（如機器散發出燃燒的氣味），必須在切斷電源時停止機器運行。
7. 在雷暴期間必須切斷電源。
8. 嚴禁擅自更換電源線，不得中途連接電源線或與其他大功率電器並聯使用。
9. 嚴禁擅自拆卸、修改、修理或清潔內部設備。
10. 清洗機器時，請停止使用機器，並關閉電源開關。
11. 該設備僅供室內使用。
12. 不要在維修中或未正確安裝的插座上使用該設備
13. 請勿使用本機，請遵循以下注意事項：
  - A：靠近火源。
  - B：油污可能會飛濺的地方。
  - C：陽光直接照射的區域。
  - D：水容易濺起的地方。
  - E：靠近浴室、洗衣房、淋浴間或游泳池。
14. 千萬不要將手指、杆插入出風口。要特別注意警告孩子們這些的危險。
15. 運輸和儲存時，請保持機組朝上，壓縮機位置正確。
16. 兒童應在監護人的監督下，確保他們不玩該產品。

17. 如果電源軟線損壞，必須由製造商、其服務代理或類似合格的人員，以避免危險。
18. 適用於8歲及以上兒童，以及身體、感官或精神能力下降或缺乏經驗和知識的人，如果他們得到了有關以安全的方式使用該器具的監督或指導，並瞭解所涉及的危險。兒童不得玩該產品。未經監督，兒童不得進行清潔和用戶維護。
19. 產品的安裝應符合國家的線路規定。
20. 保險絲類型和額定值：T,250V AC,6.3A。
21. 回收利用。  
該標誌表明，該產品不應與整個歐盟的其他家庭廢物一起處理。為防止不受控制的廢物處理可能對環境或人類健康造成損害，回收利用它負責促進材料資源的可持續再利用。若要歸還您使用過的設備，請使用退貨和回收系統或聯繫購買產品的零售商。他們可以用這種產品進行環保安全的回收。
22. 請聯繫授權服務技術人員維修或維護本設備。
23. 不要拉，變形，或修改電源線或浸泡在水裏。扯或誤用電源線可能導致設備損壞和觸電。
24. 應遵守國家有關氣體的規定。
25. 保持通風通道暢通。
26. 任何參與製冷劑迴路的工作或破壞工作的人都應持有由行業認可的評估機構出具的有效證書根據行業認可的評估，有能力安全處理製冷劑規範。
27. 維修只能按照設備製造商的建議進行。需要其他技術人員協助的維護和修理應在易燃製冷劑使用主管人員的監督下進行。
28. 請勿通過拔插電源插頭的方式操作或停止設備，可能會因發熱而引起電擊或火災。
29. 如果有奇怪的聲音，氣味或煙霧，請拔掉電源。
30. 請勿將機器靠在障礙物或牆上。
31. 機器周圍後方距離及左右距離大於20cm，上方距離及前方距離大於50cm。

注意:

1. 如有零件損壞，請聯繫經銷商或指定維修店維修。
2. 如有損壞，請關閉空氣開關，斷開電源，並與經銷商或指定維修店聯繫；
3. 在任何情況下，電源線應牢固接地。
4. 為避免危險，若電源線損壞，請關閉空氣開關並斷開電源。它必須從經銷商或指定的維修更換。



## 檢查區域

在開始對含有易燃製冷劑的系統進行工作之前，必須進行安全檢查，以確保將著火的風險降至最低。

對製冷系統進行維修時，應遵守以下注意事項。

### a) 工作過程

工作應在受控程式下進行，以儘量減少工作進行時存在可燃氣體或蒸汽的風險。

### b) 一般工作區

所有在當地工作的維修人員和其他人員都應被告知正在進行產品工作的性質。應避免在密閉空間內工作。工作空間周圍的區域應被分割。通過控制易燃材料，確保區域內的條件是安全的。

### c) 檢查製冷劑是否存在

在工作之前和工作期間，應該用合適的製冷劑檢測器檢查該區域，以確保技術人員知道潛在的易燃氣體。確保所使用的洩漏檢測設備適合與易燃製冷劑一起使用，即無火花、充分密封或本質上安全。

### d) 要有滅火器

如果要對製冷設備或任何相關部件進行任何熱工作，應隨時準備適當的滅火設備。

在裝料區附近放置乾粉或二氧化碳滅火器。

### e) 無火源

任何人不得進行有關製冷系統的工程，而該工程涉及暴露任何含有或曾經含有易燃製冷劑的管道

使用任何引火源時，應使其有引致火災或爆炸的危險。

所有可能的火源，包括吸菸，應與安裝、修理、拆卸和處置的地點保持足夠遠的距離，在此過程中，易燃製冷劑有可能被釋放到周圍空間。

在進行工作之前，要對設備周圍的區域進行調查，以確保沒有易燃危險或點火危險。張貼禁止吸菸的標誌。

#### f) 通風面積

在進入系統或進行任何熱工之前，確保該區域處於露天或通風良好。在工程進行期間，應保持一定程度的通風。通風應安全分散任何製冷劑，最好將其從外部排除到大氣中。

#### g) 檢查製冷設備

在更換電子元件時，它們應符合目的和正確的規格。在任何時候都應遵守製造商的維護和服務指南。如有疑問，請向製造商的技術部門尋求幫助。使用易燃製冷劑的設施，應當進行下列檢查：

充注量根據裝有製冷劑部件的房間大小而定；通風設備和出口運轉正常，沒有堵塞；如果使用間接製冷迴路，應檢查二次迴路是否存在製冷劑；設備上的標記繼續可見和可辨認。

字跡難以辨認的，應當改正；製冷管道或部件應安裝在不太可能暴露於任何可能腐蝕含製冷劑部件的物質的位置，除非部件的材料本身具有抗腐蝕性能，或有適當的保護措施來防止這種腐蝕。

#### h) 檢查電氣設備

電氣部件的維修和維護應包括初始安全檢查和部件檢查程式。如果存在危及安全的故障，則在故障得到滿意的處理之前，不應將電源連接到電路上。如果故障不能立即糾正，但需要繼續操作，則需要適當的臨時解決方案應使用。

這將報告給設備的所有者，以便各方得到建議。初始安全檢查應包括：電容器放電：這應以安全的方式進行，以避免產生火花的可能性；在充電、恢復或清洗系統時，沒有暴露帶電的電器元件和電線；地球連接是有連續性的。

### 密封部件的維修

a) 在對密封部件進行維修時，在拆除密封蓋等之前，應切斷正在工作的設備的所有電源。如果在維修過程中絕對有必要為設備提供電源，則應在最關鍵的位置設置一種永久操作的洩漏檢測形式，以警告潛在的危險情況。

#### b) 應特別注意以下事項，以確保通過工作

電氣元件，外殼的改變方式不會影響到保護水準。這包括電纜損壞、連接數量過多、端子未按原始規格製作、密封損壞、連接接頭不正確等。

請確保設備安裝牢固。確保密封件或密封材料沒有變質，不再起到防止易燃氣體進入的作用。更換部件應符合製造商的規範。

矽密封膠的使用可能會抑制某些類型洩漏檢測設備的有效性。本質上安全的組件在工作之前不需要被隔離。

#### 1. 修理本質上安全的部件

在沒有確保不超過使用中設備允許的允許電壓和電流的情況下，不要在電路中應用任何永久性的電感或電容負載。本質上安全的組件是唯一的類型，可以工作，而生活在一個易燃的氣氛。測試儀器應處於正確的額定值。僅使用製造商指定的部件更換部件。其他部件可能導致製冷劑在空氣中因洩漏而著火。

#### 2. 佈線

檢查電纜不會受到磨損、腐蝕、壓力過大、振動、尖銳邊緣或任何其他不利的環境影響。檢查還應考慮到來自壓縮機或風扇等源的老化或持續振動的影響。

#### 3. 易燃製冷劑的檢測

在任何情況下，不得使用潛在的火源來查找或檢測製冷劑洩漏。不得使用鹵化物火炬(或任何其他使用明火的探測器)。

#### 4. 洩漏檢測方法

對於含有易燃製冷劑的系統，下列洩漏檢測方法被認為是可接受的。

電子洩漏探測器應使用用於檢測可燃製冷劑，但靈敏度可能不夠，或可能需要重新校準。(檢測設備應在無製冷劑區域進行校準)。

確保探測器不點火的潛在來源，適合使用的製冷劑洩漏檢測設備應設定在一個百分比的LFL製冷劑應校準使用的製冷劑和適當比例的氣體(最高25%)確認。

洩漏檢測液適合與大多數製冷劑一起使用，但應避免使用含氯的洗滌劑，因為氯可能與製冷劑發生反應並腐蝕銅管。



如果懷疑有洩漏，應清除/熄滅所有明火。

如果發現需要鈎焊的製冷劑洩漏，應從系統中回收所有製冷劑，或將系統中遠離洩漏的部分隔離(通過關閉閥門)。

在鈎焊前和鈎焊過程中，應將無氧氟(OFN)通過系統進行淨化

## 5. 移除和疏散

當闖入製冷劑迴路進行維修或作其他用途時，常規程式應使用。

然而，重要的是遵循最佳實踐，因為可燃性是一個考慮因素。應遵守下列程式：

- 移除製冷劑
- 用惰性氣體清潔線路
- 撤離
- 再次用惰性氣體清潔線路
- 通過切割或鈎焊斷開電路

製冷劑充注應回收到正確的回收氣缸中。

系統應該用OFN進行沖洗，以保證設備的安全。

這個過程可能需要重複幾次。

此任務不得使用壓縮空氣或氧氣。

通過OFN打破系統中的真空，並繼續填充，直到達到工作壓力，然後排放到大氣中，最後拉到真空。

這個過程應該重複，直到系統內沒有製冷劑。當使用最後的OFN電荷時，系統應放氣至大氣壓力，以使工作發生。

如果要對管道進行鈎焊操作，這種操作是絕對重要的。

確保真空泵的出口不靠近火源，並保持通風。

## 6. 充注過程

除常規的充注過程外，還應遵循以下要求。

在使用充電設備時，確保不發生不同製冷劑的污染。軟管或管路應儘可能

短，以儘量減少其中的製冷劑含量。氣缸應保持直立。

在向製冷系統充注製冷劑之前，確保製冷系統接地。充注完成時(如果還沒有)，請標記系統。

要特別小心，不要把製冷系統裝滿。在給系統充注之前，應先用OFN進行壓力測試。

在充注完成後，在調試之前，系統應該進行洩漏測試。在離開現場之前，應進行後續洩漏測試。

## 7. 停用

在執行這一程式之前，技術人員必須完全熟悉設備及其所有細節。建議採用安全回收所有製冷劑的良好做法。

在進行這項工作之前，應採集油和製冷劑樣品，以便在回收製冷劑再使用之前進行分析。在這項工作開始之前，有足夠的電力是至關重要的。

a) 熟悉設備及其操作。

b) 電氣隔離系統。

c) 在嘗試程式之前，要確保如下：

- 如果需要，可提供機械處理設備，用於處理製冷劑氣缸；
- 所有的個人防護裝備是可用的，並被正確使用；
- 回收過程一直由有能力的人監督；
- 回收設備和氣缸符合適當的標準。

d) 如果可能的話，泵入製冷劑系統。

e) 如果真空是不可能的，做一個歧管，以便製冷劑可以從系統的各個部分去除。

f) 在進行回收之前，確保氣缸位於秤上。

g) 啟動恢復機，按照製造商的要求操作指令。

h) 氣缸不要過充。(不超過80%體積充液)。

i) 不要超過氣缸的最大工作壓力，即使是暫時的。

- j) 當氣缸充好並完成過程後，應及時將鋼瓶和設備搬離現場，並關閉設備上的所有隔離閥。
- k) 回收的製冷劑未經清潔和檢查，不得進入其他製冷系統。

#### 8. 標籤

設備應貼上標籤，說明它已退役並已清空製冷劑。標籤上應註明日期和簽名。設備上必須有易燃製冷劑標識。

#### 9. 復原

當從系統中移除製冷劑時，無論是為了維護還是停用，都建議安全移除所有製冷劑。

將製冷劑轉移到氣缸時，請確保只使用合適的製冷劑回收氣缸。確保有正確數量的氣缸保持系統總電荷可用。所有使用的氣缸都指定用於回收的製冷劑，併為該製冷劑貼上標籤(即用於回收製冷劑的專用氣缸)。氣缸應配備完整的減壓閥和相關的工作狀態良好的截止閥。空的回收氣缸被抽空，如果可能的話，在回收發生之前冷卻。

回收設備應當處於良好的工作狀態，並有一套關於手邊設備的說明，並且應當適合易燃製冷劑的回收。此外，應備有一套經過校準的磅秤，並處於良好的工作狀態。軟管應該配置完整的無洩漏斷開接頭，狀態良好。

在使用恢復機之前，要檢查恢復機是否處於令人滿意的工作狀態，已妥善維護，任何相關的電氣元件都已密封，以防止在製冷劑洩漏時著火。

如有疑問，請諮詢製造商。

回收的製冷劑應在正確的回收氣缸中返回給製冷劑供應商，並安排相關的廢物轉移通知單。不要在回收裝置中混合製冷劑，尤其是在氣缸中。如果要拆卸壓縮機或壓縮機油，請確保已將其抽真空到可接受的水準，以確保易燃製冷劑不留在潤滑油內。在將壓縮機歸還給供應商之前，應進行疏散過程。只有對壓縮機體進行電加熱才能加速這一過程。當油從系統中排出時，應安全進行。

## 存儲和處置的問題

- 請以環保的方式回收或處理產品的包裝材料。
- 嚴禁將空調倒置或側著存放或運輸，以免損壞壓縮機。
- 按照歐盟和地方法規處理本產品。製冷劑必須在處理前排放完。
- 火災或爆炸危險。本裝置裝有易燃製冷劑，必須遵守額外的安全預防措施。
- 除製造商推薦的方法外，不要使用加速除霜過程或清潔的方法。
- 產品不能儲存在類似明火，燃氣，運行中的電器裏面或者旁邊。
- 禁止刺穿或燒穿製冷劑管路。要注意，製冷劑不會有異味。
- 保持通風口暢通。
- 當處理、安裝和操作設備時。要小心避免損壞冷凍塗料管。
- 不要在產品中鑽孔。
- 維護、清潔和服務只能由受過培訓並具有使用製冷劑資格的技術人員才能提供服務。
- 產品的安裝應符合歐盟和當地法規。易燃製冷劑需要特殊處理程式。請與當地有關部門聯繫，以確保產品的環保安全。

## 使用易燃製冷劑的裝置的運輸、標記和貯存

### 運輸含有易燃製冷劑的設備

請注意，對於含有可燃氣體的設備，可能存在額外的運輸條例。允許一起運輸的設備的最大件數或設備的配置將由適用的運輸規則決定。

### 使用標誌的設備標記

在工作區域使用的類似產品的標識一般由當地法規處理，並給出工作地點提供安全和/或健康標識的最低要求。

所有必需的標誌均須保留，僱主應確保僱員得到適當和充分的指導和培訓，瞭解適當安全標誌的含義，以及因應這些標誌需要採取的行動。

標識的有效性不應該因為太多的標識被放置在一起而降低。

任何使用的象形圖都應該儘可能簡單，並且只包含基本的細節。

### 使用易燃製冷劑的設備處置

參照國家規定。

### 設備/電器的儲存

設備的儲存應按照製造商的說明進行。

### 包裝（未售出）設備的存放

儲存包的保護措施應確保包內設備的機械損壞不會導致製冷劑充注的洩漏。

允許儲存在一起的設備的最大數量將由當地法規決定。

## 智能移動應用平台服務協議

請參考移動應用程式內容：在接受本協議之前請您務必仔細閱讀本協議的移動應用程式全部內容，充分理解條款內容，特別是限制及免責條款。限製或免除責任條款，私隱聲明，將以加粗或其他醒目形式提示您注意。如果您對本協議的條款有疑問的，請聯繫相關業務部門進行詢問。除非您已閱讀並接受本協議及相關協議、規則等所有條款，否則，您無權使用本服務。一旦您選“同意協議並提交”（具體措辭詳見註冊頁面）並完成註冊流程，或您以任何方式使用本服務，即視為您已閱讀並同意上述協議、規則等的約束。如您有違反本協議的任何行為時，智能生活有權根據您違反的情況隨時單方採取限制、中止或終止向您提供服務等措施，並有權追究您相關責任。

## 如何處理廢棄電子產品

1. 請勿將電子產品當成家庭廢棄物丟棄；
2. 請依當地的法例規定處理廢棄的電子產品；
3. MOMAX鼓勵您積極參與電子產品回收計劃。

## 保養條款

1. 由購買日期起12個月內，如產品有損壞或故障，經本公司技術人員證實為在正常使用之情況下發生，本公司將提供免費維修服務；
2. 維修時必須出示本保用證及購買商號之發票正本，如果用戶不能提供，本公司有權不提供維修服務。用戶可能需要支付相關維修費用；
3. 保用期內，出現以下條款產品保用證自動失效：
  - (a) 是可消耗的部件，例如過濾網；
  - (b) 非本公司人員恣意拆解或維修產品之任何部分；
  - (c) 錯誤的操作如：非法接駁電源，以及水、污穢物滲入產品內導致產品損；
  - (d) 不可抗拒意外事件或天然災害導致產品損壞；
4. 此保用證如經塗改，保用證自動失效；
5. 本公司有權增刪任何維修及保用條款而不作通知；
6. 如因錯誤使用本公司產品而導致手提電話或其他電子產品有任何損壞，本公司不會承擔任何責任；
7. 有關 MOMAX 原裝產品和您的手機或電子產品的相容性，請在購買時向經銷商確認。此產品規格隨時可能變更，恕不另行通告；
8. 請瀏覽 [www.momax.net](http://www.momax.net) 瞭解最新產品資訊。

## 簡介

### IoT 智能2-in-1空气净化除湿机 (AP11S)

- 通过H11 HEPA，活性碳滤网及抗菌涂层净化空气。
- 环境温度低至5度仍能有效抽湿
- 通过MOMAX Smart APP进行远程控制，并可根据环境触发自动化。
- 每天最多抽湿量可达12L

### 使用之前

1. 请确保你所在地区的电源供应符合产品需求。
2. 本产品必需使用独立13A电源插座。
3. 确保电源线和产品没有破损。
4. 本产品不能代替日常通风，日常除尘。
5. 请勿将手指或其他物体插入出风口或入气口，以免造成人身伤害或设备故障。

搜寻“AP11S” in [helpdesk.momaxsmart.com](http://helpdesk.momaxsmart.com)

获取有关设定和支援。

观看最新的视频教学，学习设置和操作您的 AP11S。

随时了解最新资讯。



## 快速入门指南

### 1. 下载“MOMAX Smart”应用程序

从iOS App Store、安卓、Google Play Store或其他平台下载“MOMAX Smart”应用程序。然后，在你的手机启用蓝牙功能。

### 2. 注册

注册一个账户，然后使用您的手机号码或电子邮件地址登录。

### 3. 无线配对

按“+”（添加设备），选取“MOMAX 智能2-in-1空气净化除湿机”以添加设备。


打开设备，按住定时键约5秒直到听到一声提示声及看到Wifi提示灯在快闪。按“确定提示灯正在快闪”，再按“下一步”。

- 不能透过手机的蓝牙清单直接配对本产品。
- 搜索过程可能需要两分钟。请在此期间不要进行任何操作。

### 4. 成功连接

如果配对成功，你会在应用程序中看到本产品的图标。你可以修改此AP11S的名称。确保您的蓝牙已连接，结果将发送到手机的应用程序。


## 产品总览



1. 控制面板
2. 手提把手
3. 机身
4. 轮子


5. 空气净化滤网盖
6. 滤网
7. 水箱
8. 排水口

## 控制面板



	电源开关键
	湿度设定键
	定时键
	风速键/童锁键

## LED 显示器



- |              |          |
|--------------|----------|
| 1. Wi-Fi 指示灯 | 5. 电源指示灯 |
| 2. 相对湿度显示    | 6. 湿度指示灯 |
| 3. 童锁指示灯     | 7. 定时指示灯 |
| 4. 水满指示灯     | 8. 风速指示灯 |

	功能
	<b>电源开关键</b> <ul style="list-style-type: none"> <li>• 控制设备开机/关机</li> <li>• 当设备开机后，电源指示灯会亮起来</li> </ul>
	<b>湿度设定键</b> <ul style="list-style-type: none"> <li>• 设定环境的目标湿度，可设为40%，60%，80%或连续除湿</li> </ul>
	<b>定时键</b> <ul style="list-style-type: none"> <li>• 设定机器定时关机时间，可设为2H，4H或8H</li> <li>• 长按定时键进入配网模式</li> </ul>
	<b>风速键/童锁键</b> <ul style="list-style-type: none"> <li>• 设定机器的风速，可设为高风、低风和睡眠模式</li> <li>• 长按3秒可开启和关闭童锁功能</li> </ul>
Cont	<b>相对湿度显示</b> <ul style="list-style-type: none"> <li>• 显示机器附近的环境相对湿度值</li> </ul>
	<b>童锁指示灯</b> <ul style="list-style-type: none"> <li>• 童锁模式下会亮起，所有按键会被锁定</li> </ul>
	<b>水满指示灯</b> <ul style="list-style-type: none"> <li>• 当水箱满的时候，指示灯会亮起，而机器会停止运作</li> </ul>

#### 空气质量指示灯：

设备开机后会有约30秒的预备状态，此时控制面板底部的颜色灯会渐变（顺序为蓝青绿黄橙红紫）

空气质量对照如下：

- 空气质量良好时，灯光显示为蓝色。
- 空气质量正常时，灯光显示为黄色
- 空气质量差时，灯光显示为红色。

当机器进入睡眠模式时，全部灯光会关闭。


#### 除湿湿度设定：

当按下湿度设定键时，其相应的湿度指示灯会亮起，而机器亦会根据设定的湿度值(40%，60%，80%，连续抽湿)来进行除湿工作，将环境湿度降至设定值。

### 连续排水：

当机器需要连续排水时，用一根合适的软胶管通过进水箱的孔位连接到排水孔上。当机器连续排水运行时，水箱不会盛水。

- 将连续排水管从连续排水口伸到机器内部，然后从水箱口处将排水管插到排水孔。
- 连续排水时，排水管需平放于地面。排水管的任何部位不可有折迭和上翘的情况，以及排水管的出口端不能放入其他容器的水平面下。



## 保护功能

### 水满自动保护：

- 机器在工作时，若水箱水满的话，压缩机和风扇马达会停止工作，此时水满指示灯会亮起。
- 取出水箱后将水倒掉。
- 放回水箱，机器将按水满前的状态重新启动工作(3分钟后才会重新启动除湿功能)。

### 滤网更换提醒功能：


- 当整机累计运行满2200小时，电源指示灯会以每秒1次的频率闪烁，提示需要更换滤网。如已更换可长按电源键进行重设。

## 清洁保养

保养前，请确保拔除电源插头。

### 清洁：

用一块软布擦拭水箱及主机外壳。(请勿使用有腐蚀性的清洁剂)  
每两星期左右用吸尘器清洁一次滤网。





## 产品规格

型号	: AP11S
额定电压	: AC 220~240V, 50Hz
额定功率	: 158W
最大功率	: 205W
过滤网种类	: HEPA附活性碳及抗菌涂层
适用面积	: 可达24m <sup>2</sup> (天花高度2.3m)
空气洁净量	: 大约55.8m <sup>3</sup> /小时
水箱容量	: 3.2公升
湿度设定	: 40%, 60%, 80%, Cont
除湿能力	: 12公升/日 (30°C, 相对湿度80%) 6.9公升/日 (27°C, 相对湿度60%)
工作温度	: 5°C - 35°C
噪音量	: <45dB
最大的制冷剂容量	: R290/45g
最大允许工作压力	: 4.52MPa
最大排气压力	: 2.6MPa
无线频率	: 2.4GHz
尺寸	: 295 x 295 x 560mm
重量	: 12kg±100g

## 包装内容

1. 2 Healthy MAX IoT 智能 2-in-1 空气净化除湿机
2. HEPA滤网附活性碳及抗菌涂层 (1片)
3. 轮子 (4个)
4. 使用说明书及保用证

## 安全预防措施

本页记录了防止用户和其他人的人身伤害或财产损失的安全预防措施的主要主题。请仔细阅读，并遵守这里记录的预防事项。

1. 请勿用湿手操作本机器，或直接用水冲洗除湿机，或将本机器放置在水源附近。
2. 请勿把手放入出风口或其内部，请勿将重物放在本机器的出风口处或直接放在出风口处。
3. 请勿将任何物体扔入除湿器。
4. 请勿在使用除湿机的地方放置易燃易爆气体，请远离任何热源。
5. 严禁通过电源开关直接关闭机器，当机器长期不使用时，请关闭电源开关。
6. 如果出现任何不良情况（如机器散发出燃烧的气味），必须在切断电源时停止机器运行。
7. 在雷暴期间必须切断电源。
8. 严禁擅自更换电源线，不得中途连接电源线或与其他大功率电器并联使用。
9. 严禁擅自拆卸、修改、修理或清洁内部设备。
10. 清洗机器时，请停止使用机器，并关闭电源开关。
11. 该器具仅供室内使用。
12. 不要在维修或未正确安装的插座上使用该设备
13. 请勿使用本机，请遵循以下注意事项：  
A：靠近火源。  
B：油污可能会飞溅的地方。  
C：阳光直接照射的区域。  
D：水容易溅起的地方。  
E：靠近浴室、洗衣房、淋浴间或游泳池。
14. 千万不要将手指、杆插入出风口。要特别注意警告孩子们这些的危险。
15. 运输和储存时，请保持机组朝上，压缩机位置正确。
16. 儿童应在监护人的监督下，确保他们不玩该产品。

17. 如果电源软线损坏，必须由制造商、其服务代理或类似合格的人员，以避免危险。
18. 适用于8岁及以上儿童，以及身体、感官或精神能力下降或缺乏经验和知识的人，如果他们得到了有关以安全的方式使用该器具的监督或指导，并了解所涉及的危险。儿童不得玩该产品。未经监督，儿童不得进行清洁和用户维护。
19. 产品的安装应符合国家的线路规定。
20. 保险丝类型和额定值:T, 250V AC,6.3A。
21. 回收利用。  
该标志表明，该产品不应与整个欧盟的其他家庭废物一起处理。为防止不受控制的废物处理可能对环境或人类健康造成损害，回收利用它负责促进材料资源的可持续再利用。若要归还您使用过的设备，请使用退货和回收系统或联系购买产品的零售商。他们可以用这种产品进行环保安全的回收。
22. 请联系授权服务技术人员维修或维护本设备。
23. 不要拉，变形。或修改电源线或浸泡在水里。扯或误用电源线可能导致设备损坏和触电。
24. 应遵守国家有关气体的规定。
25. 保持通风通道畅通。
26. 任何参与制冷剂回路的工作或破坏工作的人都应持有由行业认可的评估机构出具的有效证书根据行业认可的评估，有能力安全处理制冷剂规范。
27. 维修只能按照设备制造商的建议进行。需要其他技术人员协助的维护和修理应在易燃制冷剂使用主管人员的监督下进行。
28. 请勿通过拔插电源插头的方式操作或停止设备，可能会因发热而引起电击或火灾。
29. 如果有奇怪的声音，气味或烟雾，请拔掉电源。
30. 请勿将机器靠在障碍物或墙上。
31. 机器周围后方距离及左右距离大于20cm，上方距离及前方距离大于50cm。

注意:

1. 如有零件损坏，请联系经销商或指定维修店维修。
2. 如有损坏，请关闭空气开关，断开电源，并与经销商或指定维修店联系；
3. 在任何情况下，电源线应牢固接地。
4. 为避免危险，若电源线损坏，请关闭空气开关并断开电源。它必须从经销商或指定的维修更换。



## 检查区域

在开始对含有易燃制冷剂的系统进行工作之前，必须进行安全检查，以确保将着火的风险降至最低。

对制冷系统进行维修时，应遵守以下注意事项。

### a) 工作过程

工作应在受控程式下进行，以尽量减少工作进行时存在可燃气体或蒸汽的风险。

### b) 一般工作区

所有在当地工作的维修人员和其他人员都应被告知正在进行产品工作的性质。应避免在密闭空间内工作。工作空间周围的区域应被分割。通过控制易燃材料，确保区域内的条件是安全的。

### c) 检查制冷剂是否存在

在工作之前和工作期间，应该用合适的制冷剂检测器检查该区域，以确保技术人员知道潜在的易燃气体。确保所使用的泄漏检测设备适合与易燃制冷剂一起使用，即无火花、充分密封或本质上安全。

### d) 要有灭火器

如果要对制冷设备或任何相关部件进行任何热工作，应随时准备适当的灭火设备。

在装料区附近放置干粉或二氧化碳灭火器。

### e) 无火源

任何人不得进行有关制冷系统的工程，而该工程涉及暴露任何含有或曾经含有易燃制冷剂的管道

使用任何引火源时，应使其有引致火灾或爆炸的危险。

所有可能的火源，包括吸菸，应与安装、修理、拆卸和处置的地点保持足够远的距离，在此过程中，易燃制冷剂有可能被释放到周围空间。

在进行工作之前，要对设备周围的区域进行调查，以确保没有易燃危险或点火危险。张贴禁止吸菸的标志。

### f) 通风面积

在进入系统或进行任何热工之前，确保该区域处于露天或通风良好。在工程进行期间，应保持一定程度的通风。通风应安全分散任何制冷剂，最好将其从外部排除到大气中。

### g) 检查制冷设备

在更换电子元件时，它们应符合目的和正确的规格。在任何时候都应遵守制造商的维护和服务指南。如有疑问，请向制造商的技术部门寻求帮助。使用易燃制冷剂的设施，应当进行下列检查：

充注量根据装有制冷剂部件的房间大小而定；通风设备和出口运转正常，没有堵塞；如果使用间接制冷回路，应检查二次回路是否存在制冷剂；设备上的标记继续可见和可辨认。

字迹难以辨认的，应当改正；制冷管道或部件应安装在不太可能暴露于任何可能腐蚀性制冷剂部件的物质的位置，除非部件的材料本身俱有抗腐蚀性性能，或有适当的保护措施来防止这种腐蚀。

### h) 检查电气设备

电气部件的维修和维护应包括初始安全检查和部件检查程式。如果存在危及安全的故障，则在故障得到满意的处理之前，不应将电源连接到电路上。如果故障不能立即纠正，但需要继续操作，则需要适当的临时解决方案应使用。

这将报告给设备的所有者，以便各方得到建议。初始安全检查应包括：电容器放电：这应以安全的方式进行，以避免产生火花的可能性；在充电、恢复或清洗系统时，没有暴露带电的电器元件和电线；地球连接是有连续性的。

## 密封部件的维修

- a) 在对密封部件进行维修时，在拆除密封盖等之前，应切断正在工作的设备的所有电源。如果在维修过程中绝对有必要为设备提供电源，则应在最关键的位置设置一种永久操作的泄漏检测形式，以警告潜在的危险情况。

## b) 应特别注意以下事项，以确保通过工作

电气元件，外壳的改变方式不会影响到保护水准。这包括电缆损坏、连接数量过多、端子未按原始规格制作、密封损坏、连接接头不正确等。

请确保设备安装牢固。确保密封件或密封材料没有变质，不再起到防止易燃气体进入的作用。更换部件应符合制造商的规范。

矽密封胶的使用可能会抑制某些类型泄漏检测设备的有效性。本质上安全的组件在工作之前不需要被隔离。

## 1. 修理本质上安全的部件

在没有确保不超过使用中设备允许的允许电压和电流的情况下，不要在电路中应用任何永久性的电感或电容负载。本质上安全的组件是唯一的类型，可以工作，而生活在一个易燃的气氛。测试仪器应处于正确的额定值。仅使用制造商指定的部件更换部件。其他部件可能导致制冷剂在空气中因泄漏而着火。

## 2. 布线

检查电缆不会受到磨损、腐蚀、压力过大、振动、尖锐边缘或任何其他不利的环境影响。检查还应考虑到来自压缩机或风扇等源的老化或持续振动的影响。

## 3. 易燃制冷剂的检测

在任何情况下，不得使用潜在的火源来查找或检测制冷剂泄漏。不得使用卤化物火炬(或任何其他使用明火的探测器)。

## 4. 泄漏检测方法

对于含有易燃制冷剂的系统，下列泄漏检测方法被认为是可接受的。

电子泄漏探测器应使用用于检测可燃制冷剂，但灵敏度可能不够，或可能需要重新校准。(检测设备应在无制冷剂区域进行校准)。

确保探测器不点火的潜在来源,适合使用的制冷剂泄漏检测设备应设定在一个百分比的LFL制冷剂应校准使用的制冷剂和适当比例的气体(最高25%)确认。

泄漏检测液适合与大多数制冷剂一起使用，但应避免使用含氯的洗涤

剂，因为氯可能与制冷剂发生反应并腐蚀铜管。

如果怀疑有泄漏，应清除/熄灭所有明火。

如果发现需要 焊的制冷剂泄漏，应从系统中回收所有制冷剂，或将系统中远离泄漏的部分隔离(通过关闭阀门)。

在焊前和焊过程中，应将无氧氮(OFN)通过系统进行净化

## 5. 移除和疏散

当闯入制冷剂回路进行维修或作其他用途时，常规程式应使用。

然而，重要的是遵循最佳实践，因为可燃性是一个考虑因素。应遵守下列程式:

- 移除制冷剂;
- 用惰性气体清洁线路
- 撤离;
- 再次用惰性气体清洁线路
- 通过切割或 焊断开电路。

制冷剂充注应回收到正确的回收气缸中。

系统应该用OFN进行冲洗，以保证设备的安全。

这个过程可能需要重复几次。

此任务不得使用压缩空气或氧气。

通过OFN打破系统中的真空，并继续填充，直到达到工作压力，然后排放到大气中，最后拉到真空。

这个过程应该重复，直到系统内没有制冷剂。当使用最后的OFN电荷时，系统应放气至大气压力，以使工作发生。

如果要对管道进行 焊操作，这种操作是绝对重要的。

确保真空泵的出口不靠近火源，并保持通风。

## 6. 充注过程

除常规的充注过程外，还应遵循以下要求。

在使用充电设备时，确保不发生不同制冷剂的污染。软管或管路应尽可能短，以尽量减少其中的制冷剂含量。气缸应保持直立。

在向制冷系统充注制冷剂之前，确保制冷系统接地。充注完成时(如果还没有)，请标记系统。

要特别小心，不要把制冷系统装满。在给系统充注之前，应先用OFN进行压力测试。

在充注完成后，在调试之前，系统应该进行泄漏测试。在离开现场之前，应进行后续泄漏测试。

## 7. 停用

在执行这一程式之前，技术人员必须完全熟悉设备及其所有细节。建议采用安全回收所有制冷剂的良好做法。

在进行这项工作之前，应采集油和制冷剂样品，以便在回收制冷剂再使用之前进行分析。在这项工作开始之前，有足够的电力是至关重要的。

a) 熟悉设备及其操作。

b) 电气隔离系统。

c) 在尝试程式之前，要确保如下：

- 如果需要，可提供机械处理设备，用于处理制冷剂气缸；
- 所有的个人防护装备是可用的，并被正确使用；
- 回收过程一直由有能力的人监督；
- 回收设备和气缸符合适当的标准。

d) 如果可能的话，泵入制冷剂系统。

e) 如果真空是不可能的，做一个歧管，以便制冷剂可以从系统的各个部分去除。

f) 在进行回收之前，确保气缸位于秤上。

g) 启动恢复机，按照制造商的要求操作指令。

h) 气缸不要过充。(不超过80%体积充液)。

i) 不要超过气缸的最大工作压力，即使是暂时的。

j) 当气缸充好并完成过程后，应及时将钢瓶和设备搬离现场，并关闭设备上的所有隔离阀。

k) 回收的制冷剂未经清洁和检查，不得进入其他制冷系统。

## 8. 标签

设备应贴上标签，说明它已退役并已清空制冷剂。标签上应注明日期和签名。设备上必须有易燃制冷剂标识。

## 9. 复原

当从系统中移除制冷剂时，无论是为了维护还是停用，都建议安全移除所有制冷剂。

将制冷剂转移到气缸时，请确保只使用合适的制冷剂回收气缸。确保有正确数量的气缸保持系统总电荷可用。所有使用的气缸都指定用于回收的制冷剂，并为该制冷剂贴上标签(即用于回收制冷剂的专用气缸)。气缸应配备完整的减压阀和相关的工作状态良好的截止阀。空的回收气缸被抽空，如果可能的话，在回收发生之前冷却。

回收设备应当处于良好的工作状态，并有一套关于手边设备的说明，并且应当适合易燃制冷剂的回收。此外，应备有一套经过校准的磅秤，并处于良好的工作状态。软管应该配置完整的无泄漏断开接头，状态良好。

在使用恢复机之前，要检查恢复机是否处于令人满意的工作状态，

已妥善维护，任何相关的电气元件都已密封，以防止在制冷剂泄漏时着火。

如有疑问，请咨询制造商。

回收的制冷剂应在正确的回收气缸中返回给制冷剂供应商，并安排相关的废物转移通知单。不要在回收装置中混合制冷剂，尤其是在气缸中。如果要拆卸压缩机或压缩机油，请确保已将其抽真空到可接受的水准，以确保易燃制冷剂不留在润滑油内。在将压缩机归还给供应商之前，应进行疏散过程。只有对压缩机体进行电加热才能加速这一过程。当油从系统中排出时，应安全进行。

## 存储和处置的问题

- 请以环保的方式回收或处理产品的包装材料。
- 严禁将空调倒置或侧著存放或运输，以免损坏压缩机。
- 按照欧盟和地方法规处理本产品。制冷剂必须在处理前排放完。
- 火灾或爆炸危险。本装置装有易燃制冷剂，必须遵守额外的安全防护措施。
- 除制造商推荐的方法外，不要使用加速除霜过程或清洁的方法。
- 产品不能储存在类似明火，燃气，运行中的电器里面或者旁边。
- 禁止刺穿或烧穿制冷剂管路。要注意，制冷剂不会有异味。
- 保持通风口畅通。
- 当处理、安装和操作设备时。要小心避免损坏冷冻涂料管。
- 不要在产品中钻孔。
- 维护、清洁和服务只能由受过培训并具有使用制冷剂资格的技术人员才能提供服务。
- 产品的安装应符合欧盟和当地法规。易燃制冷剂需要特殊处理程序。请与当地有关部门联系，以确保产品的环保安全。

## 使用易燃制冷剂的装置的运输、标记和贮存

### 运输含有易燃制冷剂的设备

请注意，对于含有可燃气体的设备，可能存在额外的运输条例。允许一起运输的设备的最大件数或设备的配置将由适用的运输规则决定。

### 使用标志的设备标记

在工作区域使用的类似产品的标识一般由当地法规处理，并给出工作地点提供安全和/或健康标识的最低要求。

所有必需的标志均须保留，雇主应确保雇员得到适当和充分的指导和培训，了解适当安全标志的含义，以及因应这些标志需要采取的行动。

标识的有效性不应该因为太多的标识被放置在一起而降低。

任何使用的象形图都应该尽可能简单，并且只包含基本的细节。

### 使用易燃制冷剂的设备处置

参照国家规定。

### 设备/电器的储存

设备的储存应按照制造商的说明进行。

### 包装（未售出）设备的存放

储存包的保护措施应确保包内设备的机械损坏不会导致制冷剂充注的泄漏。

允许储存在一起的设备的最大数量将由当地法规决定。

## 智能移动应用平台服务协议

请参考移动应用程序内容：在接受本协议之前请您务必仔细阅读本协议的移动应用程序全部内容，充分理解条款内容，特别是限制及免责条款。限制或免除责任条款，私隐声明，将以加粗或其他醒目形式提示您注意。如果您对本协议的条款有疑问的，请联系相关业务部门进行询问。除非您已阅读并接受本协议及相关协议、规则等所有条款，否则，您无权使用本服务。一旦您选“同意协议并提交”（具体措施详见注册页面）并完成注册流程，或您以任何方式使用本服务，即视为您已阅读并同意上述协议、规则等的约束。如您有违反本协议的任何行为时，智能生活有权根据您的违反的情况随时单方采取限制、中止或终止向您提供服务等措施，并有权追究您相关责任。

## 如何处理废弃电子产品

1. 请勿将电子产品当成家庭废弃物丢弃；
2. 请依当地的法例规定处理废弃的电子产品；
3. MOMAX鼓励您积极参与电子产品回收计划。

## 保养条款

1. 由购买日期起12个月内，如产品有损坏或故障，经本公司技术人员证实为在正常使用之情况下发生，本公司将提供免费维修服务；
2. 维修时必须出示本保用证及购买商号之发票正本，如果用户不能提供，本公司有权不提供维修服务。用户可能需要支付相关维修费用；
3. 保用期内，出现以下条款产品保用证自动失效：
  - (a) 是可消耗的部件，例如过滤网；
  - (b) 非本公司人员恣意拆解或维修产品之任何部分；
  - (c) 错误的操作如：非法接驳电源，以及水、污秽物渗入产品内导致产品损；
  - (d) 不可抗拒意外事件或自然灾害导致产品损坏；
4. 此保用证如经涂改，保用证自动失效；
5. 本公司有权增删任何维修及保用条款而不作通知；
6. 如因错误使用本公司产品而导致手提电话或其他电子产品有任何损坏，本公司不会承担任何责任；
7. 有关 MOMAX 原装产品和您的手机或电子产品的相容性，请在购买时向经销商确认。此产品规格随时可能变更，恕不另行通告；
8. 请浏览 [www.momax.net](http://www.momax.net) 了解最新产品资讯。

# **momax**

## **Warranty / 保用證 / 保用证**

Model / 型號 / 型号: \_\_\_\_\_

Date of Purchase / 購買日期 / 购买日期: \_\_\_\_\_

Remarks / 備註 / 备注: \_\_\_\_\_

### **Customer Service / 客戶服務中心 / 客户服务中心**

Hong Kong and Macau:

Unit A, 4/F., Cheung Lung Industrial Building,

10 Cheung Yee Street, Lai Chi Kok, Kowloon, Hong Kong

Hotline: 852-2402 3186 E-Mail: info@momax.net

香港及澳門:

香港九龍荔枝角長義街10號昌隆大廈4樓A室

服務熱線: 852-2402 3186 電郵: info@momax.net

中国内地:

摩米士科技(深圳)有限公司

广东省深圳市深南大道7006号万科富春东方大厦7楼

邮编: 518000 全国服务热线: 86-400-886-0010

电邮: info@momax.net.cn

Copyright © 2022 MOMAX Technology Ltd. All rights reserved.

MOMAX is registered trademark of MOMAX Technology Ltd.

All other trademarks are the property of their respective owners.

版權所有 © 2022 MOMAX Technology Ltd. 保留所有權利。

MOMAX是MOMAX Technology Ltd 的註冊商標。

所有其他商標均為其各自擁有者的財產。

版權所有 © 2022 MOMAX Technology Ltd. 保留所有權利。

MOMAX是MOMAX Technology Ltd 的註冊商標。

所有其他商標均為其各自擁有者的財產。



**WARNING: THE WORKING AREA OF THE PRODUCT SHALL NOT BE LESS THAN 9m<sup>2</sup>.**





[www.momax.net](http://www.momax.net)