



A 4x Pole




A1 2x Pole




C 2x Beam



C1 2x Beam



D 2x Beam



D1 2x Beam




D2 2x Beam



E 4x Corner Roof Bar




E1 4x Corner Roof Bar Connector




E2 8x Roof Bar



F 4x Solidfying Bar




G 4x Solidfying Bar




G1 2x Solidfying Bar




G2 2x Solidfying Bar




H 2x Finishing Bar




H1 2x Finishing Bar




(H2) 2x Finishing Bar




(J) 2x Finishing Bar



(J1) 2x Finishing Bar



(J2) 2x Finishing Bar



(J3) 4x Finishing Bar



(K) 2x Finishing Bar



(K1) 2x Finishing Bar




(K2) 2x Finishing Bar




(K3) 2x Finishing Bar




(K4) 4x Finishing Bar




(K5) 4x Finishing Bar




(L1) 2x Roof Panel




(L2) 2x Roof Panel




(L3) 2x Roof Panel




(L4) 2x Roof Panel




(M1) 2x Roof Panel




(M2) 2x Roof Panel




(M3) 2x Roof Panel




(M4) 2x Roof Panel




(M5) 2x Roof Panel




(M6) 2x Roof Panel




(M7) 2x Roof Panel




(M8) 2x Roof Panel




(N1) 2x Roof Panel



(N2) 2x Roof Panel




(N3) 6x Roof Panel




(N4) 2x Roof Panel




(N5) 2x Roof Panel




(P1) 2x Roof Panel




(P2) 2x Roof Panel



(P3) 2x Roof Panel




(P4) 2x Roof Panel




(P5) 2x Roof Panel



P6 2x Roof Panel




P7 2x Roof Panel




P8 2x Roof Panel



P9 2x Roof Panel




P10 2x Roof Panel




P11 2x Roof Panel




P12 2x Roof Panel




Q 2x Net Frame




Q1 2x Net Frame



Q2 2x Net Frame



Q3 2x Net Frame



Q4 2x Net Frame



T 4x Track




T1 4x Track



T2 2x Track




T3 2x Track




B 4x Base



B1 12x Bracket




































B3 2x Base



C2 6x Union Bar




 <b>R</b> 4x Corner Solidifying Bar	 <b>R1</b> 4x Corner Solidifying Bar	 <b>S</b> 1x Inside Roof Connector	 <b>S1</b> 1x Outside Roof Connector
 <b>S2</b> 3x J-Hook	 <b>U</b> 4x Bracket	 <b>U1</b> 6x Bracket	 <b>U2</b> 4x Bracket
 <b>U3</b> 8x Bracket	 <b>U4</b> 2x Bracket	 <b>V</b> 144x Hook	 <b>W</b> 148x Black Rubber
 <b>X</b> 6x Joint Cover	 <b>X1</b> 4x Corner Cover	 <b>X2</b> 14x Finishing End	 <b>X3</b> 12x Finishing End
 <b>Y</b> 4x Curtains	 <b>Y1</b> 4x Mosquito Netting	 <b>Y2</b> 2x Mosquito Netting	 <b>Y3</b> 2x Curtains
 <b>Z</b> 72x Plastic Bracket	 <b>Z1</b> 4x Plastic Bracket	 <b>Z2</b> 4x Plastic Bracket	 <b>Z3</b> 6x Plastic Bracket
 <b>Z4</b> 6x Plastic Bracket	 <b>1</b> 1x	 <b>2</b> 36x	 <b>3</b> 24x
 <b>4</b> 32x	 <b>5</b> 152x	 <b>7</b> 28x	 <b>8</b> 278x




M6x25

9 8x




M6x28

10 92x




M6x45

11 4x







M6x50

12 44x




7


# POST ASSEMBLY:



8



(1) Attach 2 Part #B1 to Part #A with 4 Bolts #8.



(2) Attach Part #B to Part #A with 3 Bolts #8.


(3) Repeat the above procedures to assemble the other 3 Part #A.



A1 2x



B1 4x



B3 2x




1 1x




M6x16

8 16x


9



(1) Attach 2 Part #B1 to Part #A1 with 4 Bolts #8.













(2) Attach Part #B3 to Part #A1 with 4 Bolts #8.



X2







(3) Repeat the above procedures to assemble another Part #A1.


# BEAM ASSEMBLY:




(6) Repeat the above procedures to assemble the another beam.

**X2**


-  **C2** 2x
-  **D** 2x
-  **D2** 2x
-  **X** 2x
-  **S4**
- 1** 1x
-  **M6x16**
- 8** 20x




(1) Insert Part #C2 into Part #D. and secure with 3 Bolts #8.




(2) Insert the other side of Part #C2 into Part #D2 and secure with 3 Bolts #8.




(4) Insert Part #X into the beam and secure with 1 Bolt #8.



(3) Connect Part #D2 and Part #D through Part #C2.




**X2**




(5) Secure the bottom of Part #X and Part #D2/D with 3 Bolts #8.

(6) Repeat the above procedures to assemble the another beam.




C2 2x



D1 2x



X 2x




1 1x




M6x16


8 20x




(1) Insert Part #C2 into Part #D2, and secure with 3 Bolts #8.




(2) Insert the other side of Part #C2 into Part #D2 and secure with 3 Bolts #8.



(4) Insert Part #X into the beam and secure with 1 Bolt #8.




(3) Connect Part #D2 and Part #D through Part #C2.




(5) Secure the bottom of Part #X and Part #D2/D1 with 3 Bolts #8.

(6) Repeat the above procedures to assemble the another beam.






## TRACK ASSEMBLY:

(1) Slide the plastic hooks to the double-rail track #T & T1 (each slot should slide 7 plastic hooks).




(2) Repeat the above procedures for the other 3 track #T & T1.





(1) Slide the plastic hooks to the double-rail track #T & T1 (each slot should slide 4 plastic hooks).



(2) Repeat the above procedures for the another track #T2 & T3.

✓ S4


1 1x



M6x16

8 12x

(1) Use 6 Bolts #8 to fix the track T & T1 to the beam C & C1.



15

(2) Repeat the above procedures for the other beam.

✓ S4


1 1x



M6x16


8 24x

(1) Use 12 Bolts #8 to fix the track T,T2 ,T3 &T1 to the beam D, D2 & D1.




16

(2) Repeat the above procedures for the other beam.





S4

1 1x



M6x35

4 32x



(1) Connect Part #C and #D to Part #A with 8 Bolts #4.  
(From Outside)

(2) Repeat the above procedures to assemble the other 3 corners.

▲ Please don't tighten all bolts.

✓ S4


1 1x



M6x16

8 16x

(1) Connect Part #C and #D to Part #A with 4 Bolts #8.  
(From Inside)



Repeat the above procedures to assemble the other 3 corners.

▲ Please don't tighten all bolts.

✓ S4



1 1x



M6x16




8 10x

(1) Connect Part #A1 to the middle of Part #D2 with 5 Bolts #8.




Repeat the above procedures to assemble the opposite side.

▲ Please don't tighten all bolts.


-  **R** 4x
-  **R1** 4x
-  **M6x16**
- 8** 32x

(1) Affix Part #R and Part #R1 to the frame with 8 Bolts #8.

**Inside View**




**Outside View**



Repeat the above procedures to assemble the other 3 corners.

▲ Please don't tighten all bolts.







X1 4x



ST5x16



3 16x



(1) Cover the corner with Part #X1. (2) Secure with 2 Self-tapping Screws #3. (from top to bottom)








(3) Secure with 2 Self-tapping Screws #3. (from bottom to top)




Repeat the above procedures to assemble the other 3 corners.  
▲ Tighten all bolts.






## Assemble the 4 Corner Roof Bars:




(1) Connect Part #E1 and Part #E with 2 Bolts #8 .



(2) Attach Part #U to Part #E with Bolt #8 .

(3) Repeat the above procedures to assemble the other 3 corner roof bars.



S 1x



S4

1 1x




M6x16

8 16x


Please have a freestanding ladder ready at the center of the gazebo.

(1) Place 4 Part #E1 on the 4 corners of Part #S. Secure with 8 Bolts #8. (from bottom to top)







Outside View







**ATTENTION:** You can also finish this step on the ground and then lift 4 corner roof bars and inside roof connector to the top together. (Need 2 people and 2 ladders)



Outside View











(2) Place 4 Part #E on 4 Part #A; secure with 8 Bolts #8.

-  **E2** 6x
-  **U1** 6x
-  **S4**
- 1** 1x
-  **M6x10**
- 7** 6x




(1) Attach Part #U1 to Part #E2 with Bolt #7 .

(2) Repeat the above procedures to assemble the other 5 roof bars.



(1) Attach Part #U4 to Part #E2 with Bolt #7 .

(2) Repeat the above procedures to assemble another roof bar.



E2 2x




1 1x




M6x16

8 6x


(1) Place Part #E2 on part #S. Secure with Bolt #8 (from bottom to top).



Outside View




Inside View



(2) Connect Part #E2 and Part A1 with part #U4. Secure with 2 Bolts #8.

(3) Repeat the above procedures to assemble the opposite side.



E2 2x




1 1x






M6x16

8 6x

(1) Place Part #E2 on Part #S.  
Secure with Bolt #8 (from bottom to top).




Outside View



Inside View

(2) Connect Part #E2 and the Assembled Beam (C&C1) with part #U1. Secure with 2 Bolts #8.

(3) Repeat the above procedures to assemble the opposite side.



E2 4x





1 1x



M6x16

8 12x


(1) Place Part #E2 on Part #S.  
Secure with Bolts #8 (from bottom to top).




(2) Connect Part #E2 and the Assembled Beam (D1&D2&D) with part #U1. Secure with 2 Bolts #8.

(3) Repeat the above procedures to assemble the opposite side.







S1 1x




S2 3x




Secure 3 Part # S2 to Part #S and Part #S1. (From bottom to top)  
**ATTENTION:** The holes of Part #S and Part #S1 need to be aligned, on the same vertical line.









G1 2x



G2 2x



U3 6x



1 1x




M6x10

7 6x




M6x16


8 8x




(1) Insert Part #U3 into Part #G1 and secure with Bolt #8.




(2) Insert 2 Part #U3 into Part #G2 and secure with 2 Bolts #8.




Inside View



(3) Attach Part #G1 and Part #U3 to Part #E2 with Bolt #7.




(4) Attach Part #G2, G1 and Part #U3 to Part #E2 with Bolt #7 and Bolt #8.




(5) Attach Part #G2 and Part #U3 to Part #E2 with Bolt #7.



(6) Repeat the above procedures to assemble the opposite side.



G 4x





1 1x




M6x16


8 4x



Inside View




(1) Attach Part #G and Part #U3 to Part #E2 with Bolt #8




Outside View

(2) Repeat the above procedures to assemble the opposite side.

Attach 2 Part #F and Part #U3 to Part #E2 with Bolt #7 and Bolt #8.



F 4x



U3 2x



1 1x





M6x10

7 2x




M6x16

8 4x











Inside View



Outside View

Repeat the above procedures to assemble the opposite side.

-  U2 4x
-  S4
-  1 1x
-  M6x16
-  8 12x




Outside View












2x




- (1) Insert Part #U2 into Part #F and Part #G.
- (2) Secure with 2 Bolts #8.
- (3) Secure them to Part #E with Bolt #8.




(4) Repeat the above procedures to assemble the other 3 sides.



	J1 2x
	J2 2x
	J3 4x
	Q1 2x
	Q2 2x
	Q3 2x
	Q4 2x
	S4
	1
	M6
	5 8x
<b>34</b>	

- (1) Connect Part #J1 and Part #Q1 with 1 Bolt #7 and 1 Nut #5.
- (2) Connect Part #J3 and Part #Q3 with 1 Bolts #7 and 1 Nuts #5.



- (3) Connect Part #J3 and Part #Q4 with 1 Bolts #7 and 1 Nuts #5.
- (4) Connect Part #J2 and Part #Q2 with 1 Bolt #7 and 1 Nut #5.




	M6x10
	7 8x

- (5) Repeat the above procedures to assemble the opposite side.




ST6.3x15


2 6x



Inside View




(1) Place the Assembled J1 & Q1, J3 & Q3, J3 & Q4 and J2 & Q2 on Part #E2, securing with 3 Self-tapping Bolts #2.




(2) Repeat the above procedures to assemble the opposite side.





J 2x



Q 2x



1 1x



2 2x




5 4x





7 4x

(1) Connect Part #J and Part #Q with 2 Bolts #7 and 2 Nuts #5.



(2) Place the Assembled Part #J & #Q on Part #E2, securing with 1 Self-tapping Bolt #2.



(3) Repeat the above procedures to assemble the opposite side.




X3 4x




ST6.3x15

2 4x

(1) Place Part #J and Part #J1 on Part #E; put on Part #X3 and secure with Self-tapping Screw #2.



Inside View



(2) Repeat the above procedures to assemble the other 3 corners.




# Cover Part #Z, #Z1 & #Z2 to Roof Panels.


(L1) 2x



(L2) 2x



(L3) 2x



(L4) 2x








(Z) 8x



(Z1) 4x




(Z2) 4x




Attach Z/Z1/Z2/Z3/Z4 by lightly tapping with a screwdriver.


# Cover Part #Z, #Z3 & #Z4 to Roof Panels.




(N1) 2x




(N2) 2x




(N3) 6x




(N4) 2x




(N5) 2x






(Z) 12x



(Z3) 2x







(Z4) 2x





X2

**ATTENTION: The bigger roof panel need to cover the smaller one.**




(1) Insert Part #N1 and Part #N2 into the frame; attach Part #H1 to Part #E2, securing with Bolt #2.

(2) Insert Part #N5 and Part #N4 into the frame; attach Part #H2 to Part #E, securing with Bolt #2.




**▲ Please don't tighten all bolts.**





(3) Repeat the above procedures to assemble the opposite side.

(1) Insert 3 Part #N3 into the frame.




⚠ When installing Part #H1, K4, K5, H2, you should unscrew the bolt that have not been tightened.





K4 2x



K5 2x




X2 6x




ST6.3x15



2 6x



(1) Place Part #H1 and Part #K4 on Part #E2; put on Part #X2 and secure with Bolt #2.




(2) Place Part #K4 & #K5 on Part #E2; put on Part #X2 and secure with Bolt #2.



(3) Place Part #K5 and Part #H2 on Part #E2; put on Part #X2 and secure with Bolt #2.

(4) Repeat the above procedures to assemble the opposite side.

**ATTENTION:** The bigger roof panel need to cover the smaller one.




(H) 2x




ST6.3x15




(2) 2x



(1) Insert Part #L1 and Part #L2 into the frame.



(2) Insert Part #L4 and Part #L3 into the frame.



(3) Attach Part #H to Part #E2, securing with Self-tapping Bolts #2.

(4) Repeat the above procedures to assemble the opposite side.






X3 4x




ST6.3x15

2 4x

(1) Place Part #H and Part #H2 on Part #E1;  
put on Part #X3 and secure with Self-tapping Screw #2.





Outside View




(2) Repeat the above procedures to assemble the other 3 corners.










# Cover Part #Z to Roof Panels

X2












Section View




-  (M1) 2x
-  (M2) 2x
-  (M3) 2x
-  (M4) 2x
-  (M5) 2x
-  (M6) 2x
-  (M7) 2x
-  (M8) 2x
-  (Z) 28x





# Cover Part #Z, #Z3 and #Z4 to Roof Panels










-  **(P1) 2x**
-  **(P2) 2x**
-  **(P3) 2x**
-  **(P4) 2x**
-  **(P5) 2x**
-  **(P6) 2x**
-  **(Z) 12x**
-  **(Z3) 2x**
-  **(Z4) 2x**






**X2**







# Cover Part #Z, #Z3 and #Z4 to Roof Panels

-  **P7** 2x
-  **P8** 2x
-  **P9** 2x
-  **P10** 2x
-  **P11** 2x
-  **P12** 2x
-  **Z** 12x
-  **Z3** 2x
-  **Z4** 2x











▲ Part #W should be inserted between roof panels and solidifying bar or beams, then secure with bolts and nuts.



**ATTENTION: The bigger roof panel need to cover the smaller one.**




(1) Insert Part #P1, Part #P2 and Part #P3 into the frame. (2) Insert Part #P12, Part #P11 and Part #P10 into the frame.




(3) Place 2 Part #W between roof panels and solidifying bars. Then secure with 2 Bolts #12 and 2 Nuts #5.


(4) Place 10 Part #W between roof panels and beams. Then secure with 10 Bolts #10 and 10 Nuts #5.



(5) Repeat the above procedures to assemble the opposite side.



(W) 24x



(1) 1x




M6

(5) 24x




M6x28

(10) 20x




M6x50

(12) 4x



(W) 40x



(1) 1x




M6

(5) 40x



M6x28

(10) 24x




M6x50



(12) 16x

**ATTENTION: The bigger roof panel need to cover the smaller one.**


(1) Insert Part #P4 and Part #P5 into the frame.




(2) Insert Part #P9 and Part #P8 into the frame.




(3) Place 8 Part #W between roof panels and solidifying bars. Then secure with 8 Bolts #12 and 8 Nuts #5.




(4) Place 12 Part #W between roof panels and beams. Then secure with 12 Bolts #10 and 12 Nuts #5.



(5) Repeat the above procedures to assemble the opposite side.



W 24x



1 1x



M6

5 20x




M6x25

9 4x



M6x28

10 12x





M6x50

12 8x


**ATTENTION: The bigger roof panel need to cover the smaller one.**

(1) Insert Part #P6 into the frame.





(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5; Place 1 Part #W between roof panels and Part #E2.

Then secure with 1 Bolt #9.




(2) Insert Part #P7 into the frame.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.

(5) Repeat the above procedures to assemble the opposite side.





W 12x



1 1x



M6



5 12x





M6x28

10 12x



**ATTENTION: The bigger roof panel need to cover the smaller one.**



(1) Insert Part #M1 and Part #M2 into the frame.




(2) Insert Part #M8 and Part #M7 into the frame.



(3) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.

(4) Repeat the above procedures to assemble the opposite side.



(W) 20x



(1) 1x




M6

(5) 20x



M6x28

(10) 12x




M6x50



(12) 8x

**ATTENTION:** The bigger roof panel need to cover the smaller one.


(1) Insert Part #M3 into the frame.




(2) Insert Part #M6 into the frame.



(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.




(5) Repeat the above procedures to assemble the opposite side.





W 24x



1 1x



M6

5 20x




M6x25

9 4x



M6x28

10 12x




M6x50


12 8x

**ATTENTION: The bigger roof panel need to cover the smaller one.**


(1) Insert Part #M4 and Part #M5 into the frame.




(2) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.



(3) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.



(4) Repeat the above procedures to assemble the opposite side.



(W) 4x




(1) 1x



M6



(5) 4x




M6x45

(11) 4x


Place Part #W between roof panels and Part #E2. Then secure with Bolt #11 and Nut #5.




Repeat the above procedures to assemble the other 3 sides.




K2 2x




K3 2x



K4 2x



K5 2x




X2 6x





ST6.3x15


2 6x



(1) Place Part #K4 and Part #K5 on Part #E2; Put on Part #X2 and secure with Bolt #2.




(2) Place Part #K2 on Part #K4 and Part #E2; Put on Part #X2 and secure with Bolt #2.




(3) Place Part #K3 on Part #K5 and Part #E2; Put on Part #X2 and secure with Bolt #2.

(4) Repeat the above procedures to assemble the opposite side.



(K) 2x



(K1) 2x





(X2) 2x



ST6.3x15

(2) 2x

(1) Attach Part #K and Part #K1 to the frame; Put on Part #X2 and secure with Self-tapping Bolt #2.



(2) Repeat the above procedures to assemble the opposite side.




X3 4x



ST6.3x15

2 4x



(1) Place Part #K3 and Part #K on Part #E;  
Put on Part #X3 and secure with Self-tapping Screw #2.


(2) Repeat the above procedures to assemble the other 3 corners.






ST5x16


3 8X



Attach roof panels to finishing bars  
with 8 Self-tapping Screws #3.




Y1 4x




Y2 2x



# Hang up Mosquito Netting to **Inside Track**



Y1




Y1



Y1


7 Hooks

Y1



7 Hooks



7 Hooks



7 Hooks

Y1


Y2 8Hooks



8Hooks


Y2

Y1



7 Hooks


7 Hooks



7 Hooks

7 Hooks

Y1







Y 4x



Y3 2x


# Hang up Curtains to Outside Track



7 Hooks



Y3 8Hooks






7 Hooks

7 Hooks

7 Hooks

7 Hooks



7 Hooks

Y3 8Hooks

Y 7 Hooks

