

# INSTRUCTIONS



## FXRP FAIRING FOR '91-'05 DYNA

**QUESTIONS?**  
EMAIL: [info@getklocked.com](mailto:info@getklocked.com)  
CALL: (605) 996.3700


### TOOLS NEEDED:

- |                |                |                        |                             |
|----------------|----------------|------------------------|-----------------------------|
| - Ratchet      | - 9/16" Socket | - 9/16" Wrench         | - Phillips Head Screwdriver |
| - 7/16" Socket | - 7/16" Wrench | - 3/16" Hex Bit Socket | - Fender Cover/Towel        |
| - 1/2" Socket  | - 1/2" Wrench  | - Torque Wrench        |                             |

**We highly recommend a complete installation for test fit prior to paint. The test fit is also important to test for handlebar clearance that may need to be adjusted or replaced.**

### 1. Verify all the contents of the Fairing Fit Kit (FIG 1):

- a. Fairing
- b. Neck Bracket
- c. Lower Bracket
- d. Lower Support
- e. Fairing Mount Adapter
- f. 7" Headlight Mount Ring
- g. Hardware Kit
  - i. Hardware Bag "B" - Windshield
  - ii. Hardware Bag "C" - 7" Headlight Ring Mount
  - iii. Hardware Bag "D" - Fairing to Neck
  - iv. Hardware Bag "E" - Lower Support to Fairing
  - v. Hardware Bag "F" - Neck to Frame
  - vi. Hardware Bag "G" - Lower Bracket to Frame
- h. Headlight Cover Kit
  - i. Headlight Cover
  - ii. Headlight Cover Trim
  - iii. Headlight Cover Hardware
  - iv. Headlight Cover Instructions
- i. FXRP 9" Dark Smoke





## INSTRUCTIONS CONTINUED



2. Cover the front fender to help protect against damage (FIG 2).
3. Disconnect negative battery cable.
4. Remove windshield and fairing if equipped.



5. Remove headlight and mount (FIG 3).
6. Using **Hardware Bag "G"** install the **Lower Bracket** to the frame. Hardware can be finger tight for now (FIG 4).
7. Remove front fuel tank bolt. Using **Hardware Bag "F"**, install the **Neck Bracket** (FIG 5) with upper bolt through fuel tank and lower bolt through lower bracket (FIG 6). **Neck Bracket** is installed outside of the fuel tank tabs. Hardware can be finger tight for now.



8. Using **Hardware Bag "D"**, install **Fairing** (FIG 7) and **Fairing Mount Adapter** to the **Neck Bracket**. Position the **Fairing Mount Adapter** so the notch is at the 6 o'clock position (FIG 8). Snug bolts down, still allowing for side-to-side adjustments.
9. Using **Hardware Bag "E"** install the **Lower Support**. This support shares the 3/8" bolt through the center of the Lower Bracket already used in Step 6. Install the 1/4" hardware through the **Fairing** and **Lower Support**. The mounting plates at the ends should be inside the fairing not underneath (FIG 9).



## INSTRUCTIONS CONTINUED

10. Tighten all loosely installed hardware in order below to torque values listed.
  - a. Hardware Bag "G" - 3/8" hardware - Lower Bracket to Frame - 18 ft-lbs.
  - b. Hardware Bag "F" - 5/16" hardware - Neck Bracket - 13 ft-lbs.
  - c. Hardware Bag "E" - 1/4" hardware - Lower Support to Fairing - 45 in-lbs.
  - d. Hardware Bag "D" - 3/8" hardware - Fairing to Neck - 18 ft-lbs.
11. Using **Hardware Bag "C"** install **7" Headlight Ring Mount to Fairing Mount Adapter**. Torque to 45 in-lbs (FIG 10). If not using trim ring, remove screw from threaded tab.
12. Remove headlight retaining ring, install headlight and reinstall retaining ring (FIG 11).  
**NOTE:** Headlight adjustment screws with springs may require thread locking compound after adjustments are made.
13. Using **Hardware Bag "B"** insert the seven well nuts and install the provided **9" Dark Smoke Flare®**. Torque to 10 in-lbs (FIG 12).
14. Refer to instructions in FXR Fairing Headlight Cover Kit (white box) for Cover install.



Klock Werks is not held responsible for any damage resulting from improper installation performed by the consumer or their dealer.