

# EOS Junior-T



## ASSEMBLY INSTRUCTIONS

*Note: This is an all-inclusive manual. It shows optional accessories and customizations that may not apply to your greenhouse. Direct any questions to Exaco.*



***Assembly Videos can  
be found by scanning  
the code to the left  
with your  
smartphone.***



***www.exaco.com***

***877-760-8500***

Or find the link to our YouTube page at [www.exaco.com](http://www.exaco.com). Go to the Victorian Greenhouse Playlist for all videos.

# Table of Contents

Introduction & General Information.....	3
Packing List.....	4-
Foundation Measurements and Planning.....	6
Option: Placing Greenhouse on a Stem Wall	
Junior Orangerie on a Stem Wall.....	7
Single Sliding Door on a Stem Wall.....	8
Double Sliding Door on a Stem Wall.....	9
Glass Specs.....	12-13
Diagram of Greenhouse Extrusions/Profiles.....	14
Assembling your Greenhouse Frame	
Foundation Frame and Side Walls.....	15-21
Building the Roof.....	22-34
Gutter Downspouts and Roof Decorations.....	33
Retro Greenhouse Assembly.....	35
Installing the Glazing.....	36-42
Important Information before installing glazing.....	37
Polycarbonate greenhouse procedures.....	38
Glazing and Gasket Installation.....	39-42
Door Assembly and Installation	
Sliding Door Assembly and Information.....	44-48
Option: Sliding Door Low Threshold Installation.....	49-50
Sliding Door Lock.....	51-52
Hinged Door Installation.....	64-74
Hinge Adjustment.....	75-76
Window and Vent Installation	
Roof Window/Vent Assembly/Installation.....	53-54
Roof Vent Openers.....	54-56

Louvered Window Assembly/Installation .....	57-59
Louvered Window Cover.....	60
Option: Push Out Window Assembly.....	61-63
Shelving options	
2 Slat Shelf Assembly.....	77
5 Slat Shelf Assembly.....	78
Narrow Top Shelf Assembly.....	79
Seed Bed/Tray Assembly.....	80
Option: Shadecloth Assembly.....	81-82
Misting System.....	83
Option: Exhaust Fan Installation.....	84
Option: Fly Screens for Window/Door.....	85-87
Customer Service Information.....	88



## Customer Service or Assembly Questions?

Give us a call: 1-877-760-8500

[customerservice@exaco.com](mailto:customerservice@exaco.com)

[www.EXACO.com](http://www.EXACO.com)

Please watch our assembly videos on our Exaco YouTube Channel, find the link at [www.exaco.com](http://www.exaco.com), then go to the Victorian Greenhouse Playlist - or scan the QR code to the right!



---

# PRODUCT INFORMATION

Dear customer,

Thank you for buying a Janssens high-quality aluminium greenhouse.

## REMARKS

In this manual, you will find the assembly instructions for all basic/standard-model greenhouses. However, this manual also contains pages which apply to optional accessories that may not be included with your kit. *This greenhouse is designed for cultivation of plants/flowers. Therefore leakage, water drops and condensation inside the building are allowed.* The building may only be entered by competent persons during cultivation or maintenance. Aluminium profiles that are not painted may show black stains, these stains are not a production error: they can be easily removed with an aluminium cleaner available at a home improvement store. The rubber strips have been treated with oil/silicone on the interior to facilitate the assembly. The building should be mounted on a solid concrete foundation deep enough to get a solid and frost-free ground. Anchoring of the foundation should be made by the owner or operator and should be checked periodically. During winter, the roof will need to be cleared of snow or supported in a suitable way. The greenhouse should be built in a location protected from strong winds. Protective gear (such as protective gloves) should be used during assembly in order to avoid injuries. One should at all times pay attention to the local building regulations.

## ASSEMBLY ORDER

The assembly procedure is the same for all our greenhouses.

- Sorting of the profiles/extrusions according to the model/size of greenhouse. The aluminum profiles (extrusions) are identified by their cross-section and length.
- Assembly of the complete aluminium framework.
- Leveling of the construction using a level
- Anchoring/securing of the greenhouse to the ground
- Glazing installation

## REQUIRED TOOLS

- Metric or Combination Measuring Tape (highly recommended)
- Socket wrench or spanner 10mm
- Level
- Screwdriver
- Drill + drill bit 4.2 mm
- Scissors (to cut the rubber).


We reserve the right to change the construction without prior notice!

**Questions? Need Assembly Support?**  
**Please call Exaco at 877-760-8500, ext. 701 or email**  
**customerservice@exaco.com.**

# STANDING PALLET

WEIGHT: 510 kg

DIMENSIONS:  
800 x 900 x 2200 mm



ITEM	PC
DAKR_HEL	2 pc
PRO6578 corner profile	1430 mm 6 pc
PRO40633 inner corner profile	1430 mm 2 pc
PRO6918 endbar roof	1430 mm 6 pc
PRO1456 glazing bar	1430 mm 18 pc
PRO10980 round tube Ø40	1500 mm 4 pc
PRO1748 rubber 12,5m/rol	7 pc
TRE wind bracings sides	1614 mm 16 pc
ZAKJE_SILICONEN	1 pc
ESD_183_ZS	1 pc
decorations	9 pc
ridge decoration (box)	2 pc


ITEM	PC
PRO6120 foundation profile	829 mm 2 pc
PRO6120 foundation profile	829 mm 2 pc
PRO20779 gutter profile	829 mm L 2 pc
PRO20779 gutter profile	829 mm R 2 pc
NOKSTUK_EOS	1 pc
K 30X30 tube 30x30x2 mm	1490 mm 1 pc
U 30x30x30x2	1490 mm 1 pc

POSITION	GLAS DIMENSIONS	PC
door	730 x 1850 mm	1 pc
gables + roof	730 x 1450 mm	22 pc
special-size	450 x 1450 mm	4 pc
triangle E3	361 x 520 x 290 mm (*70)	2 pc
triangle E1	730 x 680 x 85 mm	6 pc
triangle E2	361 x 910 x 690 (*70)	4 pc
roofwindow	730 x 825 mm	2 pc
underneed roofwindow	730 x 625 mm	2 pc
special triangle ET1	430 x 552 x 1 mm	4 pc
special triangle ET2	730 x 1440 x 555 mm (*35)	4 pc

# COLLI A JUNIOR

WEIGHT: 22 kg

DIMENSIONS:  
240 x 120 x 2600 mm




ITEM	PC
PRO6120 foundation profile	2360mm 2 pc
PRO20229 horizontal gable prof.	2244 mm 1 pc
PRO20229 horizontal gable prof.	768mm L 1 pc
PRO20229 horizontal gable prof.	768mm R 1 pc
PRO20229 horizontal gable prof.	768mm L+R 1 pc
L 40x40 GATFUND	400 mm 4 pc
PRO1456 glazing bar	918 mm 1 pc
PRO1456 glazing bar	672 mm L 1 pc
PRO1456 glazing bar	672 mm R 1 pc
PRO1456 glazing bar	520 mm 1 pc
PRO1456 glazing bar	2130 mm L 1 pc
PRO1456 glazing bar	2130 mm R 1 pc
TRE wind bracings sides	2065 mm 2 pc
SAPAK_EOS	1 pc

# COLLI B EOS T

WEIGHT: 25 kg

DIMENSIONS:  
240 x 120 x 2250 mm




ITEM	PC
PRO6120 foundation profile	2010 mm L 1 pc
PRO6120 foundation profile	2010 mm R 1 pc
PRO20779 gutter profile	2010 mm L 1 pc
PRO20779 gutter profile	2010 mm R 1 pc
PRO40091 ridge profile	1918 mm 3 pc

# PACKING LIST "EOS JUNIOR T"

## COLLI A EOS T

WEIGHT: 21 kg


DIMENSIONS:  
240 x 120 x 2600 mm





ITEM	PC
PRO1456 glazing bar	918 mm 1 pc
PRO1456 glazing bar	672 mm L 1 pc
PRO1456 glazing bar	672 mm R 1 pc
PRO1456 glazing bar	555 mm L 2 pc
PRO1456 glazing bar	555 mm R 2 pc
PRO41942 valley roofbeem	1805 mm 2 pc
PRO6120 foundation profile	2360mm 1 pc
PRO20229 horizontal gable prof.	2244 mm 1 pc
L 40x40 GATFUND	400 mm 4 pc
PRO2290 heavy rubber 5 m	1 pc
SAPAK_EOS	1 pc
ZAK_TMODEL	1 pc
ZAKJE_BOUT_?	3 pc

# GLASS-SET EOS JUNIOR T

Replacement glass should be 3/16" thick tempered safety glass, no tint, edges may be unfinished




## GABLE PIECES:



# " JUNIOR ORANGERIE "


Please call Exaco for measurements if you have a custom greenhouse.



## Notes:

- Do not set anchors in concrete until the entire greenhouse frame is complete, level and square. You will need some play to attach the uprights.
- It is recommended to build your foundation down to the frost line in your area and/or consult a local contractor for recommendations.
- Greenhouse base frame is 2.25" wide
- Corner anchor posts are 1.5" x 1.5". They attach at the interior corners of the base frame, then extend 12" below ground. Bolts attach to the bottom of the anchor to be a "catch" in the concrete. We recommend leaving a 4 to 6" hole in your concrete for the anchor. Do not embed the corner anchors into concrete until the greenhouse structure is built, leveled and square.
- Embedding the corner anchor into concrete is the most secure method, although you may choose to trim them off, cut in half, and use as L brackets to attach to the greenhouse and foundation with the appropriate stainless steel screws (i.e. Tap Con screws for concrete)

<b>A</b> = 1+2+3	<b>1</b> 829mm (32.6") <b>2</b> 2360mm (92.9") <b>3</b> 829mm (32.6")	<b>A</b> = 4018 158.2"
<b>B</b> = 4+5	<b>4</b> 2360mm (92.9") <b>5</b> 829mm (32.6")	<b>B</b> = 3189 125.5"





OPTIONAL: Stem Wall Single Sliding Door

If you are placing your greenhouse on a stem/knee wall, please reach out to Exaco for details before constructing your wall to ensure it is properly built.


If you are placing your greenhouse at ground level - you may continue your build.









**Note:** When assembling the foundation in this step, only hand-tighten the nuts. The corners may need to be slightly loose to attach the corner uprights (PRO6578).












**Suggestion:** If installed on a concrete foundation you may cut PRO210 flush with the bottom of PRO6120. To anchor, use cut off PRO210 pieces as L-brackets to secure the PRO6120 to the concrete foundation. Please see YouTube animated assembly video for more information.






Before attaching, insert 3 M6x15 bolts as shown for the sliding door guide.








	ITEM	PC.	L
	PRO210	8 PC.	400 MM
	PRO6120	2 PC.	2.010 MM
	PRO6120	3 PC.	2.360 MM
	PRO6120	2+2 PC.	829 MM
	M6x12	32 PC +6 PC + 4PC	
	M6x50	32 PC	
		1 PC.	600 MM
		8 PC.	







**NOTE:** You may need to loosen the nuts holding your anchor corner brackets to allow some "play" in the corner to slide the corner post (PRO6 78) onto the bolt heads. It is helpful to have a second person holding the bolts in line with a needle nose pliers while a second person slides the corner profile into place.

	ITEM	PC.	L
	PRO6578	6 PC.	1.430 MM
	M6X12	16 PC.	
	PRO40633	2 PC.	1.430 MM











	ITEM	PC.	L
	PR020229	2 PC.	2.244 MM
	M6x12	4 PC.	






11







JO3








ITEM	PC.	L
	20x55x20	1 PC. 600 MM
	15x20	1 PC. 600 MM
		27 PC.


**OPTIONAL:** If you purchased shade curtains, insert the slider loops into the gutter profile channel before this assembly step. See pages 68-70 for more information.

ITEM	PC.	L
	PRO20779	2 PC. 2.010 MM
	PRO20779	2+2 PC. 829 MM
	M6x12	10 PC.







		2 PC.
	LG	2 PC.
	M6x12	4 PC.






**OPTIONAL:** If you purchased shade curtains, insert the slider loops into the gutter profile channel before this assembly step. See pages 68-70 for more information.







	ITEM	PC.	L
	PRO20229	3 PC.	773 MM L + R + LR
	PRO1456	2 PC.	2.130 MM
	M6X12	12 PC.	







**NOTE!**





Before securing vertical profiles, insert bolts for:  
 Louvered Window, see p. 40  
 Optional Top Shelf, see p. 62  
 Optional Seed Tray, see p. 63

	ITEM	PC.	L
	PRO1456	9 PC.	1430 MM
	M6x12	18 PC.	




**Important!** If your wind braces don't fit where they should, your greenhouse is not square/level. Please go back to ensure your structure is square!




	ITEM	PC.	L
	K 30 x 30	1 PC.	1.500 MM
	U 30 x 30	1 PC.	1.500 MM
		1 PC.	
		20 PC.	









Insert bolts to connect short uprights to the PRO6 18. You will need as many bolts as you have short uprights.





A





B





	ITEM	PC.	L
	PRO6918	6 PC.	1.430 MM
	PRO40091	3 PC.	1.918 MM
	M6X12	12 PC.	






For additional support in heavy snow areas, you may add a stainless self-tapping screw (not included) next to the bolt where the rafter meets the ridge and gutter.










	ITEM	PC.	L
	PRO1456	2 PC.	918 MM
	PRO1456	2+2 PC.	672 MM
	PRO1456	1 PC.	520 MM
	M6x12	21 PC.	
	LG	9 PC.	




ITEM	PC.	L
 PRO1456	9 PC.	1430 MM
 PRO1456	2 PC.	703 MM
 M6x12	30 PC.	

Crossbar for framing roof vent opening. Roof Vents can be installed in any bay. Insert bolts to attach connecting plate.




	ITEM	PC.	L
	PRO41942	2 PC.	1805 MM
	PRO1456	4 PC.	555 MM
	M6x12	10 PC.	
	M6x25	2 PC.	
		4 PC.	





**Very Important!** Push the ridge beam up at least 10mm (1/2 ") before tightening the spandrel/scroll support bolts to reduce roof sag.

ITEM	PC.
	9 SETS



**X** = EXTRA FIXING / EXTRA BEFESTIGUNG / ATTACH EXTRA




**Important!** If your wind braces don't fit where they should, your greenhouse is not square/level. Please go back to ensure your structure is square!



	ITEM	PC.	L
	TRE	12 PC.	1611 MM
	TRE	4 PC.	1611 MM
	TRE	2 PC.	2060 MM
		2 PC.	





**Note:** Attach the elbow to the greenhouse base. First, drill a small hole in the back of the elbow and then a small hole in the frame of the greenhouse for the screw to thread into. Run the screw through the hole on the inside of the elbow and into the greenhouse base.




Use 38mm screw from (ZAK\_H)

22

JO14






10 mm  
POLYCARBONATE




Find your Glass Holders in ZAK\_H  
(with your gutter pieces and other hardware)

Glazing supports slide onto the  
gutter profile, space them 100mm  
or 4 inches from each roof profile.










**Glazing shim installation:**

Install the glass panels then fix the shims to either side of the glass with a dab of silicon. Then install the rubber trim. Shims are only installed in end panels as shown below. Space the shims 100mm/4" from the top and bottom. Polycarbonate units will not use these shims.








To install gasket, roll it back on itself as shown. This exposes the inner flange that is pushed into the channel. It will be easier to insert when warm and pliable.







**NOTE:** Crescent seal is only installed in the eaves and roof.  
 Not along side walls.






It helps to use a tool to push the gasket up under the eaves. Note that it inserts under the second flange further up.




# Sliding door (standard for most models) Some models will have double sliding doors.



# Sliding door installation continued




Slide door rollers into top door hanger (PRO7546 or PRO7876) and slide a stopper on either side. Determine how far you want your door to slide, then tighten the screw on the bottom of the stopper to secure. Finish with door hanger caps.




Attach bottom door guide (PRO39796) to your foundation frame (PRO6120). If you have purchased a low threshold option, please see the following page for instructions.

# Roof Window Vent - all hardware is in roof window package




Note: Rubber seal is only installed on the sides of the roof window.

Note: A 1 inch long bolt is inserted into the lower profile. This bolt is for the optional manual or the spindle opener.




# Roof Window Installation


**Note:** Inserting a bolt/nut on both sides of the roof window will prevent it from moving side to side once it is in place.



Standard manual opener shown (generally not installed). However, it may be used to secure the window in the closed position - auto opener **MUST** be detached.




**STEP 1:** Slide window into the ridge beam from either end of the greenhouse. The "hook" on the top of the roof window profile will slide into the channel of the ridge beam.



# OPTION: Auto Opener (Ventomax)

**IMPORTANT!** Read installation instructions included in your Ventomax auto opener box to ensure proper installation. There is also information to fully understand the functioning and maintenance of these unique openers.




The Ventomax openers work with an oil filled piston (black cylinder). The oil begins to expand around 72 degrees and will push out and open your window when the temperature in the greenhouse is above 75 degrees (outdoor temp will likely be cooler).

Installing the automatic opener requires 2 bolts to be inserted into the roof crossbar for the lower mount. The upper mount will clamp onto the window profile. (Shown to the right)


**If you are struggling to install your piston and it is above 70 degrees, place the piston in cold water/ fridge for 10 minutes so the rod can retract.**

**Oil piston rod 2-3 times/year with a light oil such as WD40 or even olive oil.**






# OPTION: Spindle Manual Opener



Installation Option 1:  
Mount top of opener to  
window with a screw

Installation Option 2: Insert a 1 inch long bolt into  
lower roof window channel. Slide to the center and  
lock it in place with a nut as shown below.

Next, hold the lower U-shaped mount up  
to the crossbar and mark the center of one  
hole. Using a 1/8" drill bit, drill the first  
hole, then screw the bracket on, check for  
level - then mark and drill the second hole.  
Slide the brass part of the opener over the  
bolt in the window channel. Use the  
supplied nylock nut to secure the opener  
on the top mounting bolt. Finally thread  
the large side bolts into the U-shaped  
mount and the opener is installed.



## **ACCESSORIES**

This section contains many of the optional accessories.

You will have some, but likely not all, items seen in this section.


**IMPORTANT:** Find Janssens Accessory installation video on our site here:

<https://www.exaco.com/greenhouse-victorian.php>

It will be immensely helpful!



# OPTIONAL UPGRADE: Low Threshold for Sliding Door/s






**OPTIONAL UPGRADE:**

Low Threshold for Sliding Door/s p. 2






Attach bottom door guide to low threshold and foundation frame.



OPTION



Install lock at bottom of a:  
-Single Sliding Door  
-First door of double sliding doors  
-both of your double sliding doors





OPTION




If you have a double sliding door, you may install one lock on the inside of your greenhouse as shown

(View from inside at top of door)

Ø 10




# Roof Window Vent - all hardware is in roof window package



Note: Rubber seal is only installed on the sides of the roof window.



Note: A 1 inch long bolt is inserted into the lower profile. This bolt is for the optional manual or the spindle opener.



# Louvre Window - All Standard Royal models include one louvred window

Note: All louvered window are black (even with green models).




Insert a washer between black louvre frame and the greenhouse profile at all four bolt locations.

It is likely that your kit include an automatic opener (SESAM LIBERTY) for the louvre vent. Please refer to the Installation and Care manual packaged with the Sesam Liberty opener. You will need to remove the manual opener following the directions.



Piston maintenance: apply a light oil (WD40 or olive oil work) to the piston rod to keep it moving smoothly 2-3 times/year.




1




Louvre window may be installed on sidewall (under gutter profile (PRO20227)) or on gable end (under horizontal gable profile (PRO20229)). Both are shown to the left and below.



2



3




Insert a washer (not included) between black louvre frame and the greenhouse profile at all four bolt locations.

4X

4

Pinch louvre clamps together to hold glass. We recommend using a few dabs of silicone where the glass meets the clamps to hold the glass more securely. You may use the silicone that came with your red shims.



# Louver Window Cover



During cold weather, the louvered window may get drafty. Your kit includes a lexan cover to seal the louvers during this time.



To install the Lexan panel:


- Unscrew the piston from your auto opener
- Go outside the greenhouse and pull back the heavy duty rubber gaskets that hold in the panes of glass to the left, right, and bottom of the louvered window (see picture to the right)
- Place the lexan panel over the louvers as though it were a pane of glass and replace all the heavy duty gaskets (see photos below)




OPTION: Push out window - no standard Royals include this option unless added










RUBBER E400330








RUBBER PRO1748









# Option: Hinged Door




IMPORTANT: Find Janssens Accessory installation video on our site here: <https://www.exaco.com/greenhouse-victorian.php>



HD 1





	ITEM	PC.	L
	L 40X40	4 PC	36 MM
	PRO6280	2 PC	703 MM
	PRO6280	2 PC	1.441 MM
	PRO6280	2 PC	1.930 MM
	4,2 x 13	8 PC	







Double Hinged door will need opening of 1441mm, 17mm from bolt holes on foundation frame.



(Single door shown, double door jamb installation will be identical)










(view from top)






OPTION:

Hinged door on a stem wall (door extension kit will be needed)








Single hinged door





OPTION: Double Hinged Door








Step 1: Insert large rectangular cartridge into side cutout of door and attach with 2 screws.


Step 2: Insert center square rod and attach handles - with 2 extra long screws and threaded caps.

Step 3: Tighten set screw in handle - note that square rod must be equidistant from each handle.






Step 4: Slide face plates onto door handles and snap in place.





**IMPORTANT:** Find Janssens Accessory installation video on our site here: <https://www.exaco.com/greenhouse-victorian.php>









Insert lock cartridge and secure with screw.




Attach latch catch plate to second door.



















\*This page only applies to double hinged doors.\*






HINGE  
ADJUSTMENT  
(Left to Right)












### HINGE ADJUSTMENT (Up)



### HINGE ADJUSTMENT (Front/Back)




# OPTION: 2 Slat Shelf (TAB2)




Note: Shelves do not meet the end of the bracket - allowing you to run these shelves end to end if desired.

# OPTION: 5 Slat Shelf (TAB5)



Note: Shelves do not meet the end of the bracket - allowing you to run these shelves end to end if desired.



# OPTION: Narrow Top Shelf



## STANDARD

Insert bolts into channel of PRO1456 and secure with nuts.

M6x12




## ALTERNATIVE

Drill screws into PRO 1456 to secure


SCREW

SH

# OPTION: SEEDTRAY (ST)




## STANDARD



Attach L bracket to bolts inserted into corner post and PRO1456


## ALTERNATIVE



## INSTALLING AN EXHAUST FAN IN A VICTORIAN GREENHOUSE


The exhaust fan in a Victorian Greenhouse should be installed up high in one of the gable ends of the greenhouse. If you happen to have polycarbonate walls on your Victorian, you may cut an opening in the polycarbonate to accommodate the fan. If you have glass glazing, we recommend replacing one of your upper angled gable panes with a piece of Lexan. We do offer a pre-cut panel for purchase that is cut with this unusual shape (with a square cut out) that will replace one of the gable panes of glass.

OPTION 1: Attach fan with bolts inserted into channel of PRO1456



Once your panel with the cutout for the fan is in place, mount the fan on the interior of the greenhouse using bolts in the channels of the aluminum extrusions. These bolts will fit through the holes on the exhaust fan. You may need to cut the corner off due to the diagonal support beam being in the way. Once the fan is mounted on two sides to the aluminum extrusions caulk around the area where the box of the shutters meets the glazing.

Option 2: Attach with self-tapping screws






Conversely, you can use self-tapping screws to hold the Exhaust Fan in place. Pre-drill holes in the exhaust fan metal to match up with the Pro1456 Gable piece. You may need to cut the corner off due to the diagonal support beam being in the way. Once the fan is mounted on two sides to the aluminum extrusions caulk around the area where the box of the shutters meets the glazing.



# OPTIONAL ACCESSORY: Louvre Window Fly Screen







(view from outside)



# OPTIONAL ACCESSORY: Roof Vent Fly Screen



(view from inside)





# OPTIONAL ACCESSORY: Sliding Screen Door

(view from inside)



## **OPTIONAL ACCESSORY: ROYAL ORANGERIE SHADECLOTH**

**Inserting the curlicue hooks into the curtain:** The curlicue hooks that insert into the curtain will go in every 6<sup>th</sup> loop in the white ribbon– look at the picture diagram to ensure you are inserting them in the correct direction so the curtain hangs well. Your curtains will have one looped ribbon running across the center (for the ridge) and 3 white looped ribbons on either side. You will use the center ribbon of the set of three and the ridge ribbon. **Please note: if you have forgotten to insert any items during assembly, you may “notch” the channel with a ½” drill bit in an inconspicuous place. We can send a touch up paint pen if you need one.**



### **Royal Orangerie (footprint of 12’10” D x 15’7” W)**

Has a shade cloth set SUN310 – T SET, which consists of the following pieces: SUN310-T (Center sections T1 & T2) and (3) SUN310-73. There are 3 sets of “scroll” supports which the curtains fit around. The misting system is best hung in the long direction from bolts/ hooks next to each “scroll” support.


Insert the following in this order:

- In main ridge profile:
  - 1 bolt (for L bracket that connects at gable end)
  - 9 Sliding Eye Hooks
  - Space for scroll support
  - 1 bolt for hook for misting system
  - 1 Twist lock (optional)
  - 20 Sliding Eye Hooks
  - 1 bolt for hook for misting system
  - 20 Sliding Eye Hooks
  - 1 Twist lock (optional)
  - 1 bolt for hook for misting system
  - Space for “scroll” support
  - 9 Sliding Eye Hooks
  - 1 bolt (for L bracket that connects at gable end)
- In short ridge profile (inserting from front of the greenhouse):
  - 1 Twist lock (optional)
  - 18 Sliding Eye Hooks
  - Space for “scroll” support
  - 9 Sliding Eye Hooks
- In rear gutter profile:
  - 9 Sliding Eye Hooks
  - Space for “scroll” support
  - 1 Twist lock (optional)
  - 40 Sliding Eye Hooks
  - 1 Twist lock (optional)
  - Space for “scroll” support
  - 9 Sliding Eye Hooks
- In each small gutter section:
  - 9 Sliding Eye Hooks


Schermdoek - Toile d' ombrage - Strahlenschutz - Sunscreen  
 Solskærm-Solskjerm-Telo ombregiante scorrevole - Skuggväv

TYPE	SUN236_73	SUN310_73	SUN236_300	SUN310_300
	24 pcs	24 pcs	93 pcs	93 pcs
	24 pcs	24 pcs	93 pcs	93 pcs

01




02



69

03
















SD1




Schermdoek - Toile d' ombrage - Strahlenschutz - Sunscreen  
 Solskærm-Solskjerm-Telo ombregiante scorrevole - Skuggväv

SUN236

SUN310



1	 T1		72 pcs	91 pcs
			72 pcs	91 pcs
2	 T2		52 pcs	66 pcs
			52 pcs	66 pcs
3	 73		24 pcs	24 pcs
			24 pcs	24 pcs
	 300		93 pcs	93 pcs
			93 pcs	93 pcs



SD2



## Customer Service or Assembly Questions?

Give us a call  
Toll free: 1-877-760-8500  
customerservice@exaco.com  
Exaco Trading  
www.EXACO.com

***Please watch our animated assembly  
video on our Exaco Trading Co  
YouTube Channel.  
Find the link at [www.exaco.com](http://www.exaco.com)***

**Janssens NV** Mechelsesteenweg 388, B-2500 Lier Belgium  
(T) +32 15 30 67 80 (W) [www.janssens-alusystems.be](http://www.janssens-alusystems.be) (E) [info@janssens-alusystems.be](mailto:info@janssens-alusystems.be)

**Janssens NV** Mechelsesteenweg 388, B-2500 Lier Belgium  
(T) +32 15 30 67 80 (W) [www.janssens-alusystems.be](http://www.janssens-alusystems.be) (E) [info@janssens-alusystems.be](mailto:info@janssens-alusystems.be)