



INSTRUCTIONS

LENGTH ADJUSTMENT

To adjust the length of your Scott Release with a Nylon Connector Strap (NCS), loosen both of the #4-40 socket head cap screws [1:A] which attach the lock-down clamp to the bracket sewn into the release strap using a 3/32" hex tool. Move the nylon connector strap to the desired length and retighten both screws.

TRAVEL ADJUSTMENT

To adjust the travel of your Scott Release, adjust the #4-40 set screw [1:B] in the body of the release. Adjust the screw in turn increments. Test the travel after each adjustment. TO INCREASE TRAVEL, turn the screw counter clockwise. TO DECREASE TRAVEL, turn the screw clockwise.

ADJUSTING FINGER EXTENSIONS

To adjust the sweep angle of the finger extension on your Scott Release, first loosen the 2 #4-40 socket head screws [2:A] that connect the finger extension to the trigger. Move to the desired position and re-tighten the screws.

CHANGING SEARS

To change sears in your Scott Release, first remove the #4-40 button head screw [2:B] from the side of the body using a 1/16" hex tool. Next, press the 3/32" dowel pin [2:C] out of the body using the 1/16" hex tool. The trigger will now come out of the body; be careful not to lose the spring [3:A] that is wedged between the body and trigger.

Remove the [2] #2-56 socket head screws [3:B] that attach the sear to the trigger using a 5/64" hex tool. Remove the sear and install the sear you choose to use. Reinstall the #2-56 socket head screws and reinstall the trigger into the body by placing the spring in the spring pocket on the trigger. Insert the trigger into the body and reinstall the 3/32" dowel pin [2:C] and #4-40 button head screw [2:B].

Note: make sure that you don't bind up the spring [3:A] when installing the trigger to the body.

WARRANTY SERVICES:

IMPORTANT: In the unlikely event that you require service on your product, please contact Customer Service at 1 (877) 503-5483. If necessary, our Customer Service Agents will provide you with a Return Merchandise Authorization (RMA) number and instructions on how to ship the product(s) back. It's important that you contact a Customer Service Agent before returning any item. Please be sure to include your RMA number when returning an item, so that we can identify the return as yours. Without the RMA, we will not be able to process your return, and your item will not be returned to you.

PATENT INFORMATION:

This product maybe covered by one or more patents. A complete list of Scott Archery patents can be found by visiting scottarchery.com/pages/patents

