

# American Tradition Flagpole Installation Instructions

## INSTALLATION INSTRUCTIONS

### Foundation:

Material required: Approximately 3-80 lb. bags of "Sakcrete" concrete mix.

**Step 1:** Dig hole 2' deep with the top and bottom diameters as shown.

**Step 2:** Set sleeve plumb in wet concrete. Temporarily insert bottom section of pole in sleeve and check straightness with level. Let concrete harden.

### Pole Assembly:

**Step 1:** Assemble shaft by sliding sections together as shown and described below.

**Step 2:** Mount ball on pole by screwing into top of truck, tightening with pliers or small pipe wrench.

**Step 3:** Run one end of the halyard through sheave (pulley) located in the truck (both ends to be rejoined at the cleat area).

**Step 4:** Attach snap hooks to halyard by inserting a loop of rope through the eye and pulling tight over snap (as shown in detail below).

Note: Leave enough slack in halyard to run down pole to cleat. Locate second snap hook approximately 4'-10" below first snap hook using same procedure.

**Step 5:** Insert assembled flagpole into ground sleeve.

**Step 6:** Caulk around flagpole at the top of sleeve at ground level.

### Maintenance:

To replace halyard, remove pole from sleeve. Do not attempt to climb pole or lean a ladder against it. It is not designed to support the weight of a person.

### Application Note:

This flagpole is not designed to withstand high winds while flying a flag. Always remove flag during high winds or inclement weather.

## SPECIFICATIONS

Cone Tapered High Strength Aluminum Flagpole  
Complete with all Fittings

