
DIGITAL KITCHEN SCALE





OPKS004

Instruction Manual

*Thank you for your choosing the digital kitchen scale from ONE Home Collection. For proper use of this product and ensuring its accuracy and service life, please read this manual carefully before using it.

Features

- High-precision sensor
- Weighing range of 5000g/1g 10000g/1g
- Division value 1q
- · LCD display with negative white digital
- Automatic zero point tracking
- Automatic turn-off
- Overload prompt
- Unit-conversion switch (g/kg/lb/oz/ml/milk ml)

Power Supply

This product adopts the environment-friendly design with ultra-low energy consumption. AAA battery is assembled for ex-factory. Please remove the isolated thin film of the battery after purchase and then you may use it. When the low voltage prompt appears, please replace the battery.

NOTE: Batteries are not included.

Operation



- 1. Put the loading plate (if any) on the scale body
- 2. Press ON button to turn on the scale
- 3. No loading or weighing can be done before the display resets to zero.

Unit Conversion



This product is designed with multiple units which can be converted mutually by pressing UNIT button.

Turn-off & Reset manually



Press ON/OFF button for a while to turn this item off. Please press Z/T button to reset manually.

Overload Prompt



When this prompt sign appears during weighing, it means the current load exceeds the maximum weight of this product. Please take off the object immediately to avoid the damage to the scale body

Low Voltage Prompt



When the battery is low, the left display will show (Lo) prompt. Then please replace the battery immediately.

Note

- 1. Don't put the product in water or clean it with corrosive chemicals.
- After any plastic part of the scale body is stained with oil, spicy ingredients, vinegar or other stimulating substances, please clean it immediately.
- 3. When using, place the scale on a hard flat surface and not on uneven surfaces like carpet

F© (€ RoHS 🌣

