1. Summary

GA-ML24TPoE+ is an Ethernet Switch with management function having 28ports of 10/100/1000BASE-T
and SFP extension slot, one of which is selectable.
Ports 1 to 24 support IEEE802.3at/af PoE power supply function.

2. Feature

(1) Ports 1 to 24 are 10/100/1000BASE-T ports corresponding to auto negotiation.
Also their speed and communication mode can be switched by configuration.
Ports 25 to 28 can be used as a 10/100/1000BASE-T port corresponding to auto negotiation or an SFP extension slot exclusively.

(2) Ports 1 to 24 can supply power conforming with IEEE802.3at and 802.3af. Supplying power up to 30 W per port,
and up to 370 W in total is possible.

(3) Equipped with PoE auto reboot function, and monitoring, and the switching of the power supply OFF/ON to ports is possible
via Ping, LLDP, and the 3 traffic volume methods.

(4) Equipped with silent fan control functions, which can be set to match the operating environment temperature and power supply,
and be used with any of the fan rpm, "High", "Low" and "Min".

(5) All twisted pair ports support straight/cross cable auto sensing function.
Simply connect devices with straight cables, whether it is a terminal or a network device.
(This function does not work if the port communication configuration is set at Fixed or Link Aggregation.
Ports 1 to 24 are set at MDI-X. (default))

(6) Telnet/SSH allows remote configuration changes and verifications of the Ethernet Switch.
Remotely configure the PoE settings for each port (Ports 1 to 24).

(7) The connection status for each port is detected by the power saving mode, and it can reduce the power consumption to required
levels when not linked up. (Factory default: disabled)

(8) Rapid Spanning Tree Protocol is supported, allowing to build a system with redundancy.

(9) The IEEE802.1p compatible QoS function is supported.

(10) Supports triple authentication that can simultaneously wait on IEEE802.1X authentication, MAC authentication, and
WEB authentication via one port, and an authentication network which is matched to the kinds of connection terminals can be
constructed.

(11) Equipped with step authentication functions, and can prevent illegal access of the terminals.

(12) Since it is equipped with authentication supplicant functions, a more robust security configuration can be configured in combination
with the upper switch's IEEE802.1X authentication function.

(13) Due to the loop detection/shutoff function, a port where loop has occurred can be automatically shut off to prevent loop failures.
When a port is shut off and recovered automatically, SNMP trap can be sent to notify the incident to the administrator.
Moreover, the port with a loop can be identified by loop notification on the LEDs on the main unit and referring the history
of loop on the setting screen.

(14) The PoE scheduler function enables scheduling of PoE power supply control.

(15) Supports ZEQUO assist Plus. Processes from introduction to maintenance can be performed easily.

3. Rated/Environmental Conditions

3-1. Power supply	AC100-240V, 50/60Hz, 8.0A (with a built-in power supply)
3-2. Power consumption	Normally, Max.472W (38.6W when not supplying power), Min.29.8W
3-3. Operating environment	Temperature: 0 - 50℃ Humidity:　　20 - 80%RH (no condensation) (Please note) Please note that if the aforementioned conditions are not satisfied, may be caused fire, electrical shock, malfunctions or misoperations, which are not covered by the warranty. ＊If it is used beyond the operating environmental temperatures, then the protective devices will start working and the Ethernet Switch power will be shut off. ＊The upper limit for the operating environmental temperatures may be altered by changing the settings for the silent fan control functions. For details, check "7-11. The Silent Fan Control Functions".
3-4. Storage environment	Temperature: -20 - 70℃ Humidity:　　10 - 90%RH (no condensation)
3-5. EMC compliance	CISPR 32 Class A EN 55032 Class A AS/NZS CISPR32 Class A VCCI Class A EN 61000-3-2, EN 61000-3-3 EN 55024 IEC 61000-4-2, IEC 61000-4-3, IEC 61000-4-4, IEC 61000-4-5, IEC 61000-4-6, IEC 61000-4-8, IEC 61000-4-11 ＊ Electrical surges (lightning-induced surges in wiring): 10 kV 　(Depending upon the twisted pair ports, and Panasonic's proprietary evaluations)
3-6. Safety compliance	IEC 62368-1 EN 62368-1
3-7. Environment compliance	RoHS compliant

4. Form

4-1. Form and materials/colors	Dimensions　　　　　:44mm(Height)×440mm(Width)×387mm(Depth) 　　　　　　　　　　(Excluding protruding sections) Case material　　　　:SECC Color　　　　　　　: Main unit: Green 03, Front face: Black 03, 　　　　　　　　　　Face plate label: Black 04
4-2. Mass(Weight)	5,800g

5. Hardware Specifications

5-1. Interface	

Twisted pair port 1-24　　　　　　　　:RJ45 connector (＊1)
　　Transmitting and receiving network system:

IEEE802.3	10BASE-T
IEEE802.3u	100BASE-TX
IEEE802.3ab	1000BASE-T

　　Energy Efficient Ethernet (＊2)　　:IEEE802.3az (LPI)
　　Transmission speed　　　　　　　　:10/100/1000Mbps, full/half duplex
　　Compatible cable　　　　　　　　　:Twisted pair cable
　　　　　　　　　　　　　　　　　　　 (At least equivalent to EIA/TIA568
　　　　　　　　　　　　　　　　　　　 category 5e)
　　Maximum transmission distance　　:100m
　　Auto-Negotiation　　　　　　　　　:Communication speed and full/half duplex
　　　　　　　　　　　　　　　　　　　 are automatically recognized.
　　　　　　　　　　　　　　　　　　　 The setting can be fixed to 10Mbps, 100Mbps
　　　　　　　　　　　　　　　　　　　 or 1000Mbps and full duplex or half duplex.
　　PoE power supply function　　　　 :IEEE802.3af/at
　　　　　　　　　　　　　　　　　　　 Up to 370 W of power can be supplied to
　　　　　　　　　　　　　　　　　　　 ports 1 to 24 in total.
　　　　　　　　　　　　　　　　　　　 (Maximum power supplied to
　　　　　　　　　　　　　　　　　　　 a single port: 30 W)
　　PoE power supply method　　　　　 :Alternative A
　　　　　　　　　　　　　　　　　　　 (Cable signal lines 1, 2, 3, and 6 are used.)

Twisted pair port 25-28　　　　　　　 :RJ45 connector
　　Transmitting and receiving network system:

IEEE802.3	10BASE-T
IEEE802.3u	100BASE-TX
IEEE802.3ab	1000BASE-T

　　Transmission speed　　　　　　　　:10/100/1000Mbps, full/half duplex
　　Compatible cable　　　　　　　　　:Twisted pair cable
　　　　　　　　　　　　　　　　　　　 (At least equivalent to EIA/TIA568
　　　　　　　　　　　　　　　　　　　 category 5e)
　　Maximum transmission distance　　:100m
　　Auto-Negotiation　　　　　　　　　:Communication speed and full/half duplex
　　　　　　　　　　　　　　　　　　　 are automatically recognized.
　　　　　　　　　　　　　　　　　　　 The setting can be fixed to 10Mbps, 100Mbps
　　　　　　　　　　　　　　　　　　　 or 1000Mbps and full duplex or half duplex.

　　＊1　Embedded power saving mode detects the connection status automatically
　　　　 and saves power consumption to minimum.
　　＊2　Energy Efficient Ethernet (EEE) conforming to IEEE802.3az (LPI).
　　　　 When there is no data transmission at link up, the energy-saving state
　　　　 automatically starts so that power consumption can be reduced on each port.

SFP extension slot 25-28
　　Transmitting and receiving network system:　IEEE802.3z 1000BASE-X
　　＊　Select either of RJ45 or SFP for use
　　SFF-8472 (DMI:Diagnostic Monitoring Interface)
　　＊　Optional Accessories　　　　:1000BASE-SX SFP Module(i) (PN54022-NZ)
　　　　　　　　　　　　　　　　　　　 1000BASE-LX SFP Module(i) (PN54024-NZ)

5. Hardware Specifications

5-2. Switching mode	Switching method	: Store and Forward
	Switching capacity	: 56.0Gbps
	Packet transfer capability	: Non-blocking
		Max. 1,488,000pps/port (1000Mbps)
		Max. 148,800pps/port (100Mbps)
		Max. 14,880pps/port (10Mbps)
	MAC Address table	: Max. 16K entry/unit
		Automatic learning can be enabled/disabled
		for each port. Fixed registration is enabled.
	Buffer memory	: 2.0M Bytes/unit
	Flow control	: half-duplex Back pressure
		full-duplex IEEE802.3x
	Aging timeout	: 10 to 1,000,000 sec. (Default: 300 sec.)
	Jumbo frame supported	: 9KB
	Transmittable frames	: EAP, BPDU
5-3. Terminal emulator connection	Console port	: RJ45 connector 1 port
	Transmission mode	: RS-232C (ITU-TS V.24)
	Emulation mode	: VT100
	Communication configuration	: 9,600bps, 8bit, None Parity control, Stop bit 1 bit

5. Hardware Specifications

5－4. LED display

(1) POWER (Power) LED
　　Green Light　: Power is ON
　　Off　　　　　: Power is OFF

(2) PoE LIM. (PoE limit) LED
　For silent fan control high-speed (High) ＊ For factory default, or low-speed (Low2)
　　Off　　　　　: Supplying power in the range from 0 to 355 W.
　　Green Light　: Supplying power in the range from 355 to 370 W.
　　Orange Blink : A single port's power supply is exceeding the upper limit, or
　　　　　　　　　the total power supply of the Ethernet Switch is exceeding 370 W.
　For silent fan control low-speed (Low1), or Min.-speed (Min.)
　　Off　　　　　: Supplying power in the range from 0 to 153 W.
　　Green Light　: Supplying power in the range from 153 to 168 W.
　　Orange Blink : A single port's power supply is exceeding the upper limit, or
　　　　　　　　　the total power supply of the Ethernet Switch is exceeding 168 W.

(3) TEMP (Temperature sensor) LED
　　Green Light　: The system is normally operating.
　　Orange Blink : The temperature exceeded the set threshold of the internal
　　　　　　　　　temperature sensor.
　　　　　　　　　Set threshold of the internal temperature sensor: 61℃
　　　　　　　　　(factory default)

(4) FAN (Fan sensor) LED
　　Green Light　: The system is normally operating.
　　Orange Blink : Fan failure

(5) STATUS/ECO (Status/ECO mode) LED
　　Green Light　: Operating in status mode.
　　Green Blink　: Operating in ECO mode.
　　　　　　　　　All port LEDs are turned off.
　　Orange Light　: Starting.
　　Orange Blink　: Malfunction (Contact the seller).

(6) GIGA (GIGA mode) LED
　　Green light　　: Operating in GIGA mode.

(7) Full (DUPLEX mode) LED
　　Green light　　: Operating in DUPLEX mode.

(8) LOOP HISTORY (Loop History mode) LED
　　Green Light　: Operating in loop History mode
　　Green Blink　: Loop is occurring,
　　　　　　　　　or occurred within 3 days.
　　Off　　　　　: No loop detection.

Refer to table 1 on page 7 for the display of each port.

Date issued	Oct. 31, 2019	Panasonic Life Solutions Networks Co., Ltd.
Date revised	Nov. 1, 2021	

5. Hardware Specifications

5-4. LED display	Following items can be displayed using the LED display change button:

Following items can be displayed using the LED display change button:
Display for the connection with a connected terminal (Status mode),
Display for the 1000 Mbps transmission rate (GIGA mode),
Display for the full-duplex or half-duplex transmission system (DUPLEX mode),
Display for ports with a loop history (Loop history mode), or
All port LED lamps to be turned OFF (ECO mode).

The mode at the start is called "Base mode".
There are two types of Base modes : Status mode (factory default setting) and ECO mode.
You can change the Base mode by holding down the LED display change button (for at least 3 sec.).
When the Base mode is changed normally, all STATUS/ECO , GIGA and FULL LED lamps light up at the same time. When you release the button, the Base mode is changed to the selected mode.
If the mode is changed to the GIGA mode, DUPLEX mode, or Loop History mode and the LED display switch button is not used for one minute or longer, the mode automatically returns to the Base mode (Status mode or ECO mode).
The Base mode is maintained even after the power is turned OFF.

LED display change button

Switch two types of Base modes and their LEDs by following:

When Base mode is Status mode (factory default setting)

- - - ▶ Press "LED DISPLAY CHANGE BUTTON" manually.
——▶ Automatic
— — ▶ Automatically returns to Base mode after 1 minute.

Switch Base mode (keep pressing "LED DISPLAY CHANGE BUTTON" for at least 3 seconds)

When Base mode is ECO mode

- - - ▶ Press "LED DISPLAY CHANGE BUTTON" manually.
——▶ Automatic
— — ▶ Automatically returns to Base mode after 1 minute.

LED lamps for each mode and LED lamps for ports 1 to 28 correspond to the following states. (Table 1)

Date issued	Oct. 31, 2019	Panasonic Life Solutions Networks Co., Ltd.
Date revised	Nov. 1, 2021	

5. Hardware Specifications

5-4. LED display			Table 1		
	Port LED	Display mode	Behavior	Description	
LED(Left) LED(Right)	Left	STATUS/ECO	Green Light Green Blink Orange Light Orange Blink Off	Link is established. Transmitting and receiving data. Shut off via the loop detection and shut off function/storm control or the BPDU guard. Sending and receiving just the control packet. No device connected or the ECO mode is set.	
		GIGA	Green Light Off	Link is established at 1000 Mbps. Link is established at 100 Mbps or 10 Mbps, or no device is connected.	
		FULL	Green Light Off	Link is established at full-duplex Link is established at half-duplex or no device is connected.	
		LOOP HISTORY	Green Light Off	Loop has been detected within 3 days. No loop detection history.	
	Right		Green Light Orange Blink Off	PoE are being supplied power. Single port overload. Or an overload of the Ethernet Switch overall, and the ports displayed cannot be supplied power. Power is not being supplied, or the PoE receiving equipment are not connected. or, it is set in the ECO mode.	

5-5. Cascade connections	Port 1-28 corresponding to the Auto MDI / MDI-X (Allowed change by the setting for the application) Ports 1-24 are set to "Disable" at factory default setting.
5-6. FAN	installed

6. Software Specifications

6-1. Configuration	Control parameters can be set by the following procedures: (1) Configuration from an asynchronous terminal connected to the console port. (2) Configuration from a remote terminal connected via TELNET and SSH. (3) Configuration from a remote terminal according to the Web screen.
6-2. Ethernet Switch Control	ZEQUO assist Plus can confirm the management/operation status of Ethernet Switch. Ethernet Switch can be controlled by the following procedures: (1) Control from an asynchronous terminal connected to the console port. (2) Control from a remote terminal using SSH/TELNET and TCP/IP network connection (3) Control using SNMP Manager The Ethernet Switch operation status can be checked using the following functions. (1) Internal temperature sensor function (2) Function to display the CPU usage and memory usage (3) SFP module status checking function (DDM: Digital Diagnostic Monitoring)
6-3. Rebooting	The system can be reset from the software in the following two modes: (1) Warm start. (2) Reset back to the factory default settings.
6-4. Supported Agent	Management protocol :SNMP v1/v2c /v3 (RFC 1157, RFC 1901, RFC 3411, RFC 3412, RFC 3413, RFC 3414, RFC 3415, RFC 3416) TELNET (RFC 854, RFC 855) SSH v2 (RFC 4252, RFC 4253, RFC 4254, RFC 4716, RFC4419) Data transfer protocol :TFTP (RFC 783, RFC 1350)

6-5. Supported MIB	RFC1213-MIB(MIBⅡ) (RFC 1213) (※1)
	BRIDGE-MIB (RFC 4188) (※2)
	SNMPv2-MIB (RFC 1907)
	RMON-MIB (RFC 2819) only etherStatsTable
	SNMP-FRAMEWORK-MIB (RFC 2571)
	SNMP-MPD-MIB (RFC 2572)
	SNMP-NOTIFICATION-MIB (RFC 2573N)
	SNMP-TARGET-MIB (RFC 2573T)
	SNMP-USER-BASED-SM-MIB (RFC 2574)
	SNMP-VIEW-BASED-ACM-MIB (RFC 2575)
	SNMP-COMMUNITY-MIB (RFC 2576)
	IP-MIB (RFC 4293) (※3)
	IF-MIB (RFC 2863) excluding IfMIB
	IEEE8021-PAE-MIB excluding dot1xPaeSupplicant
	
	*1 Excluding following items
	    At , ipRouteTable, icmp, egp
	*2 Excluding following items
	    dot1dStp, dot1dSr, dot1dStatic
	*3 Excluding following items
	    ipDefaultRouterTable, ipv6RouterAdvertTable

6-6. System log	Maximum number to be kept: 10,000 Transfers system logs to the Syslog server (IPv4/IPv6)

6. Software Specifications

6-7. Loop detection	Turns on the port LED with an orange light when a loop occurs in the corresponding port. At this time, the relevant port automatically shuts down (default setting: 60 sec.) to prevent loop from occurring. While loop is occurring, or if loop has occurred within 3 days, LOOP HISTORY LED blinks to notify this. · Loop detection setting 　　　Enabled (factory default setting) 　　　Enabled/disabled can be switched by configuring a setting using the console. 　　　The setting is kept even when the power is turned OFF. · Loop detection port 　　　Enabled: Ports 1 to 24 (factory default setting) 　　　Disabled: Ports 25 to 28(factory default setting) · Loop shutoff time 　　　60 to 86,400 sec. (Factory default setting: 60 sec.) 　　　The Set Time Port LED lights up orange and the port shuts off. · Loop history retention time 　　　3 days 　　　The LOOP HISTORY LED blink for three days. 　　　The Port LED also remains lit for three days after the loop is eliminated. Loop shutoff mode has the following 2 types of modes. ·Block mode (factory default setting) 　　　When loops are detected, the port statuses are automatically blocked, and just the specified packets which include the loop detection packets will be transmitted and received. ·Shut-down mode 　　　When loops are being detected, the ports will be automatically linked down, and none of the packets will be transmitted and received. 　　　＊Just the loop detection packets from 30 seconds before the set restoration time will automatically be transmitted and received.
6-8. Others	Syslog Client (Transfers system logs to the Syslog server.) TFTP Client (Upgrades the software and saves/loads configuration information.) SNTP Client TELNET Client DHCP Client LLDP LLDP-MED DNS Resolver DHCP Snooping DDM Statistics sFlow Ethernet OAM CFM UDLD (Scheduled to be supported)

7. Layer 2 Switching Functions

7-1. Spanning Tree	IEEE 802.1D Spanning Tree Protocol, Rapid Spanning Tree Protocol IEEE 802.1Q Multiple Spanning Tree Protocol BPDU guard
7-2. VLAN	IEEE802.1Q Private VLAN MAC-based VLAN Subnet based VLAN Protocol-based VLAN Number of VLAN registrations: 4,094 (including default) Asymmetric VLAN Voice VLAN (LLDP-MED) Dynamic VLAN Guest VLAN Internet mansion function
7-3. Link aggregation	IEEE802.3ad Link Aggregation function (LACP/Manual) Up to 14 groups can be created (up to 8 ports per group).
7-4. SPAN,RSPAN	Subject port traffic can be copied and transmitted to designated ports (multiple subject ports can be designated) Remote switching packets can be monitored via RSPAN.
7-5. Port grouping	Members of the port group can communicate only among member ports in the same group. (Number of group registrations: 256)

7-6. QoS	IEEE802.1p 8 levels of Priority Queue supported
	Scheduling Method:
	  Strict Priority Queuing (SPQ:Strict priority queuing)
	  Weighted Round Robin (WRR:Weighted round robin scheduling)
	  Weighted Deficit Round Robin (WDRR: Weighted Deficit Round Robin scheduling)

7-7. Authentication Function	IEEE802.1X Port-based authentication Mac-based authentication using IEEE 802.1X Dynamic VLAN function using IEEE 802.1X Guest VLAN using IEEE 802.1X (EAP-MD5/TLS/PEAP Authentication method) IEEE802.1X supplicant Force Authorized MAC Address Configuration EAP Packet Forwarding function (Enable/disable EAP transmission can be specified for each port.) MAC authentication WEB authentication Triple authentication (*1) Step authentication (*2) *1 IEEE802.1X MAC-based/MAC/WEB authentication can be received simultaneously *2 2 authentications can be combined in phases MAC-WEB authentication MAC-802.1X authentication 802.1X-WEB authentication
7-8. PoE power supply function	IEEE802.3af/at power supply function. Up to 370 W of power can be supplied to ports 1 to 24 in total. (Maximum power supplied to a single port: 30 W) Supply method :Alternative A(Cable signal lines 1, 2, 3, and 6 are used.)
7-9. PoE scheduler function	PoE power supply control can be scheduled. The setting can be configured by the month, week, day or specific date. The maximum number of schedules to be registered: 32
7-10. PoE auto reboot function	Monitoring, and the switching of the power supply OFF/ON to ports is possible via Ping, LLDP, and the 3 traffic volume methods.

7. Layer 2 Switching Functions

7-11. Silent fan control	The fan rpm can be set in accordance with the usage environments. If the fan rpm are set, the available power supply will be automatically restricted. If the fan rpm (Fan Speed) are set to Low1,or Min., the device's overall available power supply (Power Budget) will be automatically restricted, and it can be used with the fan noise reduced.

Fan Speed		Operating environment temperature	Available PoE power	Comments
High		0-50℃	370W	Factory default
Low	(Low1)		168W	
	(Low2)	0-40℃	370W	
Min.			168W	

7-12. Ring redundant protocol	Redundancy is enabled by ring configuration. (Up to 8 group can be registered.)
7-13. Multicast	IGMP snooping(IGMPv1/v2/v3) function (can be up to 1,024 groups of registration) IGMP Querier function MLD snooping(MLDv2) function (can be up to 1,024 groups of registration) Multicast filtering function
7-14. Access control	Access control can be controlled by the following parameters: (1) IP address, IPv6 address (Source or Destination) (2) MAC address (Source or Destination) (3) TCP/UDP port number (Source or Destination) (4) VLAN ID (5) IEEE 802.1p Priority (6) DSCP,DSDP6 (7) Protocol (8) ICMP type (9) TCP SYN Flag
7-15. Time setting	SNTP settings, time manual setting
7-16. Storm control function	Unknown unicast, Broadcast, Multicast Control of the storm is possible

Date issued	Oct. 31, 2019	Panasonic Life Solutions Networks Co., Ltd.
Date revised	Nov. 1, 2021	

8. WEB Browser-based Control (WEB control screen)

8-1. System Requirements	
8-1-1. WEB Browser	Microsoft Internet Explorer 11

8-2. Configuration Function	
8-2-1. Switch Configuration	Administration · Authentication IP Address · IGMP Querier SNMP · IGMP Snooping SNTP · Spanning Tree Port · MSTP (Multiple Spanning Tree) System Security · Loop Detection ID/Password Change · DDM Forwarding Database(FDB) · Ring protocol Time(SNTP) · PoE LLDP · Statistics VLAN · System Log Link Aggregation · Syslog Transmission QoS Storm Control Access control ARP entry manual registration Port grouping Port monitoring Port counter
8-3. Monitoring Configuration	Firmware upgrade, Reboot, Save current, Configuration file transfer, Ping execution

9. Connector Pin Arrangement

9-1. Port 1 – 28

Status	Pin No.	1	2	3	6	4	5	7	8
MDI-X	Signal	BI_DB+	BI_DB−	BI_DA+	BI_DA−	BI_DD+	BI_DD−	BI_DC+	BI_DC−
MDI	Signal	BI_DA+	BI_DA−	BI_DB+	BI_DB−	BI_DC+	BI_DC−	BI_DD+	BI_DD−

Pin No. → 1 2 3 4 5 6 7 8

9-2. Console port

Pin No.	Signal	Pin No.	Signal
1	NC	5	GND
2	NC	6	RXD
3	TXD	7	NC
4	GND	8	NC

Pin No. → 1 2 3 4 5 6 7 8

Date issued	Oct. 31, 2019	Panasonic Life Solutions Networks Co., Ltd.
Date revised	Nov. 1, 2021	

10. Installation Procedures and Accessories

10-1. Installation Procedures	(1) Mounting to rack	
10-2. Accessories	(1) Installation Guide	:1
	(2) Rubber foot	:4
	(3) Mounting bracket (for 19-inch rack)	:2
	(4) Screw (for 19-inch rack)	:4
	(5) Screw (for fixing the mount brackets to the Ethernet Switch)	:8
	(6) Power cord (AS/NZS3112)(*)	:1
	* The attached power cord is dedicated for AC 100 - 240 V use.	

11. Optional Accessories

11-1. 1000BASE-SX SFP Module(i) (Model No.:PN54022-NZ)	Fiber optic port connector type :LC connector (Duplex) Standards :IEEE802.3z 1000BASE-SX Transmission speed :1000Mbps, full duplex Compatible cable :Fiber cable 50/125 μ m Multi Mode Fiber 62.5/125 μ m Multi Mode Fiber Maximum transmission distance :550 m at 50/125 μ m 220 m at 62.5/125 μ m Operating Temperature :0 - 60℃
11-2. 1000BASE-LX SFP Module(i) (Model No.:PN54024-NZ)	Fiber optic port connector type :LC connector (Duplex) Standards :IEEE802.3z 1000BASE-LX Transmission speed : 1000Mbps, full duplex Compatible cable :Fiber cable 10/125 μ m Single Mode Fiber 50/125 μ m Multi Mode Fiber 62.5/125 μ m Multi Mode Fiber Maximum transmission distance :10 km when Single Mode Fiber is used 550 m when Multi Mode Fiber is used Operating Temperature :0 - 60℃

12. Prohibitions when Using the Product to Guarantee Safety

Denotes that "Death or serious injuries may be caused".
The manufacturer assumes no responsibility for any problems occurring when the following conditions are not satisfied.
Observe the following items when using the product.

(1) Do not use power supply other than AC 100 − 240 V.
     Deviation could lead to fire, electric shock, and/or equipment failure.

(2) Do not handle this Ethernet Switch and connection cables during a thunderstorm.
     Deviation could lead to electric shock.

(3) Do not disassemble and/or modify this Ethernet Switch.
     Deviation could lead to fire, electric shock, and/or equipment failure.

(4) Do not damage the power cord. Do not bend too tightly, stretch, twist, bundle with other cord, pinch, put under a heavy object and/or heat it.
     Damaged power cord could lead to fire, short, and/or electric shock.

(5) Do not unplug nor plug in the power plug with wet hands.
     Deviation could lead to electric shock, and/or equipment failure.

(6) Do not insert or drop foreign objects, such as metal or combustible things into Ethernet Switches through the openings, twisted pair port, console port and SFP extension slot.
     Deviation could lead to fire, electric shock, and/or equipment failure.

(7) Do not store or use the Ethernet Switch in places where it might get splashed with liquids such as water, in places with high humidity, or conductive dust, or in places where there are corrosive and combustible gases.
     Deviation could lead to fire, electric shock, and/or equipment failure.

(8) Do not store or use the Ethernet Switch in places where it will be exposed to direct sunlight or high temperature.
     The temperature inside will rise, which may cause fire.

(9) Do not store or use the Ethernet Switch in places where there are lots of vibrations and impacts, or in unstable areas.
     It might fall, which may cause injuries and/or equipment failure.

(10) Do not put the Ethernet Switch into fire.
     Deviation could lead to explosion and/or fire.

(11) Do not use the Ethernet Switch in dusty environments such as on floors, underneath floors, the backside of ceilings, or wiring panels.
     Do not use the Ethernet Switch in very dusty areas such as on floors, underneath floors, the backside of ceilings, or wiring panels Deviation could lead to fire, electric shock, and/or equipment failure. It is recommended that the Ethernet Switch be operated in environments such as the inside of racks where it is difficult for dust to be generated.

13. Cautions when Using the Product to Guarantee Safety

Denotes that "Minor injuries may be caused, or property damage might occur".
The manufacturer assumes no responsibility for any problems occurring when the following conditions are not satisfied.
Observe the following items when using the product.

(1) Use the bundled power cord (AC 100 - 240 V specifications).
Deviation could lead to electric shock, malfunction, and/or equipment failure.

(2) Unplug the power cord in case of equipment failure.
Deviation, such as keep connecting for a long time, could lead to fire.

(3) Be sure to connect the ground cable.
Otherwise this might cause electrical shocks, misoperations, and malfunctions.
Connect the Ethernet Switch via the supplied power cord to the outlet, which is connected to the ground.
If the outlet is not connected to the ground, connect the ground cable to the ground terminal screw.

(4) Connect the power cord firmly to the power port.
Otherwise this might cause electrical shocks and malfunctions.

(5) Unplug the power cord if the STATUS/ECO LED (Status/ECO mode) or FAN LED (Fan sensor)
blinks in orange (system fault).
Deviation, such as keep connecting for a long time, could lead to fire.

(6) Handle the Ethernet Switch carefully to prevent fingers and hands from being damaged by twisted pair port, SFP extension slot, console port, or power cord hook block.

(7) Check whether the optical fiber cable connectors are not contaminated with dust, etc.
Dust might cause the optical signal to not be transmitted normally, and cause misoperations and malfunctions. If they are contaminated, make sure to clean them off, then connect them to the optical fiber ports.

(8) This Ethernet Switch is to be periodically serviced in order to maintain its performance.
Please assign a product administrator, and have him/her be sure to implement periodic maintenance. When doing maintenance, check the inspection chart that is posted on our website which has the requisite items listed on it.

(9) When using this Ethernet Switch to design systems, use it after applying appropriate measures such as setting up redundant configurations.
Communications failures might be generated due to causes such as malfunctions or misoperations while the Ethernet Switch is being used.

(10) When using this Ethernet Switch for applications which require extremely high reliability, be careful to expend all possible means to ensure safety and reliability.
This Ethernet Switch is not designed nor manufactured with the intention that it be used for applications (in use with railways, aviation, and medical care, etc. where the influence rate due to communications failures is extremely high in regard to systems that directly affect systems and human lives) which require extremely high reliability.

(11) Be aware of glitches which are caused in the usage environments such as age-related degradation, etc.
This may vary depending upon conditions such as utilization rates and usage environments, but performance might decrease due to the age-related degradation, etc. of components. It is recommended that this Ethernet Switch be replaced about five years after it was installed.

(12) Be careful in regards to environmental restrictions whereby the Ethernet Switch can be used.
Please isolate the business power lines and communications lines. Isolate distribution lines and other distribution lines, and low current power lines, optical fiber cables, metallic water conduits, and gas conduits, etc.
Noise may be generated in the communications lines which might cause communications glitches.

(13) Do not connect any other devices except for 10BASE-T/100BASE-TX/1000BASE-T devices to the twisted pair ports.
Deviation could lead to equipment failure.

Date issued	Oct. 31, 2019	Panasonic Life Solutions Networks Co., Ltd.
Date revised	Nov. 1, 2021	

(14) Do not insert any other modules into the SFP expansion slots other than our optional SFP modules (PN54022-NZ/PN54024-NZ). Deviation could lead to equipment failure.
Check our website for the latest information on supported SFP modules.

(15) Do not connect the console ports with any other device except for Serial communication terminal. Deviation could lead to equipment failure.

(16) To connect a power receiving equipment supporting IEEE802.3at to this Ethernet Switch, use a cable rated Cat5e or higher. Using other cables may result in heat generation, ignition, and/or equipment failure.

(17) It is strongly recommended that a lightning arrester(SPD) be installed on the twisted pair port side and the power supply side of this Ethernet Switch.
Malfunctions might be caused due to overcurrent and overvoltage from the effects of lightning strikes.

14. Basic Instructions for the Use of This Product

(1) For inspection and/or repair, consult the retailer.

(2) Use commercial power supply from a wall socket closeby, which is close and easily accessible to this Ethernet Switch.

(3) Unplug the power cord when installing or moving this Ethernet Switch.

(4) Unplug the power cord when cleaning this Ethernet Switch.

(5) Use this Ethernet Switch within the specifications. Deviation could lead to malfunction.

(6) Do not touch the twisted pair cable modular metal terminals which are connected to RJ45 connectors (twisted pair ports) or the connectors, nor place them near electrically-charged objects. Static electricity could lead to equipment failure.

(7) Do not put the modular plug of the connected twisted pair cable on objects that can carry static charge, such as carpet. Do not place it in the proximity. Static electricity could lead to equipment failure.

(8) Do not put a strong shock, including dropping, to this Ethernet Switch. Deviation could lead to equipment failure.

(9) Before connecting a console cable to the console port, discharge static electricity, for example by touching metal appliance (do not discharge by touching this Ethernet Switch).

(10) Please use this Ethernet Switch in place where ambient temperature is from 0 to 50℃ and, do not store and/or use this Ethernet Switch in the environment with the characteristics listed below. (Store and/or use this Ethernet Switch in the environment in accordance with the specification.)
  - High humidity. Possible spilled liquid (water).
  - Dusty. Possible static charge (such as carpet).
  - Under direct sunlight.
  - Possible condensation. High/low temperature exceeding the specifications environment.
  - Strong vibration and/or strong shock.
  Failure to satisfy the conditions above may result in a fire, electric shock, equipment failure, and/or malfunction.
  Such events are not covered by the warranty.
  (＊) If it is used beyond the operating environmental temperatures, then the protective devices will start working and the Ethernet Switch power will be shut off.

(11) Do not block the ventilator of the Ethernet Switch. Blocked ventilator induces the heat accumulation inside, causing equipment failure and/or malfunction.

(12) Operation is not guaranteed if a module other than the optional SFP extension modules (PN54022-NZ/PN54024-NZ) is inserted into the SFP extension slot. For the latest information about compatible SFP extension modules, check our website.

(13) When using two Ethernet Switches, do not stack them. When you place them side by side, allow for a space of 20 mm or more between them. This space is not necessary if you use supplied connection brackets.

(14) When mounting Ethernet Switches to rack, leave a minimum of 20mm space between them.

Date issued	Oct. 31, 2019	Panasonic Life Solutions Networks Co., Ltd.
Date revised	Nov. 1, 2021	