

# INSTRUCTION MANUAL

# BLITZ

SUPERBLEND BLENDER & GRINDER



**PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USE**

**Due to sharp parts and potential hazards, this appliance should not be used by children under 16 years old unless supervised by an adult.**

**Please keep the appliance and mains cable out of the reach of children. This is not a toy!**


**If used by persons with reduced physical, sensory or mental capabilities, instruction and supervision must be given to understand the use of the appliance and the hazards involved.**

**Always disconnect the appliance from the power socket if it is left unattended and before assembling, disassembling or cleaning.**



**If the mains cable is damaged, it must be replaced by qualified persons in order to avoid any hazards.**

## FEATURES

- 1 Lid cap
- 2 Blending jug lid
- 3 Anti-drip spout
- 4 Grinding mill cover
- 5 Grinding mill base
- 6 Blending jug
- 7 Connector
- 8 Drive shaft
- 9 Motor unit
- 10 Rotary switch
- 11 Assembled grinding mill



**SHARP BLADES!**



## IMPORTANT SAFEGUARDS

**Do not use the appliance in a bathroom, near water, or outdoors. Do not operate the appliance with wet hands or bare feet.**

**Do not immerse any of the parts (appliance, mains cable, plug) in water or other liquids during use to protect from fire, electric shock and personal injury.**

**Do not use the appliance if it is damaged or malfunctioning.**

**Do not leave the appliance unattended whilst in use. Use and store it out of reach of children.**

**Keep hands and utensils out of the blending jug 6 while blending to reduce the risk of severe injury.**

- This appliance is intended for household use only.
  - Ensure that the appliance is always placed on a firm and flat surface, away from any edges of the worktop. Do not place the appliance onto a metal tray or metal surface whilst in use. Do not place the appliance on, or near, a hot gas or electric burner or in a heated oven.
  - Keep the appliance and mains cable away from the edges of worktops and out of reach of children. Route the mains cable so it does not overhang, and cannot be tripped over or caught.
  - Do not let the mains cable run across an open space, such as between a low power socket and a table, or across any hot area, such as a cooker. Heat may damage the mains cable.
  - The connections on both sides of the mains cable (the appliance and the power socket) should never be strained. If the mains cable is damaged it must be replaced by a qualified person or service to avoid any hazards.
  - This appliance must not be operated by an external timer or a remote control system.
- The connector 7 and drive shaft 8 should always be kept dry. Before washing and drying, disconnect the power supply; ensure that the connector 7 and drive shaft 8 are completely dry before you reconnect the appliance to power supply.
  - Ensure the blending jug lid 2 or grinding mill 11 are securely in place and securely locked onto the motor unit 9 before operating this appliance.
  - Do not switch the appliance on when it is empty. Ensure there is the at least a minimum amount of liquid or solid ingredients in the blending jug 6 or grinding mill 11.
  - Always close the blending jug lid 2 and the anti-drip spout 3, or have the grinding mill 11 securely placed and locked onto the motor unit 9 before you switch the appliance on. Do not open the blending jug lid 2 or attempt to open the grinding mill 11 whilst the appliance is running.
  - A scraper may be used but only when the appliance is not running.
  - Always switch the appliance off and unplug the mains cable from the power socket before changing attachments or approaching parts that move while in use. Unplug the appliance when not in use.
  - Ensure that the appliance has come to a complete stop before cleaning and storing away. Keep the attachments, motor unit 9, mains cable, and plug away from sources of heat. Store in a dry place.
  - Use the blending jug 6 or grinding mill 11 only with the motor unit 9 supplied (and vice versa) and do not tamper with the connector 7 in any way.
  - Read all operating instructions before using the appliance.

**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE**

## BEFORE FIRST USE


**All parts that come in touch with food are to be thoroughly cleaned before being used for the first time (see section on Cleaning).**

Ensure that the rotary switch 10 is in the position 0. Take out the required length of the mains cable and plug it into the power socket.

## ASSEMBLY OF THE BLENDING JUG


### The blades are extremely sharp. Handle carefully!

- Mount the blending jug **6** on the motor unit **9**, aligning the connector **7** and drive shaft **8** - **IMAGE A**. Turn the blending jug **6** counterclockwise until it locks - **IMAGE B**.
- Place the blending jug lid **2** on top and push down firmly - **IMAGE C**. To remove the lid cap **1** turn it counter-clockwise. To insert the lid cap **1**, turn it clockwise until it locks - **IMAGE D**. Ensure that the anti-drip spout **3** is firmly closed before switching the appliance on.
- Once finished, ensure the appliance is switched off and unplugged. Turn the blending jug **6** clockwise to remove it from the motor unit **9**.



## ASSEMBLY OF THE GRINDING MILL

- Turn the grinding mill cover **4** upside down.
- Insert the grinding mill base **5** and turn it clockwise until it locks. **IMAGE E**.
- Attach the grinding mill **11** onto the motor unit **9** - **IMAGE F**. Turn it counter-clockwise until it clicks to ensure it is locked. **IMAGE G**



## OPERATING INSTRUCTIONS

Ensure that the rotary switch **10** is turned to **0** and unplugged from the power socket.

- **BLENDING JUG:** Attach the blending jug **6** without the blending jug lid **2** and lid cap **1** onto the motor unit **9**. Put the ingredients into the blending jug **6** and place the blending jug lid **2** on top. Remove the lid cap **1** to pour the liquids through the opening during the blending process. For the best results do not fill the blending jug **6** above the 1000ml mark, especially if using liquid ingredients.
- **GRINDING MILL:** Fill the grinding mill cover **4** half full and attach the grinding mill base **5**. Mount the grinding mill **11** onto the motor unit **9** and ensure it is securely locked. Turn the rotary switch **10** to the desired speed to switch the appliance on.

## SPEED SETTINGS

- 1 LOW SPEED - for light blending of liquid ingredients
  - 2 HIGH SPEED - for heavy blending with solid ingredients and thicker liquids.
- PULSE** SHORT BURSTS OF VERY HIGH SPEED - for rough blending of solid ingredients and thicker liquids, ice crushing, grinding and short, powerful pulse movements. The dial does not permanently engage in the **PULSE** setting; you must hold the dial in position or turn repeatedly to the **PULSE** setting.

After using the blender or the grinding mill **11**, always turn the switch back to the **0** setting and unplug the appliance from the power socket.

## USEFUL TIPS

- To achieve the best results when pureeing solid ingredients, place small portions into the blending jug **6** gradually. Do not overload.
- When processing solid ingredients, cut them into small pieces (2-3cm) first.
- When blending solid ingredients, start off with a small amount of liquid. Gradually add more of the liquid through the opening in the blending jug lid **2**.
- If blending warm liquids or ingredients, always ensure that they are cooled down before blending. Do not fill the blending jug **6** over 1000ml mark.
- Always stabilise the blending jug **6** or grinding mill **11** by placing your hand on top when operating the appliance.
- For stirring solids or very thick liquid ingredients, we recommend that you use the blender in **PULSE** mode to prevent the blades from becoming stuck during use.

## CLEANING

### Never immerse the motor unit **9** in water.

Wipe the motor unit **9** clean with a damp cloth and dry immediately with a soft cloth to avoid scratches and water marks on the surface.

### LIGHT CLEANING

- **BLENDING JUG:** Empty the blending jug **6** and fill it half way with tepid water and a mild detergent. Place the blending jug **6** on the motor unit **9** and turn the rotary switch **10** several times to the **PULSE** setting, holding for a few seconds each time. Empty the blending jug **6** and rinse until clean, then dry.
- **GRINDING MILL:** To clean the grinding mill **11**, wipe the grinding mill base **5** with a damp cloth or sponge, using tepid water with some washing up liquid, if necessary. Remove any stuck-on food with a small dish washing brush. Dry immediately with a soft cloth. Wash the grinding mill cover **4** with warm soapy water and dry thoroughly.

### THOROUGH CLEANING

#### Be careful when handling the blade inside the jug. The blades are very sharp.

- **BLENDING JUG:** Ensure that the blending jug **6** or grinding mill **11** are completely empty before cleaning. Use a small dish washing brush to remove the stuck food around the blades.
- All parts **except the motor unit 9** can be washed by hand or in a dishwasher (top rack). Do not use harsh scourers and aggressive or abrasive detergents.

## SPECIFICATIONS

Rated Voltage:	220-240V~
Frequency:	50/60Hz
Rated Power:	600W
Blending jug capacity:	1.5L
Grinding mill capacity:	100g

## ELECTRICAL

### **The product must not be used without the fuse cover fitted.**

Should the power cable or the power plug become damaged, arrange for these to be replaced by Customer Service or a qualified person before continuing to use the appliance. The appliance is fitted with a 5A fuse (BS1362) in a 5A plug (BS1363).

## ENVIRONMENTAL

To reduce environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with the symbol below must not be disposed of with unsorted municipal waste. Please repair, reuse or recycle appropriately.



## SERVICE

The product is not user-serviceable. If it is not working, read the instructions, check the plug fuse and main fuse/circuit breaker. If it is still not working, consult your retailer.

If that does not solve the problem ring Customer Service – they may be able to offer technical advice. Please have the Model Number to hand, as they will not be able to help you without it.

If you are advised to return the product to us, pack it carefully, include a note with your name, address, day phone number, and description of the problem.

If under a guarantee, say where and when it was purchased and include a valid VAT receipt. Send it to SQ Professional Ltd.

## GUARANTEE

The guarantee for this product is covered by SQ Professional Limited. Any faults with this product arising through a manufacturer defect will be covered for 1 year from the date of purchase, subject to a valid VAT receipt being presented. This does not include faults or damage caused by misuse of general wear and tear. SQ Professional Ltd will not be held liable for general wear and tear, or eventual damages to persons, animals or objects caused by incorrect installation or deriving from improper, erroneous or unreasonable use.

Please contact customer services on 01992 716 070 or send an e-mail to [info@sqprofessional.com](mailto:info@sqprofessional.com), Monday to Friday from 09:30 - 17:30.

This does not affect your statutory rights.





SCAN THE QR CODE TO EXPLORE  
OUR FULL PRODUCT RANGE.

Voltage Business Centre, Units 1 - 3  
6 Mollison Avenue, Enfield, EN3 7XQ  
T: 01992 716 070 | F: 01992 700 538

E: [info@sqprofessional.com](mailto:info@sqprofessional.com)

**[WWW.SQPROFESSIONAL.COM](http://WWW.SQPROFESSIONAL.COM)**