## EARNSHAW

London

INSTRUCTION MANUAL



Vol.1.35 EN

゚ヸ゙ヸヸヸヸヸ゙゙゙ヿ゙゚゚゙゚゚

# EARNSHAW

London

Congratulations on your purchase of this finely crafted Earnshaw Timepiece.

You are now the owner of a timepiece that draws its roots from the renowned English horologist, clock and watch maker Thomas Earnshaw 1749 - 1829


## 一十十十十十十

# MULTI-FUNCTION WATCH

For more details on operating this timepiece please refer to the enclosed booklet or visit:

IM.THOMAS-EARNSHAW.COM

#### A) DISPLAY




## B) HOW TO SET THE TIME

- Pull the crown to position
   [2]-(2nd click).
   Turn the crown to set the correct
- time.
  3. Push the crown back to position [0].

## C) HOW TO SET THE DATE


- 1. Pull the crown to position [1]-(1st click).
- 2. Turn the crown clockwise to set the correct date.3. Push the crown back to position [0].



\* If the date is set between the hours of around 9:00 P.M. and 2:00 A.M., the date may not change on the following day.

### D) DUAL TIME SETTING

- Pull the crown to position
   [1]-(1st click).
- 2. Turn the crown anti-clockwise to set the Dual Time. (The dual time hand at 6 o'clock position.)
- 3. Push the crown back to position [0] after setting the time.



#### WATER RESISTANCE

The water resistance indicated on your timepiece serves only as a guide. Actual water resistance may vary depending on a number of important factors including temperature, water salinity, and actual use under water.

The water resistance of your timepiece may eventually be compromised over time with general wear and tear and the use of your watch under adverse conditions.

Always remember to employ the screw down crown (if available) to maintain the water resistance of your timepiece. Warranty may be voided if the screw down crown has not been properly employed.

Note that you should **NEVER** wear your watch in a jacuzzi, hot shower or steam room where steam may enter the case despite the watertight seals used to protect your watch.

The steam may cause condensation inside your watch, which may affect and damage the inner workings of your watch – which would also not be covered by the warranty.