


TRAMPOLINE ENCLOSURE

USER'S MANUAL



THIS PRODUCT PICTURE IS FOR REFERENCE ONLY.
NO.OF LEGS VARIES FROM DIFFERENT SIZE OF TRAMPOLINE

WARNING

**Read and follow this instruction manual, prior to
assemble and use of this equipment.**

WARNING SUIT FOR TRAMPOLINE ENCLOSURE



NO MORE THAN ONE PERSON AT A TIME ON THE TRAMPOLINE! MULTIPLE JUMPERS INCREASE THE RISK OF INJURY SUCH AS BROKEN HEAD, NECK, LEG, OR BACK



PARALYSIS OR DEATH CAN RESULT IF YOU LAND ON YOUR HEAD OR NECK! DO NOT PERFORM SOMERSAULTS (FLIPS) AS THIS WILL INCREASE YOUR CHANCES OF LANDING ON YOUR HEAD OR NECK!

NOTICE TO SUPERVISOR

- ✧ Supervisor is to strictly enforce the safety rules and be familiar with all the information provided in the owner's manual prior to allowing any users on the trampoline, and use the enclosure and trampoline.
- ✧ No trampoline users shall use the trampoline without someone watching them, regardless of the skill or age of the trampoline user. Secure the trampoline against any unauthorized use. Do not allow anyone to use the trampoline unsupervised.
- ✧ Keep objects away from the jumper and the trampoline that may interfere with the jumper or could be potentially hazardous.
- ✧ The trampoline enclosure system is not for use by children under the age of 6 or any one weighing more than 330lb (150kgs).
- ✧ Do not use the trampoline when the trampoline mat is wet or dirty. Inspect the trampoline and enclosure prior to each use and replace and worn or damaged parts. Be sure that netting is properly suspended, prior to each use. Tighten all clamps that is loose, and make sure that no damage on the netting.


NOTICE TO JUMPER

- ✧ Do not use the trampoline and the enclosure system when one is under influence of drug or alcohol. Do not smoke while use the trampoline and the enclosure.
- ✧ Avoid jumping too high. Make sure you do not jump too long that you become fatigued. Always control your jump. Do not try to jump over the enclosure netting.
- ✧ Always have someone watch you when using the trampoline, do not jump alone. No more than one person should jump on the trampoline at one time.
- ✧ Do not intentionally jump onto the trampoline enclosure. Do not try to intentionally rebound off the enclosure. Do not hang on the top of the enclosure, or try to climb on the netting. Take off any jewelry that may become entangled with the netting or cut the netting.
- ✧ Do not wear clothing with draw strings, loops, hooks, hard abrasive buckles.
- ✧ Enclosure is not designed for attaching any accessories. Unless specifically designed by the manufacturer of the enclosure.
- ✧ Climbing on and off the trampoline at the enclosure opening door. Always close the opening after entering or exit with the snapped on buckle. Do not try to crawl into the trampoline from the bottom of the enclosure. Do not use the trampoline as a spring board to jump onto other objects.


! WARNING: BE SURE TO FOLLOW ALL INSTRUCTIONS ABOVE WHEN YOU USE THE ENCLOSURE FOR TRAMPOLINE.

PARTS LIST


NO.	DESCRIPTION	Q'TY for 3 legs trampoline	Q'TY for 4 legs trampoline	Q'TY for 6 legs trampoline
A.	UPPER FRAME TUBE WITH FOAM	6 PCS	8 PCS	12PCS
B.	LOWER FRAMETUBE W/FOAM&HOLES	6 PCS	8 PCS	12PCS
C1.	BOLT	6 PCS	8 PCS	12PCS
C2.	BOLT	6 PCS	8 PCS	12PCS
D.	LOCK NUT	12 PCS	16 PCS	24PCS
E.	WASHER	12 PCS	16 PCS	24PCS
F.	SPACER	12 PCS	16 PCS	24PCS
G	WRENCH	1PC	1 PC	1PCS
H.	ENCLOSURE NETTING	1PC	1 PC	1PCS




#A UPPER FRAME TUBE WITH FOAM



#B LOWER FRAME TUBE WITH FOAM AND HOLES



#C1 BOLT



#C2 BOLT




#D LOCK NUT



#E WASHER



#F SPACER




#H ENCLOSURE NETTING




#G WRENCH

STEP 1 Attach one lower frame tube w/foam and holes #B to the leg of the trampoline as shown below. Secure the lower frame using two bolts #C1 and #C2, two lock nuts # D, two washers #E and two spacer #J. Do not over tighten at this point. Repeat this step for all lower frame tubes




STEP 2: Insert all the upper enclosure net tubes w/foam #A into the sleeve of the enclosure net #H according to following picture, but make sure that not insert the whole upper net tube into the sleeve, just insert 1/3.




STEP 3 Attach one upper enclosure tube w/foam #A to one lower frame tube w/foam and holes #B . Repeat this step for all upper net tubes.

HINT: Make sure that the enclosure netting door must be above the “U” shape leg when you assemble the safety net as show in the figure





Make sure the enclosure netting door is above the “U” shape leg

STEP 4 Now start to slide the net sleeve over the net tubes down slowly. Slide a little at the same time for each pole until fully on.



STEP 5 Fasten the bands on the bottom of the enclosure net to the frame tube or the triangle rings. Tighten up the cords on the bottom of the safety net, then tie the cords to the triangle ring as above picture. Zip the entrance of enclosure netting.



⚠ WARNING

CARE AND MAINTENANCE

This trampoline was designed and manufactured with quality materials and craftsmanship. If proper care and maintenance is provided, it will provide all jumpers with years of exercise, fun, and enjoyment as well as reduce the risk of injury. Please follow the guidelines listed below:

This trampoline is designed to withhold a certain amount of weight and use. Please make sure that only one person at any one time uses the trampoline. Jumpers should either wear socks, gymnastics shoes, or be barefoot when using the trampoline. Please be aware that street shoes or tennis shoes should NOT be worn while using the trampoline. In order to prevent the trampoline mat from getting cut or damaged please do not allow any pets onto the mat. Also, jumpers should remove all sharp objects from their person prior to using the trampoline. Any type of sharp or pointed objects should be kept off the trampoline mat at all times.

Always inspect the trampoline before each use for worn, abused or missing parts. A number of conditions could arise that may increase your chances of getting injured. Please be aware of:

- Punctures, holes, or tears in the trampoline mat
- Sagging trampoline mat
- Loose stitching or any kind of deterioration of the mat
- Bent or broken frame parts, such as the legs
- Broken, missing, or damaged springs
- Damaged, missing, or insecurely attached frame pad
- Protrusions of any types (especially sharp types) on the frame, springs, or mat

IF YOU FIND ANY OF THE PREVIOUS CONDITIONS, OR ANYTHING ELSE THAT YOU FEEL COULD CAUSE HARM TO ANY USER, THE TRAMPOLINE SHOULD BE DISASSEMBLED OR SECURED FROM USE UNTIL THE CONDITION (S) HAS BEEN RESOLVED.

WINDY CONDITIONS

In severe wind situations, the trampoline can be blown about. If you expect windy weather conditions, the trampoline should be moved to a sheltered area or disassembled. Another option is to tie the round, outside portion (top frame) of the trampoline to the ground using ropes and stakes. To ensure security, at least three (3) tie downs should be used. Do not just secure the legs of the trampoline to the ground because they can pull out the frame sockets.

MOVING THE TRAMPOLINE

If you need to move the trampoline, two people should be used. All connector points should be wrapped and secured with weather resistant tape, such as duct tape. This will keep the frame intact during the move and prevent the connector points from dislocating and separating. When moving, lift the trampoline slightly off the ground and keep it horizontal to the ground. For any type of other move, you should disassemble the trampoline.