

Baseball Batting Cages

Instructions for the 30'x12'x10' Frame Corners

The following parts are included for your frame. Please review the parts that you received with your batting cage and frame to be sure that you have all the parts listed.

*****YOU WILL NEED TO PURCHASE 18 – 10' LENGTHS OF 1 1/4" THIN WALLED EMT AT LOWES, HOME DEPOT, OR SOME OTHER HARDWARE STORE.**

Lowes Sku # - 72717 - Home Depot Sku # - 580023

PART	QTY	
(A) 3-WAY CORNERS	4	YOU WILL NEED AN AREA ABOUT 50' LONG AND 17'6" WIDE.
(B) 4-WAY CORNERS	4	
(C) 16" PIPE W/REDUCED END	4	IT IS RECOMMENDED THAT YOU MARK OFF THIS AREA BEFORE STARTING.
(H) NET HANGERS	20	
(I) PIPE END CAPS	8	
(J) SELF-DRILLING SCREWS	4	NUT SETTER INCLUDED
(K) 18' TIE DOWN ROPES	4	NOT INCLUDED
(L) ROPE STAKES	4	
(CL) 10' LENGTHS OF EMT***	18	

CONSTRUCTING YOUR FRAME


1. Lay out two of the 3-way end corners (A) 12' apart at one end, where your frame will be, with the 4" corner piece facing inward toward the other end of the frame.
2. Measure 30' and lay out the other two 3-way corners (A) the same way.
3. Lay out the 4-way corners (B) between the end 3-way corners (A) so they are 10' apart.
4. Assemble the four arch tops by attaching one 10' length of EMT (CL) to a 16" pipe (C). Insert one self-drilling screw (J) at the joints.
5. The arch legs and the arch tops are each one 10' length of EMT (CL).
6. Complete assembling the arches by attaching the legs to each of the arch top corners (A) & (B). Attach end caps (I) to the bottom of the legs (CL).
7. Stand up one end arch and the second arch. Attach two 10' runners (CL) between the arches. Stand up the third arch and attach two 10' runners (CL) between second arch third arch. Stand up the fourth arch and attach two 10' runners between the third and fourth arch.
8. Tighten down all corner bolts.
9. Your frame should end up being a little over 30'.

HANGING YOUR BATTING CAGE NET

1. Lay out your batting cage inside the frame and find the top three ropes and tie them to the end arch and then do the same to the other end.
2. Attach the hanger clips to the rope and the net together along one side of the net, then the middle, and then the other side. If you do not get the rope and the net together, it will not hold up your net. Then take the lanyard part of the hanger and tie it around the cable. At this point you can adjust how tight you want the net to hang.
3. Tie the bottom rope tails to the bottom part of the end arch legs to prevent the wind from blowing the net inward.

To secure the frame, we recommend that you attach two 18' ropes to each end of the frame and stake the ropes to the ground.

30x12x10



PART	QTY
(A) 3-WAY CORNERS	4
(B) 4-WAY CORNERS	4
(C) 16" PIPE EXTENSIONS	4
(H) NET HANGERS	20
(I) PIPE END CAPS	8
(J) SELF DRILLING SCREWS	4
(CL) 10' LENGTHS OF EMT	18
(K) 18' TIE DOWN ROPES	4
(L) ROPE STAKES	4

