

Dart 3

Cellular 2G or LTE-M / NB-IoT

Robust and affordable vehicle tracking device with inputs/outputs, remote immobilization for fleet management, driver ID, driver safety and behavior monitoring, theft recovery, and more.



Real-Time Tracking

High-precision GNSS wired tracking device



Inputs/Outputs

1 x Ignition Digital Input, 3 x Digital Inputs, 1 x Analog Input, 1 x Switched Ground Digital Output, Switched Power Out



Backup Battery

Internal Backup Battery in case of loss of power or tampering



Driver ID

Configure iButton®, Wiegand or RFID readers for Driver ID



Driver Behavior

Run hour monitoring, accident and rollover detection, speeding, harsh braking and cornering, and more



Remote Immobilization

Immobilization option to safely disable vehicles and equipment remotely



Installation

Wired or optional OBDII or cigarette lighter power harness available for plug-and-play installation

Connectivity & Location

2G Version

| Module | Quectel MC60 850/900/1800/1900 MHz | |
|----------------------|--|--|
| Constellation | Concurrent GPS / GLONASS / Galileo | |
| Channels | 99 Channel High Sensitivity Receiver | |
| Tracking Sensitivity | -167dBM industry-leading tracking performance | |
| SIM Size & Access | Internal Micro 3FF SIM | |
| GNSS Assistance | GNSS almanac and ephemeris data for greater sensitivity and position accuracy | |
| Low Noise Amplifier | GPS signals are filtered and boosted by a SAW filter and low-noise amplifier (LNA) allowing operation where other units fail | |

LTE-M / NB-IoT Version

| Cellular Module | Nordic nRF9160 Modem operates on all major global LTE-M and NB-IoT bands. | |
|----------------------|--|--|
| | Supported LTE bands: LTE-M (Cat-M1): B1, B2, B3, B4, B5, B8, B12, B13, B14, B17, B18, B19, B20, B25, B26, B28, B66 NB-IoT (Cat-NB1/NB2): B1, B2, B3, B4, B5, B8, B12, B13, B17, B19, B20, B25, B26, B28, B66 | |
| GNSS Module | uBlox EVA-M8Q | |
| Constellation | Concurrent GPS / GLONASS / Galileo / BeiDou | |
| Channels | 72 Channel High Sensitivity Receiver | |
| Tracking Sensitivity | -167dBM industry-leading tracking performance | |
| SIM Size & Access | Internal Micro 3FF SIM | |
| GNSS Assistance | GNSS almanac and ephemeris data for greater sensitivity and position accuracy | |
| Low Noise Amplifier | GPS signals are filtered and boosted by a SAW filter and low-noise amplifier (LNA) allowing operation where other units fail | |
| Cell Tower Location | Cell tower location fallback for positioning when GPS can't get a fix | |

2G and LTE-M / NB-IoT Versions

The following technical specs are shared across both versions of the Dart 3 unless otherwise stated

Power

| Input Voltage 8-36V DC (max) | | |
|---|---|--|
| High-Performance Automotive Power Supply | Stringent power "load dump" tests are conducted to ensure operation in the harshest automotive electrical systems. Built-in self-resetting fuse makes installation simple and safe. | |
| Operating Current | 2G | |
| | ≈250mA when moving | |
| | + ≈60mA while internal battery charging | |
| | LTE-M / NB-IoT | |
| | ≈50mA when moving | |
| | + ≈60mA while internal battery charging | |
| Intelligent Power Management | Device enters sleep mode when vehicle is inactive to prevent battery drain | |
| Sleep Current | <1mA | |
| Backup Battery | 2G – 1100mA LiPo internal backup battery pack | |
| | LTE-M / NB-IoT - 200mA LiPo internal backup battery pack | |

Mechanics / Design

| Dimensions | 95 x 55 x 17 mm (3.74 x 2.17 x 0.67") | |
|--------------------------|--|--|
| Weight | TBD | |
| Housing | ABS Polycarbonate Plastic | |
| Installation | 12 wire harness / 1m length supplied as standard OBDII and Cigarette Lighter harness options available for quick and easy (or temporary) installs | |
| Operating Temperature | -30°C to +60°C (connected to external power) At < 0°C and > +40°C the internal backup battery will not be charged as a safety precaution due to the dangers associated with charging batteries at extreme temperatures. | |
| Cellular Antenna | Internal | |
| GPS Antenna | Internal | |
| 3-Axis Accelerometer | 3-Axis Accelerometer to detect movement, high G-force events, and more | |
| Diagnostic LED | Diagnostic LED indicates operation status | |
| Flash Memory | Store weeks of records if device is out of cellular coverage. Storage capacity for over 10 days of continuous 30-second logging. | |
| On-Board Speed & Heading | The device continuously monitors speed and heading, allowing for over-speed alerts as well as update on speed and heading changes | |
| On-Board Temperature | The device reports internal temperature and prevents the internal battery charging in extreme temperatures. Internal temperature provides an indication of ambient temperature but may not always be precise. | |

Interfaces

| Analog Inputs | 1 x Analog input. 0-40V | |
|---------------------|--|--|
| Digital Inputs | 3* x Digital Inputs with configurable pull up/pull down 0-48V DC input range | |
| | On/Off thresholds: | |
| | Pull-up enabled: low at 0.4V, high at 1.9V Pull-down enabled: low at 0.8V, high at 2.2V | |
| | Can be used for pulse counting *Digital Input 3 pin shared with Driver ID. Cannot be used in conjunction with Wiegand or TTL readers. | |
| Digital Outputs | 1x Switched Ground digital output - 2A max Easily wired up to switch external lights, relays, buzzers, etc Can be used to immobilize a vehicle | |
| Ignition | 1 x dedicated ignition digital input 0-48V DC - 2.2V on/off threshold Can be used as a digital input if not required | |
| Switched Power Out | 3-5Vout Max current 500mA | |
| TTL Interface | Serial interface used to connect a Digital Matter RFID reader for Driver ID | |
| Wiegand | Enables easy integration with a variety of RFID card types and readers | |
| 1-Wire® or iButton® | 1-Wire® or iButton® can be used to read Driver ID tags. Readers available to suit multiple card formats. | |

Smarts

| Auto-APN | Auto-APN allows the device to analyze the SIM card and select the correct APN details from a list to is pre-loaded in the device's firmware. Configure accident and rollover alerts triggered by extreme changes in velocity and orientation of hicle or equipment. Second-by-second GPS data is saved on the device's flash memory, with a capa of approximately 2 hours of data. In the event of an accident, a subset of the data (60 seconds befor 10 seconds after) is uploaded to the server automatically (if configured) or can be requested manual for a detailed reconstruction of the incident. | |
|-------------------------------|---|--|
| Accident & Rollover Detection | | |
| Driver ID Options | RFID reader, iButton®, or Wiegand interface for Driver ID, access control, and logbooking | |
| Driver Safety & Behavior | Monitor speeding, harsh acceleration, braking, cornering, idling, and more to improve safety and prevent unnecessary wear on vehicles | |
| Geofence Alerts | The server can use device location to create geofences and alerts if an asset enters or leaves designated locations | |
| Geofence Download to Device | Geofences can be downloaded directly to the device from Telematics Guru for enhanced location-based actions and alerts. 2G - Maximum of 20 Geofences with up to 30 points per geofence LTE-M/NB-IoT - Maximum of 500 Geofences with up to 100 points per geofence | |
| GPS Jamming Detection | GPS Jamming or Interference can be detected and alerted on | |
| In-Vehicle Alerts | Can be wired up to external buzzers or lights for in-vehicle alerts | |
| Lone Worker Safety | Interface a variety of duress pendants to enable man-down alerts for lone worker safety monitoring. | |
| Preventative Maintenance | Set reminders based on distance traveled and run hours to reduce maintenance and repair costs | |
| Real-Time Tracking | Device remains continuously connected while on the move for real-time asset tracking | |

Smarts (continued)

| Remote Immobilization | Digital outputs can be connected to a relay to enable remote immobilization of vehicles and equin the case of theft, abuse, or unauthorized usage | |
|-----------------------|---|--|
| Run Hour Monitoring | Calculate run hours and distance traveled (odometer) to understand and optimize asset utilization | |
| Sensor Monitoring | Interface with a range of devices and switches for seatbelt detection, duress and panic buttons, I in-cab warning buzzers, and more | |
| Tamper Alerts | Instant alert if the device is disconnected from its power source | |
| Theft Recovery | Switch to Recovery Mode in the case of theft or loss to activate real-time tracking for asset retrieval | |

Device Management

| Flexible Configuration | Configure device parameters such as position update rate, movement and accelerometer settings, and more to fit any tracking application |
|----------------------------|---|
| Device Management Platform | Manage, monitor, configure, debug, update, and restart devices remotely from our cloud-based device management system |
| Configuration App | Configurable with DMLink provisioning tool |

Integration

Security

| Military-level AES-256 Encryption from device to Device Management Platform to protect the integrity |
|--|
| and confidentiality of telematics data. Data forwarded to third-party systems is sent via HTTPS for end- |
| to-end security. |
| а |

Warranty

| Manufacturer's Warranty | Two-year manufacturer's warranty |
|-------------------------|----------------------------------|
| | |

Certifications

| Please visit our knowledge base for a full list of compliance | Coming Soon | |
|--|-------------|--|
| specifications and documentation | | |
| for your region | | |

Warning: Please dispose of the unit correctly. Risk of explosion if the device is exposed to extreme high temperatures or fire.