



North Coast

Open-air™ Stax Finger Splint

Indications

Ideal for treating conditions resulting in lack of full DIP extension, “Mallet Finger” and Zone 1 Extensor Tendon Injury.

Instructions

1. Small flare adjustments can be made to accommodate edema by using a heat gun. Using pliers, hold the splint 1¼" (3.2cm) away from the heat gun and rotate the splint for 20 to 40 seconds. Make necessary adjustments. Allow to cool completely before application.




Figure 1

2. Thread Velcro® loop through the two slots located at the end closest to the PIP joint (see Figure 1).

Velcro® straps, such as L640, are available as convenient precut straps with adhesive book.

3. Peel away backing and attach adhesive Velcro® hook in between slots on the outside of the splint.
4. Trim strap as needed.

Sizing

Measure the circumference at the DIP crease. If patient will be wearing Coban® or other dressing under the splint, measure the circumference with the dressing on.

	DIP	Size		DIP	Size
L620	4.3 cm	0	L624	6.6 cm	4
L621	4.8 cm	1	L625	7.1 cm	5
L622	5.5 cm	2	L626	8.4 cm	6
L623	6.0 cm	3	L627	8.5 cm	7
L6235	6.2 cm	3½			

L630 Economy Kit
75 splints in nine sizes
100 Velcro® straps

L635 Starter Kit
35 splints in nine sizes
50 Velcro® straps

L645 Sampler Kit
One splint of each size

L640 Velcro® Straps
Package of 25 straps

Instructions For Care

1. Wash in warm water with mild soap.
2. Dry with a cloth.



North Coast Medical, Inc.
Gilroy, California U.S.A.
Authorised Representative
Medica Surgical Innovations Ltd.
BB2 4PB UK

