



Cowhorn lock hinge Plain screw



Embedded nut



Link rod




eccentric wheel

Three in one screw



rendering

900*600*1200-1



dimension



Installation method for three in one screws

1. Install the embedded nut



Screw installation effect

2. Install the link rod




3. The effect after installation is shown in the figure




4. Install the eccentric wheel




5. Tighten with a screwdriver







1. Find the board and accessories according to the diagram and check if they are complete



2. Distinguish the board according to the hole position and shape shown in the diagram, and lay it flat on a flat ground as shown in the figure, with the red hole position in the middle of the back plate facing upwards



3. Install the connecting rod on all plates with corresponding hole positions according to the installation method of the three in one screw, and tighten and fix it with a screwdriver. (Refer to the above figure)




4. Place the back panel flat and first install the layers onto the back panel using three in one screws, as shown in the figure

5. Install the front plate of the cat's nest again

6. First install the left and right side panels according to the hole positions of the side panels and back panels, as shown in the figure

7. Install the top and bottom plates according to the hole positions (as shown in the figure)






8. Install the wheel and fix the universal wheel to the bottom plate with 1.5cm ordinary screws as shown in the figure

9. After the wheel installation is completed, stand up the cabinet, tighten the eccentric wheel behind the back plate, and fix the side plate and back plate (as shown in the figure)

10. Install the suspension bridge, thread the suspension bridge rope from bottom to top through the corresponding hole position, and fasten it properly

11. Install the cat grab post and fence, as shown in the figure, and fix them to the corresponding positions with 3cm screws






12. Install the bottom ladder, first fix the hinge with 1.5cm screws and the ladder, and then fix the ladder on the floor board

13. Install the entrance and exit doors using 1.5cm screws as shown in the diagram

14. Install the glass door. The first step is to install the metal plug onto the bottom plate hole, and then install the glass hinge into the metal plug

15. Install the glass door. The second step is to clip the glass in, with the outer edge of the glass level with the outer edge of the hinge. Place gaskets on both sides and tighten them with a screwdriver



16. Similarly, clip the glass in on top, with the outer edge of the glass level with the outer edge of the hinge. Place shims on both sides and tighten with a screwdriver

17. Install the locking iron plate, align it with the hole position, and fix it with the shortest screw

18. Install the door lock. Install the door lock on the bottom of the right glass, as shown in the figure. Adjust the lock tongue and place a gasket on the corresponding lock hole, and tighten it with a screwdriver

19. Install the door stopper, first close the right glass door, determine the position of the door stopper, and fix it on the top plate with 3CM screws