




www.gillathletics.com  
800-637-3090

# OUTDOOR WALL PADS INST90364

## GENERAL GUIDELINES

- NEVER install wall pads more than 4" above the finished ground! If directed to install wall pads higher than 4" above the floor, STOP WORKING IMMEDIATELY and contact your local Porter representative. The recommended dimension for outdoor wall pads is 3" to account for the size of a softball.
- Check installation/architectural drawings specific to this project to determine location of wall pads.
- Panels must be inspected and measured before installation. Lay out all pads and mark Z-clip locations.
- To minimize wrinkles in fabric of installed panels, wall must be either perfectly plumb, or slightly convex (bowed out) over the area to be covered. If found to be concave (bowed in), install sufficient shims at midsection of panels to provide plumb or convex wall profile.
- Center Z-clips are needed on pads over 6' tall.

**WARNING:** This product can expose you to Urethane, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.p65warnings.ca.gov](http://www.p65warnings.ca.gov).



## FENCE PADS ONLY

CHAIN LINK FENCE HDWE PART NO. 3650

CUT VINYL TO EXPOSE  $\frac{1}{4}$ "-20 THREADED INSERTS



**WARNING**  
This pad is provided to reduce the possibility of minor injuries. However, any activity involving motion and severe impacts may result in serious injuries, including but not limited to paralysis or death. No pad can guarantee the prevention of serious head or neck injuries that are due to a violent impact while participating in various sports activities.

POKE A FEW SMALL HOLES  
IN THE BOTTOM OF EACH  
PAD TO ALLOW FOR  
PROPER DRAINAGE

