


# THE WESTPORT TOWER - HVN#1018

## ASSEMBLY INSTRUCTIONS



**Before starting this kit, make sure you read through all the instructions carefully. Always remember to dry fit parts and sand as needed.**

**We use two kinds of glue when assembling our kits. Super glue (cyanoacrylate) or PVA glue.**

**You can repaint or weather our kits easily! The paint we use is a great base primer and will take further paint nicely.**

**If you have any issues during assembly, please contact us and we'll always help!**

**We would like to take the time to thank you for purchasing a Black Site Studios product!**

[www.blacksitestudio.com](http://www.blacksitestudio.com)

### WE SUGGEST HAVING THESE TOOLS ON HAND



### IMPORTANT SYMBOLS YOU'LL FIND ON YOUR JOURNEY



ATTENTION



DRY FIT



NO GLUE




GLUE




TRIM/SAND

# THE WESTPORT TOWER - HVN#1018


## SHEET LIST




SHEET A




SHEET B




SHEET F




SHEET G




SHEET H




SHEET J




SHEET N




SHEET C




SHEET D




SHEET E




SHEET K



SHEET L



SHEET M



SHEET O X5



**CHECK YOUR SHEETS  
BEFORE STARTING THE BUILD**

# THE WESTPORT TOWER - HVN#1018


PAGE 1

## Sheets needed

- Sheet C
- Sheet H
- Sheet J
- Sheet G



**We find it easier to glue the walls together before gluing into the base. For parts H1 and J2, Lay the wall flat and glue along the edge.**





# THE WESTPORT TOWER - HVN#1018


PAGE 2

## Sheets needed

- Sheet b
- Sheet a





**We find it easier to glue the walls together before gluing into the base. For parts A1 and B3, Lay the wall flat and glue along the edge.**



# THE WESTPORT TOWER - HVN#1018

**Sheets Needed**  
**Sheet K**  
**Sheet L**





**Place part L1 in first  
then slot parts M5 &  
K3 into the holes provided.  
This can be a tight fit, make  
sure to sand or file as needed.**





# THE WESTPORT TOWER - HVN#1018

**Sheets Needed**  
**Sheet N**  
**Sheet F**




**Slot N2 into**  
**the holes**  
**provided**




**There are 3 different**  
**lengths of I beam.**

# THE WESTPORT TOWER - HVN#1018




**You can now glue in the I beams. They can be glued in whatever order you like! The more random the better.**

# THE WESTPORT TOWER - HVN#1018



**You can now glue in the floors.  
You can glue them in any order  
you like.**



**After gluing in the floors you can glue  
the top inside walls. Make sure to dryfit  
these first.**




# THE WESTPORT TOWER - HVN#1018




The windows on sheet 0 can be glued in. Once again you can do this in a random fashion. For ruined buildings such as this you'll get a better effect if you dont plan it out. Also cut or bust some of the windows yourself.

You'll notice that these inside dividing walls are optional. We did this for people who want more space on the inside for minis.


If youre wanting to use them simply apply some glue and slide them wherever you like.



M1/M2



K1/K2





Laminate the inside walls together.

These walls are optional.

2x

C3



# THE WESTPORT TOWER - HVN#1018

