

Since 1968


COMMAX
SmartHome & Security

2 CHANNEL

FM WIRELESS INTERCOM

Model: WI-2B

COMMAX



COMMAX Co.,Ltd.

513-11, Sangdaewon-dong, Jungwon-gu, Seongnam-si, Gyeonggi-do, Korea

Int'l Business Dept. Tel. : +82-31-7393-540~550 Fax. : +82-31-745-2133

Web site : www.commax.com

PM182B00001C

www.commax.com

COMMAX Co.,Ltd.




- Thank you for purchasing COMMAX products.
- Please carefully read this User's Guide (in particular, precautions for safety) before using a product and follow instructions to use a product exactly.
- The company is not responsible for any safety accidents caused by abnormal operation of the product.

Introduction

The model number is located on the bottom and record the serial number in the space provided below. Refer to these numbers whenever you call upon your Commax dealer regarding this product.

Model No. _____ Serial No. _____

To prevent fire or shock hazard, do not expose the unit to rain or moisture.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING : TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE

CAUTION : TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD AND ANNOYING INTERFERENCE, USE THE RECOMMENDED ACCESSORIES ONLY

CAUTION : TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD, REFER CHANGE OF SWITCH SETTING INSIDE THE UNIT TO QUALIFIED SERVICE PERSONNEL

CAUTION : TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD, REFER MOUNTING OF THE OPTIONAL INTERFACE BOARD TO QUALIFIED SERVICE PERSONNEL

© 2001 COMMAX COMPANY LIMITED
All Rights Reserved
Commax are registered and trademarks used by
commax company limited

Important Safeguards

- 1. Read Instructions** - All safety and operating instructions should be read before the unit is operated.
- 2. Retain Instruction** - The safety and operating instructions should be retained for future reference.
- 3. Heed Warnings** - All warnings on the equipment and in the operating instructions should be adhered to.
- 4. Follow Instruction** - All operating and use instructions should be followed.
- 5. Ventilation** - Slots and openings in the cabinet are provided for ventilation and to protect it from overheating.
- 6. Power Sources** - This equipment should be operated only from the type of power source indicated on the marking label.
- 7. Grounding** - This product is equipped with a polarized alternating - current line plug. This plug will fit into the power outlet only one way. This is a safety feature.
- 8. Power Cord Protection** - Power- supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them; pay particular attention to cords at plugs, convenience receptacles and the point where cords exit from the equipment.
- 9. Overloading** - Do not overload power outlets and extension cords as this can result in a risk of fire or electric shock.
- 10. Damage Requiring Service** - Unplug this equipment from the power source and refer servicing to qualified service personnel under the following conditions:
 - a. when the power supply cord or plug is damaged;
 - b. if liquid has been spilled or objects have fallen into the unit;
 - c. if the equipment has been exposed to rain or water;
 - d. if the equipment has been dropped or otherwise damaged;
 - e. when the equipment exhibits a distinct change in performance - this indicates a need for service.
- 11. Water and Moisture** - Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like.
- 12. Accessories** - Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the appliance.

Note : Do not place this product directly on wood or simulated woods surfaces as these surfaces are easily damaged.

- 13. Object and Liquid Entry** - Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

Important Safeguards

- 14. Servicing** - Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
- 15 Replacement Parts** - When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or having the same characteristics as the original part.
- 16 Safety Check** - Upon completion of service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
- 17 Power Line** - The system should not be located near overhead power lines or other electric light or power circuits, or where it can fall into power lines or circuits.
- 18 Attachment** - Do not use attachments not recommended by the product manufacturer as they may cause hazards.
- 19 Outdoor Cable Protection** - All outdoor connections should be protected from moisture. Internal heating can draw moisture or condensation into the covering of the unit and affect its operation.
- 20 Lightning** - For added protection for this product before a lightning storm, or when it is left unattached and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges. Be sure it is properly grounded, as defined above. If you live in an area heavily prone to lightning storms, it is recommended that you invest in power-line, telephone-line, RF cable and Actuator/Polarization surge protectors to protect your system from possible damage.
- Note to system installer:** This reminder is provided to call the system installer's attention that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.
- 21 Protective Attachment Plug** - The product is equipped with an attachment plug having overload protection. This is a safety feature. See Instruction Manual for replacement or resetting of protective device. If replacement of the plug is required, be sure the service technician has used a replacement plug specified by the manufacturer that has the same overload protection as the original plug.

■ INTRODUCTION

Thank you very much for your selecting our 2 channel F. M. wireless intercom (Model WI-2B).

The condenser microphone of this intercom produces a high-sensitivity. The phase locked loop (P.L.L.) and frequency modulation (F.M.) circuit produces high-fidelity.

A filter circuit is also for minimizing interference and line noise.

■ FEATURES


- * No wiring between sets is required.
- * Plug each set into the nearest AC outlet.
- * Push to talk and remove to listen.
- * Can be used as a monitor for the BABY'S ROOM or any room in the house.

■ CAUTION

Please refer to the following conditions when using this item.

- * The intercom should be situated away from heat sources such as radiators, heat registers, stoves or other items that produce heat.
- * The intercom should not be used near water, for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement or near a swimming pool, etc.
- * Please avoid use of this item at low temperature.
- * Care should be taken so that liquids are not spilled into or on top of either unit.
- * Power supply cords should be routed so that they are not likely to be walked on or pinched by other items placed upon or near them.
- * The power cord to the intercom should be unplugged from the AC outlet when left unused for a long time.
- * In case of use with other electronics such as T.V, hairdryer, fan, computer, etc, line noise may happen.

■ CONTROL AND FUNCTIONS



■ OPERATION


1. Simply plug each unit into an AC outlet.
2. Set each intercom station to the desired channel by setting the channel selector to the A or B
3. Turn on the power/volume switch to ☐ (OFF), ☒ (LOW), ☒ (MIDDLE) or ☒ (HIGH).
4. To page another station, press the call button, and this will produce a call tone on the same channel to all other units.
5. In order for the receiving station to respond, press the talk button to talk and release to listen. Speak in a normal voice from arms length for best results.
6. To listen to a reply, remove your finger from the talk button, and the other station can now send a message.
7. For dictating or sending long messages, just push the lock button down and talk as long as you want.
8. In order to listen to the reply, you need to push the lock button down to release it. This will allow a reply to be received from any station.

Note : When a station is locked into the talk mode, it cannot receive a message or call tones from other stations.

■ OPERATION RANGE

Communication must be between operated locations on the same power transformer.

Avoid locations where there is a sub-transformer between them.



■ SPECIFICATIONS

Power source AC 110V/120V/220V/230V/240V, 50/60Hz

Power consumption 5W

Frequency Ch A : 230KHz

Ch B : 260KHz

Power source AC 230V/240V, 50Hz

(European) Ch A : 120KHz

Ch A : 145KHz

R.F Output power 100 mW

Audio output power 500 mW

Dimension 143(W) × 136(D) × 40(H)mm

Weight 425g