

# Product Warranty

Nuby's 3 in 1 Baby Carrier includes a 1 year limited warranty against defects from the date of purchase. In the event of a malfunction or defect during the in-warranty period, luv n' care® Ltd as its option will replace or repair the product under warranty upon receipt of the product and the proof of purchase with a valid date of the purchase, the defective part will be immediately repaired or replaced and returned to your free of charge. Please send defective unit, proof of purchase with valid date of purchase and a description of the problem you have encountered to;

**Nuby UK LLP**  
**13 Burford Way**  
**Boldon Business Park**  
**Boldon Colliery**  
**Newcastle upon Tyne**  
**NE35 9PZ**

**Note:** This warranty does not cover a defect that has been caused by negligence, accident or improper use of the product. Any Questions please call **0800 334 5844** (UK only) or visit [www.nuby-uk.com](http://www.nuby-uk.com)  
 COMPLIES WITH EN13209-2:2015

EC REP

DC PHARM  
 Calle Filadores,  
 S/N - NAVE 3  
 Olesa de Montserrat,  
 08640 Barcelona,  
 SPAIN



Talbot's Family Products UK LLP  
 13 Burford Way  
 Boldon Business Park  
 Boldon Colliery  
 Newcastle upon Tyne  
 NE35 9PZ  
 Freephone number:  
 0800 334 5844  
 enquiries@nuby-uk.com  
 www.nuby-uk.com  
 www.nuby.com

Made in China



Form PIC/UK  
 Item number: 30110

© 2021 Talbots.

Nuby™ and Nuby logo licensed to Talbot's by Admar International. Product Design and all other TMs owned by Talbot's.  
 PRODUCT DESIGN TM & ©

Facebook® is a registered trademark of Facebook, Inc.


# IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE



Instruction Manual

## 3 in 1 Ergonomic Baby Carrier

Newborn to Toddler



For competitions & offers join us on



### KEEP AWAY FROM FIRE AND STRONG SOURCES OF HEAT

**WARNING:** Take care when bending or leaning forward or sideways. Check all buckles, snaps straps and adjustments are secure before each use. Check for ripped seams, torn straps or fabric and damaged fasteners before each use and do not use if any such concerns are found. Always ensure sufficient room around baby's face to provide a clear source of air. Premature infants, infants with respiratory problems, and infants under 4 months are at a greater risk of suffocation. Ensure proper placement of child in product including leg placement. Never use soft carrier when balance or mobility is impaired because of exercise, drowsiness or medical conditions. Never use a soft carrier while engaging in activities such as cooking and cleaning which involve heat source or exposure to chemicals. Keep away from fire. Never wear a soft carrier while driving or being a passenger in a motor vehicle. Never lie down with your baby in the baby carrier. Child's legs should straddle the seat on your waist. Never unbuckle waist or shoulder straps while child is in the carrier. Always keep hands available to protect your child from fall or potential danger. Hold your child securely until carrier is snug and correctly attached. Child must face towards you when carried on the back. Carrier should be used by adult carrying one child only. Do not use this carrier when jogging, biking, or performing any strenuous activity. Consult your doctor before carrying heavy weight. Carrier should not be used by persons with conditions that might interfere with safe use of the product. Carrier should not be used by persons with conditions that might interfere with safe use of the product. Inspect the carrier regularly for signs of wear and tear. DISCONTINUE use if damaged, broken or parts are missing. Do not drink hot drinks while using this product as spills may scold your baby. Your child MUST be able to sit up unassisted to use the backpack position. Your child MUST face forward towards the person carrying them in the backpack position. Never leave your child in the carrier unless it is being worn as your child may suffocate. Check regularly that your child is secure, comfortable and that their face is uncovered and that they are breathing freely.

### IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

## About your 3 in 1 Baby Carrier

Carry capacity Maximum 15kg intended use  
 Age of use: From 3.5kg to 15kg (approx. newborn to 2 years)  
 Fabric: Shell 100% Polyester, Lining 95% Polyester, 5% Cotton  
 Carry: 3 in 1 (parent facing front carry and parent facing back carry, forward facing front carry)  
 When using the soft carrier monitor your child  
 For low birthweight babies and children with medical conditions a strong recommendation is given to seek advice from a health professional before using this product.  
 Important instructions for future use

### WASHING INSTRUCTION

We recommend spot cleaning your Nuby™ 3 in 1 baby carrier with a soft cloth, soap and warm water.  
 Hand wash only and drip dry until fully dry  
 Do not soak or bleach. Do not use fabric softeners or detergents.  
 Do not iron, do not dry clean.

### WARNING: FALL AND SUFFOCATION HAZARD

Read all instruction before assembling and using the soft carrier.  
**FALL HAZARD – INFANTS CAN FALL THROUGH A WIDE LEG OPENING OR OUT OF CARRIER.**  
 • Adjust leg openings and/or safety harness belt to fit baby's legs snugly.  
 • Before each use, make sure all fasteners are secure.  
 • Take special care when leaning or walking.  
 • Never bend at waist; bend at knees.  
 • Only use this carrier for babies between 3.5kg and 15kg  
**SUFFOCATION HAZARD – INFANTS UNDER 4 MONTHS CAN SUFFOCATE IN THIS PRODUCT IF FACE IS PRESSED TIGHT AGAINST YOUR BODY.**  
 • Do not strap infant too tight against your body  
 • Allow room for head movement  
 • Keep infants face free from obstruction at all times.  
**WARNING:** Your balance may be adversely affected by your movement and that of your child.

## INSTRUCTIONS FOR USE WAIST BAND

Every carrying position starts with the waist band, place around your waist and fasten the buckle making sure that you hear the click. Tighten the waist belt by pulling on the adjustable straps.



## FRONT CARRY

Baby facing in/towards you • Minimum 3.5kg

Always use this with the carrier in the wide seat position.



1. Position waist band around your waist. Bring baby up to face you. Baby's leg should straddle the seat of the carrier.



4. With both shoulder straps secure on your shoulders buckle the connecting strap buckle behind your neck and tighten.

5. To use neck support, unfasten the buttons, raise the neck support and connect with the buttons on the shoulder straps.



2. Support baby's head with your left hand; with your right hand place the shoulder strap over your shoulder.

3. Switch hands to support your baby with your left hand and place the shoulder strap over your left shoulder.

### NECK SUPPORT

1. Unfasten neck support buttons.
2. Raise neck support and connect with buttons on shoulder straps.



## FRONT CARRY

Baby facing forwards • Minimum 6 months

Do not start until baby is 6 months.

1. Place waist band on your hips or waist. Bring baby close to you, facing out. Place baby's bottom close to your belly button and positioned as if they are sitting on the belt. Guide baby's legs to either side of the carrier seat.
2. Support baby with one hand and place the shoulder strap over your shoulder with the other hand.
3. Switch hands to support your baby with one hand place the shoulder strap over your shoulder.
4. With both shoulder straps securely on your shoulders, engage the connecting strap buckle and tighten.

## BACK CARRY with assistance

Baby facing forwards towards you • Minimum 6 months old  
Your child must be able to sit up unassisted before using the back carry position

1. Secure the waist belt by fastening the button until it clicks and tighten.



2. Turn the carrier to the back of your body



4. Lift up the carrier and place one of the shoulder straps over your shoulder. Place the other strap over your arm and make sure baby's bottom is deep in the panel just above the waist band.



3. With another person's assistance carefully hold baby into position.

5. Secure the buckle across the front of your chest.

## BACK CARRY without assistance

Baby facing forwards towards you • Minimum 6 months old  
Your child must be able to sit up unassisted before using the back carry position

Put baby into front carry (as per front carry instructions)

1. Loosen the shoulder straps by lifting the outer edge of the buckle. Slip your right arm up and under the shoulder pad.
2. Slide your left arm down under the shoulder strap
3. Place one hand under baby's bottom and right hand on the belt. In one motion, lift baby and rotate them around your hip (under your lifted arm) onto your back under your lifted arm. A light bounce will assist the move. Reach hand around your back to support baby.
4. Slide right hand under shoulder strap and put into place, slide left hand under webbing and put into place.
5. Tighten straps for a snug fit.

To remove baby from back position, follow the instructions above to rotate baby around your hip to your front. When in front, release the connecting strap and shoulder straps to place baby down.

### WIDE SEAT

To change the carrier to a wide seat;

1. Unzip pocket under the neck support panel and roll down the wide panel
2. Panel then to be buttoned to the waist band.

### NARROW SEAT

To change carrier to a narrow seat;

1. Unbutton the seat panel from the waist band
2. Roll up the wide panel into the zipped pocket. Please note narrow seat should only be used for front carry with baby facing forward (for baby's over 6 months).