

Bolt Down Instructions:

Tools Needed:

- Drill Motor
- Anchors
- Masonry Drill Bit
- Wrench to fit nuts on anchors
- Marker to mark the floor

Steps:

1. Place the safe in the location desired. Note that it is desirable to have at least 1" clearance to the wall on the back and sides.
2. Mark the floor at the two front corners of the safe. This will help in relocating the safe after drilling the mount holes in the floor.
3. From inside the safe, mark the floor through the mount holes in the bottom of the safe.
4. Move the safe to the side and drill the floor at the marks with the masonry drill bit. Be sure to drill the holes deeper than the length of the anchors.
5. Vacuum the concrete dust out of and from around the holes in the floor.
6. Move the safe back into position using the corner marks to help align the safe.
7. Insert the anchor through the safe floor and into the concrete floor until the washer touches the safe floor, and then tighten the nuts from inside the safe.
8. Tighten first to a barely snug level on each bolt before tightening up all bolts evenly.