

Contact Us: **FACTORY UTV LLC.**

9237 Beatty Drive Sacramento, CA 95826

Phone : (916) 383-2730

E-mail : info@factoryutv.net

Go online: www.Factoryutv.net



Can-Am Maverick X3 Alternate Instructions

U.H.M.W. Ultra. High. Molecular. Weight. Polyethylene All Terrain Skid Plates & Under Armor Kit For UTV's

***Diff**

Alt. Front UMW Diff. Skid Plate Instructions :

Install: (2x) J-Clips on to stock main skid: *in (C) locations.*

With tip's facing inward toward vehicael, drill out rivet's if needed.

Install: (2x) M6- 1.0 x 20mm Flange Bolts *in Diff. Skid : (C) locations.*

** Align edge with Main Skid. Mark and *drill out (A) locations.*

(See *Drilling instructions)

Install: (6x) ¼"-20 x ¾" Self Tapping Bolts *in Diff. Skid : (A) locations.*


(Alt. Diff. Skid will only work in conjunction with OEM Main skid.)




Hardware (example bolts are sized to scale)

¼"-20 x ¾" Self Tapping Bolts

M6- 1.0 x 20mm Flange Bolts



Counter Sunk Washers



J-Clip's

***RS**

Rock Sliders Instructions : (standalone)

*Drill out (10x) Rivets *in main skid : (A) locations.* (See *Drilling instructions)

Install each Rockslider on top of OEM skid plate

Install: (10x) ¼"-20 x ¾" Self Tapping Bolts with (10x) Counter sunk washers *in main Skid : (A) locations.*



Ensure all bolts are fastened securely

(if Rocksliders are to be later installed with FUTV UHMW main skid plate, rocksliders will then mount in-between skid and chassis frame with longer bolts)

***Rx**

Rear skid and X-Brace Instructions : (standalone)

*Drill out (13x) Rivets *in rear skid : (A) locations.* (See *Drilling instructions)

*Drill out (6x) Rivets *in Main skid : (B) locations.* Remove OEM rear skid plate.

Install rear skid plate (whether or not w/ X-Brace) in OEM main skid plate.


(X-brace sits in-between skid & chassis frame, protecting the Transmission)

Align with lip of Main skid plate, you will need to replace rivets in (B) locations.

Install: (13x) ¼"-20 x ¾" Self Tapping Bolts with (13x) Counter sunk washers

in Rear Skid : (A) locations.

Ensure all bolts are fastened securely



*Drilling Instructions : *

Use a : #Nº7 (13/64th) drill bit.

(one size above the commonly available 3/16th bit) Recommend the use of : ¼"- 20 Tap *(Optional)

To drill and thread self tapping bolts in to chassis frame.

Finger Thread All Bolts Prior To Fastening Securely With Power Tools.

We strongly recommend the use of a "Thread Locking Compound" when installing any mounting hardware.

(When installation is complete , ensure all bolts are fastened securely.)