

Overview Guide

# Uneekor Launcher

Important: Read before using.



# Table of Contents


Creating a MyUneekor account.....	(2)
Start.....	(4)
Launch Monitor.....	(4)
Accessory Devices.....	(4)
Software.....	(5)
News.....	(6)
Devices.....	(7)
Launch Monitor Devices.....	(7)
Accessory Devices.....	(7)
Licenses.....	(8)
Computer Name.....	(8)
Register License Keys.....	(8)
Select License Keys.....	(8)
Activate License Keys.....	(8)
Install.....	(10)
Install Wizard.....	(10)
Help.....	(11)
Links.....	(11)
Submit Feedback / Request Support.....	(11)

# Creating a MyUneekor Account

Opening Uneekor Launcher:

## Step 1:

To use the Uneekor Launcher, a MyUneekor account will need to be created. Please sign in or create an account using the link on the bottom of the form or using the link [here](#)


A screenshot of the Uneekor Launcher application window. The window has a dark gray title bar with the text "Uneekor Launcher" on the left and standard window controls (minimize, maximize, close) on the right. The main content area is black. In the center, there is a white stylized "U" logo. Below the logo, the text "Sign in with your Uneekor Account" is displayed. Underneath this text are two input fields: "Email Address" and "Password". Below the password field is a checkbox labeled "Keep me signed in" which is checked. Below the checkbox is a yellow button with the text "Sign in". Below the button is a link that says "Forgot password?". At the bottom of the form is a button that says "Create your Uneekor Account". At the very bottom of the window, the version number "0.8.1" and the copyright notice "© Uneekor, Inc." are displayed.

## STEP 2:

Once an account has been created and signed in, you are free to use all the features the launcher offers.

# OPENING LAUNCHER

\*note: Once an account has been signed in, the account will be remembered until signed out



# START


## START TAB

The Start tab of the Uneekor Launcher is your home base for everything Uneekor.

The Start tab is separated into 4 different sections: Launch Monitor, Accessory Devices, Software and News.

### Launch Monitor

Find information and settings about your connected launch monitor. In this section, you will see: Launch Monitor Type, serial number, update(DLL) versions, and the ability to adjust the system altitude under settings.




### Accessory Devices

See information related to your Uneekor Accessories including Swing Optix and Balance Optix.


# START

In this section, you will see your connected accessories, their serial number, and links to purchase new accessories



## Software

In this section, you will be able to see your Uneekor software listed for you with the ability to start Uneekor and third-party software directly from the application.



# START

## News

Here, you will find news about any updates to your Uneekor products.

News	
Gameday New Course! Rich Harvest Farm	2/17/2023
EYE XO2 EYE XO2	2/17/2023
GOLFDAY beta! GOLFDAY beta!	2/17/2023
EYE MINI beta testing in progress. EYE MINI Launch Monitor.	7/18/2022
Refine+ update released Refine+ version 1.2.3 has been released.	5/15/2022

# DEVICES

## DEVICES

In the device tab, you will be able to see launch monitors and accessories that are connected to the PC as well as the ability to register the hardware to your account.

### Launch Monitor Devices

See a list of connected devices, selected your network interface and register the product with Uneekor

#### Launch monitor devices

1. For QED, EYE XO, EYE XO2 or EYE MINI static network mode: select the ethernet network interface.

Refresh Reset

Ethernet

Select Configuration completed!

2. Find launch monitor devices from your computer and network.  
3. Register devices to your Uneekor Account.  
4. Select a device to use with this computer.

Refresh

##### EYE MINI

Serial Number 501000023822  
Address 10.10.10.88  
Status OK

Register to your account

Unable to select

##### EYE XO

Serial Number 300001891043  
Address 172.16.1.232  
Status OK

Registered

Selected

### Accessory Devices

See a list of Uneekor accessories that are connected to your PC. From that list, you will be able to select your network inface for Balance Optix and register your Accessory with Uneekor

#### Accessory devices

1. For Balance Optix direct connection mode: select the ethernet network interface.

Refresh Reset

Ethernet

Select Available to select.

2. Find accessory devices from your computer and network.  
3. Register devices to your Uneekor Account.  
4. Select devices to use with this computer.

Refresh

##### Swing Optix

Serial Number 601921365138  
Address USB  
Status OK

Registered

Selected

##### Balance Optix

Serial Number 651061427075  
Address 172.16.10.10  
Status Unknown

Unable to register

Unable to select



# LICENSES

## Licenses

In the licenses tab, you will be able to see your PC name, register a new license to your account and select what licenses to use with your PC

### Computer Name

Here, you will see the name of your PC



Computer name

YOGA\_C740

### Register license Keys

Add new license keys to add to your account



Register license keys

Register new license keys to your Uneekor Account.

### Select License Keys to Activate for this Computer

Here, you will see a list of license keys that are available to be activated on the current PC

# LICENSES

## Select license keys to activate for this computer

Each license key can be activated for only one computer at the same time.  
Only one license key can be selected for each software product.

Refresh

### Available license keys

#### Gameday

E726B-AC399-5E025-3FEEE

Duration Perpetual  
Expiry N/A

Select

#### Golfday

DCDFA-D838E-B5E9C-806C7

Duration Perpetual  
Expiry N/A

Select

#### REFINE

7F5AA-D1C1C-C7F9E-DEE7F

Duration Perpetual  
Expiry N/A

Select

#### REFINE

35F74-64A44-FCC17-E33DC

Duration 1-month  
Expiry 5/1/2023 10:50 PM

Select

#### REFINE

1DE10-4E3FF-4E75D-5CFE

Duration Perpetual  
Expiry N/A

Select

#### REFINE+

67D37-67E9A-1E8A5-67836

Duration Perpetual  
Expiry N/A

Select

#### REFINE+

20AD6-16275-7BE21-4A026

Duration Perpetual  
Expiry N/A

Select

#### Third-party Connector

30275-AEC35-FEB5D-D5CC9

Duration Perpetual  
Expiry N/A

Unable to select

#### VIEW

DCF6B-D65F8-A9034-A0D16

Duration Perpetual  
Expiry N/A

Select

#### VIEW

13410-7AEBA-09A58-3D61B

Duration Perpetual  
Expiry N/A

Select

#### VIEW - Add-on: Third-party C

C8A60-1B8DB-DC32D-44D78

Duration Perpetual  
Expiry N/A

Select

## Selected or Activated License Keys For This Computer

A list of activated License keys on this PC

### Selected or activated license keys for this computer

#### Third-party Connector

7195B-ACCB4-DEA4D-A561E

Duration Perpetual  
Expiry N/A

Deactivate


# INSTALL

## Install

In the Install tab, you will see all our hardware products with an interactive step-by-step guide for each product.

### Install Wizard

Selected your product and click the continue button to open the interactive installation guide



# HELP

## Help

In the Help Tab, you will find links to our Support page, Resources page and FAQ page. You also can submit feedback to the company.


## Help

Links to Support, Resources, and FAQ



## Submit Feedback

Found an issue or have a concern? Submit feedback or feature requests directly to Uneekor.

A screenshot of a "Submit Feedback / Request Support" form in a dark theme. The form has a title bar at the top. Below the title, there is a "Category" label followed by a dropdown menu showing "General feedback". A large, empty text area for feedback is positioned below the dropdown. At the bottom of the form, there are two checkboxes: "Request support" and "Include diagnostic reports", both of which are checked. To the right of these checkboxes is a yellow "Submit" button.