



TEMPT

LOOK . FEEL . OWN

V SPORT

**USER
MANUAL**

IN THE BOX:



----- 1 Neckband



1 User Manual and
Warranty QR Card



1 Charging Cable

BUTTONS AND FUNCTIONS:

Multifunction Button (MFB) / Power Button

- Press and hold power button to turn neckband on or off
- Single press power button to answer and end calls
- Long press power button to reject calls
- Single press to play/pause multimedia files
- Single press (Volume button) to change track while playing multimedia files
- Volume up- Long press volume up(+) button
- Volume down- Long press volume down(-) button



POWER ON/OFF:


- To power OFF/ON neckband - Press and hold the power button.



HOW TO PAIR:

1. First Use:

- Turn on the Bluetooth function on your phone.
- Power on the device and the device will automatically be in pairing mode.
- On the other device search for available Bluetooth devices.
- Select "Tempt V Sport" from the list and the neckband will be automatically paired.



ANSWERING A CALL:

- Single Click power button to answer the call

REJECTING A CALL:

- Hold power button for 1 sec.

DISCONNECT A CALL:

- Single click power button to disconnect a call.



PLAYING MULTIMEDIA FILES

Media playback can be controlled directly from the neckband using the multifunction button.

PLAYING AND PAUSING A MULTIMEDIA FILE:

- Single press the MFB button. The most recently-played music file will play automatically in the default music app installed on the connected device.
- During playback, single press the MFB button to pause playback. To resume playback, single press the MFB button again.

SKIPPING TO THE NEXT MULTIMEDIA FILE:

- Single click volume up(+) button to skip to the next multimedia file.

SKIPPING TO THE PREVIOUS MULTIMEDIA FILE:

- Single click volume down(-) button to skip to the previous multimedia file.

Launching Voice Assistant:

Press and hold (1-2 sec) the MFB button to switch on Voice Assistant.

CHARGING THE BATTERY:

Charge the battery before using the neckband for the first time or when the neckband has been unused for extended periods.

- Use only approved chargers and cables.

Unapproved chargers and cables can cause the battery to explode or damage the neckband.

- If the battery is completely discharged, the neckband cannot be turned on immediately when the charger is connected. Allow a depleted battery to charge for a few minutes before turning on the neckband.

NOTIFICATION:

- Please fully charge it if it was going to lay idle for a long time and place it in a cool dry place. Please re-charge it every 2 months for storage.
- Please fully charge before first use.

CORRECT DISPOSAL OF THE PRODUCT:

(Waste Electrical & Electronic Equipment.)



This marking shown on the product or its literature, indicates that it should be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household user should contact either the retailer where they purchased this product, or the local government office, for the details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

TEMPT CARES - WARRANTY GUIDELINES

1. Tempt warranty is restricted to the first purchaser and on the product bought from direct Tempt official channel partners & resellers.
2. Tempt Products are covered under warranty for 12 months / 1 year from the date of purchase, 6 months warranty is on the box purchase and another 6 months happy warranty can be added if the product is registered within 10 days from the date of purchase on the Tempt official website www.temptindia.com
3. Proof of purchase i.e. invoice is required to claim the warranty.
4. You can register your warranty service request here at website, our team will connect back and will try and trouble shoot the issue.
5. If the issue is not resolved, we will align a service partner or arrange a pick up from your address for the replacement.
6. If in case of the reverse pickup not available Tempt will request you to ship the product to us and on the receipt of the same replacement will be done.
7. Tempt Cares is limited to provide repairs /Rectification of the fault or if the replacement is made it will be same model or an equivalent model, no refund or vouchers are possible.
8. Warranty Coverage – Workmanship, Manufacturing or technical defects, Missing parts, Received damaged.

9. Not Covered – Out of warranty, unauthorized purchase, Sound Characteristics (Subjective), in appropriate Voltage Charging, Normal wear & Tear, Cosmetic damage, Commercial Usage, Battery/ in-built MICs, Water logged, breakage or issues related to look & feel of the product, dim display under sunlight, low sound due to accumulation of dust or dirt.
10. Accessories that come along with the main Device are under warranty for 3 months from the date of purchase.
11. Tempt will not be responsible for any kind of skin allergies/Rashes or any damage or loss or data arising due to direct or indirect usage of the products.

Our Co-ordinates

Call : 7391008008

E-mail : customercare@temptindia.com

Website : www.temptindia.com

