

THE HEIGHT EXTENDER (TOP) ADD-ON ASSEMBLY INSTRUCTIONS

CONTENTS

Warnings		 	 	Page 1
Load Rating		 	 	Page 3
Dimensions		 	 	Page 4
Assembly Tips		 	 	Page 5
Inventory		 	 	Page 7
Assembly Instructions		 	 	Page 8
Pre-Installation		 	 	Page 8
Height Extender frame Installation	n	 	 	Page 13
Maintenance		 	 	Page 17

WARNING

PLEASE CAREFULLY READ ALL INFORMATION CONTAINED IN THIS ASSEMBLY MANUAL BEFORE YOU INSTALL AND USE YOUR FUNKY MONKEY BARS®.


SAFETY NOTICE

- 1. Any person handling or using the Funky Monkey Bars® products must follow the instructions as described in this document. The person in charge of assembling and using the equipment must ensure that the recommendations for use given in this document are seen by all users.
- 2. Only use the Funky Monkey Bars® after they have been fully assembled and after checking that the fittings are tightened properly (refer to page 5 Correct Tightening Method).
- 3. DO NOT install your Funky Monkey Bars® over concrete, asphalt, packed earth, wood decking or any other hard surface. A fall onto a hard surface can result in serious injury or death.
- 4. Inspect all grub screws, bolts and nuts at the beginning of each play session to ensure your Funky Monkey Bars® are tight and secure.
- 5. Ensure all tubes are fully inserted into fittings until you hear the magic "CLUNK" sound.
- 6. Ensure your Funky Monkey Bars® are properly secure at ALL times. Pegs are in place and inserted fully into the ground.
- 7. DO NOT exceed the maximum load/weight limit as recommended by Funky Monkey Bars®.
- 8. Children should be supervised by an adult at all times.
- 9. Installing a gym/crash mat under the fall zone area of your Funky Monkey Bars® would be recommended for children learning this new skill. This will reduce the chance of injury and build the child's confidence while they build strength and master the skill.
- 10. Ensure you have thoroughly read your assembly and installation instructions and viewed our on-line installation videos at https://www.funkymonkeybars.com/blogs/installation-maintenance-videos
- 11. DO NOT climb, sit or stand on top of the monkey bar (horizontal ladder) section.
- 12. DO NOT jump from the top of any section of the monkey bar.
- 13. DO NOT use your Funky Monkey Bars® when wet as the steel will be slippery.
- 14. DO NOT attach items to your frame that are not designed specifically to be used with Funky Monkey Bars®, especially lower quality products that have not been approved by Funky Monkey Bars®.
- 15. Ensure the height of your Funky Monkey Bars® (horizontal ladder) are set at a level that is age appropriate.
- 16. DO NOT install your Funky Monkey Bars® over or near objects that could interfere with users in an unsafe way. Maintain a clear area around your Funky Monkey Bars®.
- 17. DO NOT use your Funky Monkey Bars® while under the influence of drugs and alcohol.
- 18. Wear clothing free of drawstrings, hooks, loops or anything that could get caught while using your Funky Monkey Bars® and result in entanglement and/or strangulation.


ASSEMBLY

- 1. Keep small children away from the Funky Monkey Bars® during assembly.
- 2. Do not attempt to use the Funky Monkey Bars® until it is completely assembled and every fitting is tight
- 3. Installation typically takes 1-2 hours to complete. Two people are recommended for assembly.
- 4. Ensure all fittings are tightened to the correct tightening method as described on page 5.
- 5. Assembly should be carried out on clean, dry, level surface


Please refer to the video section on the Funky Monkey Bars® website for more handy tips and assembly instructions at http://www.funkymonkeybars.com/pages/videos







Heavy items!



Work on flat level surface.

LOCATION

- 1. A safe fall zone around your Funky Monkey Bars® is essential. A minimum distance of 1.5m to 2m (5 ft to 6.5ft) is recommended around the elevated hanging points of your Funky Monkey Bars®.
- 2. Place your Funky Monkey Bars® on level ground, away from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires and remove any obstructions beneath your Funky Monkey Bars®.
- 3. Ensure your Funky Monkey Bars® are positioned away from retaining walls, pool fences, structures and other play equipment. Maintain a clear space around the whole perimeter of your Funky Monkey Bars®.
- 4. Place your Funky Monkey Bars® on the most level surface available.

MAINTENANCE

- 1. At the beginning of each heavy play session we recommend the following maintenance processes be performed on your Funky Monkey Bars®:
 - Tighten all bolts, grub screws and applicable hardware (as per page 5)
 - Lubricate all metallic moving parts as per instructions (flying fox, swing hooks etc)
 - Check all protective coverings on bolts, pipes, edges and corners. Replace if they are loose, cracked or missing.
 - Check all moving parts including swing seats, shackels, snap hooks, chains and trolleys for wear, rust, or other deterioration. Replace as needed.
- 2. Twice a month during play season we would recommend the following maintenance processes be performed on your Funky Monkey Bars®:
 - Tighten all connections and hardware
 - Check all protective coverings on bolts, pipes, edges and corners. Replace if they are loose, cracked or missing.
- 3. Once a month during play season we would recommend the following maintenance processes be performed on your Funky Monkey Bars®:
 - Lubricate all metallic moving parts as per instructions (flying fox, swing hooks etc). If swings start
 to squeek then lubricate swing hooks.
 - Check all moving parts including swing seats, ropes, chains and trolleys for wear, rust, or other deterioration. Replace as needed.
 - Owners shall be responsible for maintaining the legibility of any warning labels.

For additional information concerning your Funky Monkey Bars®, please contact our customer service team or check our website for any important updates. Phone - 1300 912 198 or www.funkymonkeybars.com

OUALITY & INDEPENDENT TESTING

At Funky Monkey Bars® we take the quality of our designs and safety very seriously. All Funky Monkey Bars® frames go through a stringent, independent structural testing process prior to being made available for release to our customers.

Our frames are designed within the parameters of the Australian Standard for Playground Equipment AS4685.1:2014.

The structural integrity of our frames has been tested for performance through a combination of engineering calculations and physical testing. The tests have been performed by independent, certified structural engineers in accordance with Australian Standard for Playground Equipment AS4685.1:2014 and European Standards EN1176-1:2008.

The independent testing conducted on The Height Extender (Top) certified the frame to a load rating of 1098kgs or 18 users of 61kgs when installed on The Orangutan and 1342kg or 22 users of 61kgs when installed on The Gorilla. The maximum number of users on The Height Extender (Top) is to be 3 users (180kgs)

LOAD TESTING CERTIFICATION								
DATE OF TEST	MODEL	NUMBER OF USERS	USER LOAD (KG)	LOAD RATING (KG)				
18 April 2019	Height Extender (Top) on Orangutan	3	60	180				
21 June 2019	Height Extender (Top) on Gorilla	3	60	180				

I hereby confirm all testing was undertaken in accordance with Physical Testing of Structural Integrity requirements of AS 4685.1: 2014 App C / EN 1176-1:2008° except where noted below;

COMMENTS:


Maximum of 3 users on Height Extender accessories bar, (180kgs)


APPROVED BY: Funky Monkey Bars® WITNESSED BY: Independent Engineer

APPROVED

DATE: 21 June 2019 **DATE**: 21 June 2019

FUNKY MONKEY BARS® HEIGHT EXTENDER (TOP) OVERALL DIMENSIONS










CORRECT INSERTION INTO FITTINGS - (INDICATIVE DIAGRAM SHOWN)

All tubes must be fully inserted until contact is made with adjoining tube.






CORRECT TIGHTENING METHOD OF GRUB SCREWS - (INDICATIVE DIAGRAM SHOWN)




With long end of the allen key, hand tighten grub screw as much as possible.







2. Using other end of the allen key do one full 360 degree turn as a minimum, use muscles!











1x 8mm Allen key (Included) 1x Soft Hammer (Not included) 1x 17mm Rachet (Not included) 1x Spirit Level (Not included) 1x
Tape Measure
(Not included)

3m Step Ladder (Not included)


TUBES

4x 600 Extender Tube 50Dia. x 600mm

2x Cargo Tube 50Dia. x 1040mm

1x Accessories Tube 50Dia. x 2950mm


FITTINGS




 2x
 2

 Long Short Tee
 Straight

 D-101L
 D



2x Straight Through D-119





Extra Long Tee D-104L

One of the best things about a Funky Monkey Bar is the ability to add new equipment and accessories as your child and family grows. You can swap or add accessories to your existing frame, or add extra frames that will give you more versatility to attach equipment. Check out what we've got in store now at...

WWW.FUNKYMONKEYBARS.COM

SELECT THE LOCATION FOR THE HEIGHT EXTENDER (TOP) - (GORILLA MODEL SHOWN)








Remove base plate pegs from swing legs and twirly whirly bars on selected side.


3. Loosen grub screws connecting the swing legs to the swing bars on both ends of the selected side.

2 LOWER LEGS AND REMOVE ACCESSORIES & ELBOWS













6 RE-ATTACH SWING HOOKS - (IF APPLICABLE)













10 INSERT EXTENDER TUBES X4




Insert extender tubes and leave hand tight whilst installing extender frame.







13 INSTALL TOP ACCESSORY FRAME



FULLY TIGHTEN ALL FITTING GRUB SCREWS

3. Don't forget to tighten all loose extender tube fittings.









- 1. Ensure top assembly frame is square and level.
- 2. Firmly tighten all grub screws and bolts.

14

15 LOAD YOUR TWIRLY WHIRLY BARS X2





16

ATTACH ACCESSORIES (IF APPLICABLE)




Attach new and existing accesories in desired position if applicable and tighten swing hook bolts with rachet. Existing accessory: (trapeze shown) Existing accessory: (sling swing shown)

17 FINAL CHECKS








- 1. Ensure frame is square and level.
- Firmly tighten all grub screws and bolts.
 All base plates are pegged down.

18

MAINTENANCE.






At the beginning of each heavy play session (especially a party) and twice a month during play season ensure;

- 1. Tighten all hardware grub screws, nuts and bolts.
- 2. Pegs are in place and fully secure.
- 3. Lubricate all metallic moving parts with WD40 or vasaline (trolley and swing hooks.)
- 4. Ensure your frame is level and square.

FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY OR DEATH.

FOR MORE INFORMATION AND ASSEMBLY TIPS PLEASE REFER TO OUR WEBSITE VIDEO INSTRUCTION SECTION AT HTTP://WWW.FUNKYMONKEYBARS.COM/PAGES/VIDEOS

19 HAVE FUN





ABN







72 164 496 520

1300 912 198

info@funkymonkeybars.com

www. funkymonkeybars. com

9 Cutting Way, **Yangebup** WA 6164





