## **Contactors and Contactor Assemblies 3RT1** Contactors

**Accessories for contactors** 

## Selection and ordering data

SIRIUS

10 00 00 00 00 00 00 00 00 00 00 00 00 0						13 II		2000			
3RH19 21-1F	3RH19 21-2F		3RH19 21-1C		19 21-1C .	3RH19 21-2C		3RH19 21-1LA		3RH19 21-1MA	
For contactors	Rated operational Auxiliary contacts current <sup>2</sup> )					Screw connection		Cage Clamp connection		Weight approx.	Pack.
	NEMA A600 / Q600	Ident. no.	Design	Ś	7	Order No.	List Price \$	Order No.	List Price \$		
Туре			NO NC	NO	NC					kg	
Auxiliary swi acc. to EN 50	itch blocks for sna ) 005	apping	onto the	front							
Sizes S0 to S	<b>512</b> 1)										
	4-pole auxiliary sw	itch bloo	cks								
3RT10 2, 3RT1. 3 to 3RT1. 7, 3RT11		40 31 22 04 22 U	4 – 3 1 2 2 – 4 – –	- - 2	- - 2	3RH19 21-1FA40 3RH19 21-1FA31 3RH19 21-1FA22 3RH19 21-1FA04 3RH19 21-1FC22	1 2 1	3RH19 21-2FA40 3RH19 21-2FA31 3RH19 21-2FA22 3RH19 21-2FA04 3RH19 21-2FC22		0.065	1 unit
	Single-pole auxilia	ry switcl	h blocks a	cc. to	EN 50 00	5 and EN 50 012					
3RT1. 2 to 3RT1. 7, 3RT11		- - -	1 – – 1 – – – –	- - 1 -	- - 1	3RH19 21-1CA10 3RH19 21-1CA0 3RH19 21-1CD10 3RH19 21-1CD10	1 0	3RH19 21-2CA10 3RH19 21-2CA01 - -		0.015	1 unit
	2-pole auxiliary sw • Cable entry from		cks with c	able e	ntry from	one side					
3RT10 2, 3RT1. 3 to 3RT1. 7, 3RT11		- - -	1 1 2 – – 2		-	3RH19 21-1LA11 3RH19 21-1LA20 3RH19 21-1LA02	0	- - -		0.065	1 unit
JIII	Cable entry from	below									
		_ _ _	1 1 2 – – 2	-	- - -	3RH19 21-1MA1 3RH19 21-1MA2 3RH19 21-1MA0	0			0.065	1 unit

EN50005 and EN50012 designate the markings For position of the terminal numbers. For position of the terminals see pages 2/166-169. For int. circuit diagrams see pages 2/156-160. 1) Exception: 3RT16.

2) UL ratings, Appendix page 19/7.