

Tranya Sports Earbuds

User Manual





V20221107

PACKAGE LIST

















Type-C Charging Cable * 1

1

IMPORTANT NOTES

- Register your product on tranya.com to get an EXTRA three-month warranty for free.
 Before using the X5 wireless earbuds, please charge both the case
- and earbuds.
- 3 Three pairs of rubber eartips. Please choose the best for you.





- If both earbuds don't sync together, please reset the earbuds.
 If the earbuds don't charge, please clean the charging slot on the case and the contact surface on the earbuds.



If the sound becomes low without control, please use tweezers to take out/remove the net inside the earbuds.



TOUCH CONTROL

Play/Pause



Tap one time(L/R)





Tap 3 times(L/R)





Tap twice(L/R)

Activate Siri/other voice control software



Touch and hold for 1 second (L/R)



Tap one time(L/R)

Reject/End a call



Touch and hold for 1 second(L/R)

Game Mode





Tap 4 times(L/R)

2

POWER ON





Manually

POWER OFF















Manually

Note: When the charging case is at low battery or out of power, the earbuds will not automatically power on/off, please turn them on/off manually.

WEARING








2 Rotate the earbuds till the end of the ear hook is inserted behind the ear.

CONNECT THE EARBUDS







2 Select "X5" and confirm.

CHARGING











3

HOW TO RESET THE EARBUDS

If your earbuds stop syncing with each other, please follow below steps to reset the earbuds:

1 Put both earbuds back into the charging case.



2 Touch and hold BOTH earbuds 8s until BOTH blue lights blink 3 times.



3 The earbuds will sync together and enter the pairing mode automatically.

FAQ

Q: Why does signal interruption occur in some places, such as along the railway and the airport?

A: There are usually lots of underground cable lines along the places mentioned above, which might cause electromagnetic interference and result in a signal interruption.

Q: My earbuds don't charge, what can I do?

A: Please try to follow below steps:

1. Clean the charging slot 2. Clean the charging on the charging case.





Q: Why won't my earbuds power on/off automatically?

A: The earbuds would not power off automatically when the case is at a low battery or out of power. Please recharge the case. And you can long touch for 4 seconds to power on and long touch for 4 seconds to power off the earbuds.

Q: Will the Bluetooth mouse cause signal interference?

A: Perhaps. When your Bluetooth mouse and earbuds are connected to the same device, it might happen.