

# — Instruction Manual —

# BA68U



## DuraSkin® Backboard Padding Installation Instructions

Quantities for 2 Backboards


Customer Service  
(800) 247-7668

PARTS LIST					
Item	Qty	Description	Item	Qty	(Tools Required) Description
1	4	Molded Backboard Padding		x	Portable Drill with 5/16" drill bit
2	16	1/4 - 20 x 1" long bolts		x	Masking Tape
3	16	1/4 - 20 x 3" long bolts		x	Utility Knife
4	16	1/4 - 20 serrated flange nuts		x	Tape Measure
5	4	Alignment Pins		x	Center Punch


- ◆ Inspect all contents prior to installation. Report any missing parts to dealer immediately.
- ◆ Read all instructions before proceeding.

**Note:** The enclosed Molded Urethane Edge Guards have been designed with a molded in goal relief for clearance of the bottom of rim mount. In situations that the goal relief is not needed, it may be more aesthetically pleasing to mount the goal relief towards the rear of backboard.

- 1) Use a tape measure to mark the center-line of the backboard. Place one of the pads in position on the backboard. Use masking tape to hold it in position for locating the mounting holes. For the best fit, line up the first pad with the center-line and then place the second pad next to the first during step 6.
- 2) Mark the hole locations for the drilled holes.
- 3) Use a center punch to mark the center of the holes. This will keep the drill bit in the center of the marked location.
- 4) At the marked location, use a 5/16" drill bit to drill through the support structure of the backboard.
- 5) Make sure to collect all metal shavings to avoid personal injury or damage to the playing surface.
- 6) Select either the 1" or the 3" bolts and bolt the first edge guard in place. Fit the second edge guard in place, using the supplied alignment pins and repeat steps 2,3,4,5 and 6.



**All hard-  
Failure  
tion pro-**



**hardware.  
every loca-**

**-NOTICE-**  
ware must be replaced with the new provided  
to attach your new backboard padding at  
vided will render the warranty invalid.

**Always use the hole locations towards the rear of the backboard to avoid drilling into the backboard glass!**

### Warning!!!

**DO NOT OVER-TIGHTEN.** Take care when tightening the pads to the frame: over-tightening will cause the padding to pull away from the inserts and cause tearing or separation from the backboard. This is especially important for the side attachments due to the inserts being smaller.