

# — Instruction Manual —

## VOLLEYBALL PORTABLE T BASE

PARTS LIST					
Item	Qty	Description	Item	Qty	Description
A	2	T-Base	D	4	Floor Anchors (VB25FL) (packaged separately)
B	2	Sleeve Adapter (if applicable)	E	4	Hold Down Knobs (Installed)
C	2	Post Padding (VB51P)	F	2	Base Padding (VBTBASEP)

- ◆ **Inspect all contents prior to installation. Report any missing parts immediately.**
- ◆ **Read all instructions before proceeding.**

1. *T-Base* (A) may include *Sleeve Adapter* (B). Discard if not needed for your diameter pole.
2. Position *T-Bases* (A) so that the posts are 37 feet apart center to center. Locate *Floor Anchor* (D) positions to align with the center of the rear t-base slots, 17" apart. See Figure 1.
3. Install the *Floor Anchors* (D) into the floor following the instructions provided with the *Floor Anchors* (D).
4. The *Hold Down Knobs* (E) are factory preset, just tighten to the *Floor Anchors* (D), do not over tighten which will lift the front of the *T-Base* (A) off the floor. See Figure 1.
5. Install the *Base Padding* (F) and the *Post Padding* (C).
6. Use instructions provided with posts to complete the installation.

