


EVIE S1 / T1


Urban Warrior Bundle Installation Guide

What's In The Box

Tools




Front rack




What's In The Box

Rear rack




Kickstand




Best Practises

1. Washers should be used with all screws to avoid damaging the joint surface under load.
2. Only use washers of the correct size with the screws.
3. Ensure that the correct screw sizes are used. Improper installation may cause damage or injuries.
4. Always make sure that the bike is **powered off** before performing any installations.
5. We recommend performing installation works in a brightly lit area.
6. Take care when removing any components to avoid damaging the bike.
7. If unsure, contact our support team at support.eviebikes.com for assistance.




Front Rack Installation Guide


01. Install both rods to the front rack using the M5 screws and nuts.




02. Install the support to the underside of the front rack using the M5 screws.




03. Loosen the quick release skewer on the front wheel.




04. Remove the front wheel by detaching it from the fork.




05. Remove the screw from the mudguard mount.




06. Install the rack support over the mudguard mount using the same screw.




07. Install both rods to the bike fork using the M5 screws.



08. Re-attach the front wheel.




09. Tighten the quick release skewer.




Images in this manual may differ from the actual product.

Rear Rack Installation Guide


01. Remove the cable tie clip on the bike frame. Make sure to store it safely for later use.




02. Gently unplug the cable running along the frame.




03. Remove the rubber caps on both sides of the rear wheel. Make sure to store them safely for later use.




04. Loosen the nuts on both sides of the rear wheel. You do not need to remove the nuts completely.




05. Remove the rear wheel by detaching it from the frame.





06. Install the rear rack to the bike frame using the M5 screws.




07. Install the M6 screw to fasten the rear rack to the mudguard support.




08. Re-attach the rear wheel. If the nut was removed, carefully assemble it back in the order shown.




09. Tighten the nuts on both sides of the wheel.



10. Cover the nuts with the rubber caps on both sides of the wheel.




11. Carefully re-connect the cable. Use the arrow markings on the cables to align the connectors. Re-attach the cable tie and use it to clip the cables.




Kickstand Installation Guide


01. Align the kickstand to the mounting holes on the rear wheel.



02. Attach the kickstand using the M6 screws.



The Front Rack




Carry goods easily with the handy front basket.

Always make sure to secure items in the basket properly and avoid overloading it to maintain balance and safe riding conditions.

Do not exceed 9 kg load.

The Rear Rack




Carry extra items with the versatile rear rack. Can be used to mount panniers and bags for more storage.

Always make sure that the load is properly balanced and items secured.

Do not exceed 25 kg load.

Do not use as a passenger seat or child carrier without a child seat.

The Kickstand



Park your bike conveniently and keep it steady while loading or unloading items.

The kickstand is designed to support the weight of the bike only.

Do not use the kickstand to support your full weight or a fully-loaded bike as it may result in the kickstand bending or breaking in extreme cases.