

Certificate of Conformity

100% Polyester Round Sling



Serial No.	ADS2235433001	Date of MANF	Aug.2022
Working Load Limited	2000 KG	Effective Length	3 M

Manufactured to Comply with EN 1492-2:2000

Stock NO	Color Code	WLL (t)	WORKING LOAD LIMIT (W.L.L)					Multi-set	
			Vertical	Choker	Basket	Basket	Basket	a<45°	a<45°
			M=1.0	M=0.8	M=2.0	M=1.4	M=1.0	M=1.4	M=1.12
8201	Violet	1.0	1.0	0.8	2.0	1.4	1.0	1.4	1.1
8202	Green	2.0	2.0	1.6	4.0	2.8	2.0	2.8	2.2
8203	Yellow	3.0	3.0	2.4	6.0	4.2	3.0	4.2	3.4
8204	Gray	4.0	4.0	3.2	8.0	5.6	4.0	5.6	4.5
8205	Red	5.0	5.0	4.0	10.0	7.0	5.0	7.0	5.6
8206	Brown	6.0	6.0	4.8	12.0	8.4	6.0	8.4	6.7
8208	Blue	8.0	8.0	6.4	16.0	11.2	8.0	11.2	9.0
8210	Orange	10.0	10.0	8.0	20.0	14.0	10.0	14.0	11.2
8212	Orange	12.0	12.0	9.6	24.0	16.8	12.0	16.8	13.4
8215	Orange	15.0	15.0	12.0	30.0	21.0	15.0	21.0	16.5
8220	Orange	20.0	20.0	16.0	40.0	28.0	20.0	28.0	22.4
8230	Orange	30.0	30.0	24.0	60.0	42.0	30.0	42.0	33.6

Authorized Signatory

WARNING

1. Sling Eyes: inspect eyes before each use for damage from hook or pin. Do not use a hook or pin with a diameter greater than the design width of the eye.
2. Protect sling body from sharp edges when rigging. Wear pads to reduce damage to the slings when they come in contact with rough or sharp edges.
3. Inspect all slings before each use. Never use slings that have been damaged or overloaded.
4. Always protect slings with pads and/or wooden blocks around edges of a load.
5. Webbing slings will stretch when loaded.
6. Do not attempt to pull jammed or snagged loads free with a webbing sling or any sling.
7. Before use, select the correct flat webbing or round sling with regard to its application, capacity and the surface conditions of the load.
8. Please examine the condition of the webbings, rings and slings.
9. The permissible capacity of the slings must not be exceeded.
10. Never shorten a sling by knotting.
11. Flat webbings slings and slings must not be placed around sharp edges or rough surfaces, use wear sleeves and edge protectors where necessary.
12. Flat webbing slings should be applied in such a way, that they carry the load over the full sling width.
13. Loads may only be placed on slings if damage is precluded. Do not drag slings from under load, position the sling correctly to ensure easy removal after use.
14. Position slings in such a way, that they hold the load securely.
15. Inchoke lifts, only use flat webbings slings with reinforced eyes.
16. Using flat webbing slings with eyes. The eye opening angle should not exceed 20 degrees at the connecting point.