



AIRPLUSH ERGONOMIC BABY CARRIER User Manual




MIMOSA

Malaysia Importer/Distributor:
Global Product Solutions Sdn. Bhd. (705154-M)
Wisma Pang Cheng Yeap, Lot 5205C,
Jalan Perindustrian Balakong Jaya 1/3,
Taman Perindustrian Balakong Jaya,
43300 Seri Kembangan, Selangor Darul Ehsan, Malaysia
Tel: (60) 03 8940 6638
my.support@globaloutsourcemia.com | mysales@globaloutsourcemia.com

Hong Kong Importer/Distributor:
Trade Solutions Ltd
Unit D, 13A/F, Gemstar Tower, 23 Man Lok Street,
Hung Hom, Kowloon, Hong Kong

Singapore Importer/Distributor:
Global Outsource Solutions Pte Ltd
601 Sims Drive, Pan-I Complex, Singapore 387382
Tel: (65) 6831 5020
info@globaloutsourcemia.com



MIMOSA

1. SAFETY INFORMATION..... 2

2. BABY CARRIER SPECIFICATIONS..... 4

3. BABY CARRIER PARTS..... 5

4. FRONT CARRY INSTRUCTIONS..... 6

5. BACK CARRY INSTRUCTIONS..... 9

6. USING THE HOOD..... 12

7. FOLDING THE BABY CARRIER..... 13

8. CARE INSTRUCTIONS..... 14

Important! Please read all instructions before assembling and using the Baby Carrier. Please keep all instructions for future reference.

- Only use this carrier for children between 15lb (6.8kg) and 45lb (20kg) (minimum 7.7lb (3.5kg) with infant insert).
- Do not use this baby carrier for baby weighing less than 7.7lb (3.5kg) and under 4 months of age until the baby can support his or her own head.
- Always carry your baby facing towards your body in either the front or back carry position. This baby carrier is not designed to be used in an outward facing position. Your baby must face towards you until he or she can hold head upright.
- Check to assure all buckles, snaps, straps, and adjustments are secure before each use.
- Check for ripped seams, torn straps and fabric or damaged fasteners before each use. Do not use the baby carrier if it is damaged.
- Ensure proper placement of baby in carrier including your baby's leg placement.
- Premature infants, infants with respiratory problems, and infants under 4 months are at greatest risk of suffocation.
- Constantly monitor to ensure that your baby's mouth and nose are unobstructed.
- Never unbuckle the waist belt while your baby is in the carrier.
- Ensure the shoulder straps and waist belt are not twisted or tangled when in use. Ensure the front panel is not obstructed or bundled up.
- Always support your baby when adjusting the baby carrier to your fit.
- This baby carrier is not suitable for use during sporting activities, e.g. running, cycling, swimming, skiing, etc.
- Never leave your baby unattended in the baby carrier.
- Never use a baby carrier when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.
- Never wear a baby carrier while cooking and cleaning, holding hot drinks, etc. which involves exposure to a heat source or chemicals.
- Never wear a baby carrier while driving or when being a passenger in a motor vehicle.
- This baby carrier is not a substitution for a car seat.
- Keep this baby carrier out of reach from pets or children when not in use.
- This carrier is only intended to be used with one child at a time.
- Only use this baby carrier for babies.

⚠️ WARNING:

FALL AND SUFFOCATION HAZARD



Fall Hazard – Babies can fall through a wide leg opening or out of baby carrier.

- Adjust leg openings to fit baby’s legs snugly. Make sure your baby’s legs are positioned comfortable and safely secure.
- Before each use, make sure all fasteners (e.g. buckles, snaps, straps and adjustments) are secure at all times.
- Take special care when leaning or walking.
- Never bend at waist; always bend at knees.
- Only use this carrier for children between 15lb (6.8kg) and 45lb (20kg) (minimum 7.7lb (3.5kg) with infant insert).
- Stop use at first sign of damage.


Suffocation Hazard – Babies under 4 months may suffocate in this product if face is pressed tightly against your body.

- Do not strap your baby too tightly against your body.
- Allow room for head movement.
- Keep baby’s face free from obstruction at all times.

2. BABY CARRIER SPECIFICATIONS

Age recommendation	4 months to 20 months	
Weight recommendation	15lb (6.8kg) - 45lb (20kg)	
No. of carry positions	2 carry positions	
	<p><u>Front carry (parent facing)</u> min 15lb (6.8kg) (approx. 4 months) / 7.7lb (3.5kg) (with infant insert)</p> 	<p><u>Back carry</u> min 17lb (7.8kg) (approx. 6 months)</p> 
Material	100% Cotton and/or Polyester Mesh	
Safety	This product complies with ASTM F2236-16A:2016	

3. BABY CARRIER PARTS






Features We Love:

- Extra padding on shoulder straps for your comfort
- Can be used for front and back carrying positions
- Thick waist belt for weight distribution, reduces backaches
- Adjustable chest and waist straps to provide a perfect fit
- Removable sleeping hood
- Front storage pocket for tissues and mobile phones
- Provides an ergonomic M-position seat supporting optimal hip development
- Padded leg-opening for your baby's comfort
- Big belt buckle for added safety





4. FRONT CARRY INSTRUCTIONS

HOW TO WEAR YOUR BABY IN FRONT CARRY POSITION

	<p>1. Fasten the waist belt buckle until you hear a "click". Tighten the waist belt by pulling on the waist belt strap until the waist belt lays close to your body with no gaps.</p>
	<p>2. Position the waist belt so that the panel is centred in front of your body. Hold your baby and wrap his legs around your waist.</p>
	<p>3. Support your baby with one arm and lift the front panel up behind the baby's back.</p>
	<p>4. While still supporting your baby with one arm, slip the other arm into the shoulder strap.</p>





	<p>5. Switch hands and slip the other arm into the other shoulder strap. Always use one hand to support your baby until both straps are securely over your shoulders.</p>
	<p>6. Buckle the chest strap behind your shoulders to secure your baby in the baby carrier.</p> <p>Note: Please have someone help you with this step if you are unable to reach for the buckles.</p>
	<p>7. Adjust the baby carrier by pulling the adjustable straps under your arms forward so that your baby is comfortable and close to your body. The baby carrier should fit snugly around the leg openings, supporting baby's torso. Make sure your baby's bottom is seated deep in the panel, just above the waist belt.</p>




HOW TO TAKE OFF BABY CARRIER IN FRONT CARRY POSITION

	<p>1. Loosen the straps under your arms to take your baby out. Do not unbuckle the waist belt until your baby is removed from the baby carrier.</p>
	<p>2. Lift shoulder strap to bring the chest strap buckle up towards the back of your neck.</p>
	<p>3. Unclip and remove the chest strap buckle with one hand. Ensure that you are still holding on to your baby with the other hand.</p>
	<p>4. Remove the shoulder straps one at a time while keeping one hand on your baby at all times.</p>





5. BACK CARRY INSTRUCTIONS - FROM 6 MONTHS ONWARDS

HOW TO WEAR YOUR BABY IN BACK CARRY POSITION



	<p>1. Fasten the waist belt buckle until you hear a 'click' sound. Tighten the waist belt by pulling on the waist belt strap until the waist belt lays close to your body with no gaps. Position the waist belt so that the panel is centred on the back of your body.</p>
	<p>2. Slip one of the shoulder straps over one arm. Place your baby on one hip. Use your free arm to turn your baby from the side of your hip into the baby carrier.</p> <p>Note: Please have someone help you until you feel comfortable doing this step on your own.</p>
	<p>3. Lean forward slightly to ensure your baby is resting his weight on your back. Use the arm that is in the shoulder strap to secure your baby.</p>
	<p>4. Slip your free arm through the other shoulder strap. Maintain a slight forward lean to help control baby's weight. Always use one hand to support your baby until both straps are securely over your shoulders.</p>

	<p>5. Make sure that your baby's bottom sits deep in the panel just above the waist belt, by pulling the shoulder straps near the top of the panel upwards, while gently bouncing your baby into the baby carrier.</p>
	<p>6. Buckle the chest strap in front of your chest to secure your baby in the baby carrier.</p>
	<p>7. Adjust the baby carrier by pulling the adjustable straps under your arms backwards so that your baby is comfortable and close to your body. The baby carrier should fit snugly around the leg openings, supporting baby's torso.</p>





HOW TO TAKE OFF BABY CARRIER IN BACK CARRY POSITION



	<p>1. Lean slightly forward, loosen the straps under your arms and unclip the chest strap while securing the baby with the other hand.</p>
	<p>2. Support your baby with one hand while removing a shoulder strap from one arm.</p>
	<p>3. While supporting your baby, remove the shoulder strap from the other arm.</p>
	<p>4. Slide your baby from your back to one side of your hip.</p>

6. USING THE HOOD

	<p>1. Attach the removable sleeping hood onto the baby carrier by fastening the bottom of the hood to the snaps located near the top of the front panel.</p>
	<p>2. Fasten one of the snaps on the hood straps to the snap located on the shoulder straps to cover and help support your baby's head while he is sleeping.</p> <p>Note: Do exercise caution while using the hood with smaller babies. Please ensure that the hood is not completely covering baby's face and that there is enough opening for your baby to breathe. Always check on your baby while using the hood with the baby carrier.</p>

7. FOLDING THE BABY CARRIER

	<p>1. Lay the baby carrier out flat with the inside of the baby carrier facing towards you.</p>
	<p>2. Fold the shoulder straps in half.</p>
	<p>3. Fold one of the halved shoulder straps to align with the top of the panel.</p>
	<p>4. Do the same for the other shoulder strap.</p>

	<p>5. Hold on to both shoulder straps and begin carefully rolling the shoulder straps along with the carrier panel until you reach the waist belt.</p>
	<p>6. Once you have reached the waist belt, fasten the waist belt buckle across the rolled up portion until you hear a 'click'.</p>

8. CARE INSTRUCTIONS



Machine wash cold.
Gentle cycle.



Do not bleach.



Do not tumble dry.



Do not iron.



Do not dry clean.

- Spot clean with gentle soap and water.
- Machine wash using a laundry bag; when necessary (use cold water) and air dry.
- Avoid drying in direct sunlight.
- Do not use detergents with bleach, perfumes, dyes, chlorine or optical brightener.