

## USER GUIDE

### RF LED Dimmer Controller

**EMIT**EVER  
lighting




#### WHAT YOU GET:

RF Remote	1
RF Receiver	1
Installation Tape	1


#### TECHNICAL PARAMETERS:

- Working temperature: -20-60°C
- Input voltage: DC5~24V
- Output voltage: DC5~24V
- Net weight: 45g
- RF frequency: 433.92Mhz
- Outout current: 4A Max
- Output power: 5V<30W 12V<72W 24V<144W
- Available for: Single color
- Controller size: L64\*W31\*H15mm
- Remote size: L86\*W39.5\*H7.5mm


#### CONNECTION:



#### RECEIVER:



#### REMOTE:



Remember to remove the plastic tab


#### ATTENTION:

1. Controller's input voltage is DC5-24V, other input voltage are not allowed, Please do not overload, the total max output current is 6A;
2. Please connecting the power input and LEDs in power off, and power on in correct connection.
3. Please don't reverse the power input connection of both cathode and anode, please switch on again only when it is in right connection and no short circuit.
4. Please power off the device if you don't use it for a quit long time, don't place in high dust, high temperature environment..

**Thanks for choosing Emitever!**

## Customer Service

 Support: Lifetime Technical Support

 [service@emitever.com](mailto:service@emitever.com)