

J3L316



Because it's a narrow cabinet, it must permanently be fixed to the wall with included anti-tipping device to prevent the cabinet from tipping over. It will be very stable and safe when locked on the wall.


Please see step 11 for steps to lock the wall.

As this item contains many parts, please read the installation instruction carefully before installation. Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

hosoteservice@gmail.com

Our professional after-sales team will serve you online all day.

Before You Start




- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints


PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




Board Identification


Not actual size




TOP PANEL
Qty:1




LEFT SIDE PANEL
Qty:1




RIGHT SIDE PANEL
Qty:1




DIVIDER PANEL
Qty:1




SHELF PANEL
Qty:1




BACK BRACE
Qty:1




BOTTOM PANEL
Qty:1




SUPPORT BAR
Qty:1




UPPER BACK PANEL
Qty:1




LOWER BACK PANEL
Qty:1




DOOR
Qty:2




**SHOE BOX
BOTTOM PANEL**
Qty:2




SHOE BOX LAYER
Qty:4




**LEFT DRAWER
FRONT PANEL**
Qty:1




**RIGHT DRAWER
FRONT PANEL**
Qty:1




**DRAWER LEFT
SIDE PANEL**
Qty:2



**DRAWER RIGHT
SIDE PANEL**
Qty:2




























DRAWER BACK PANEL
Qty:2



DRAWER BOTTOM PANEL
Qty:2

Part List


 $\Phi 7.8 \times 30$ (A) x18 WOOD DOWEL spare:2	 $\Phi 15 \times 11$ (B) x28 CAM LOCK spare:3	 $\Phi 6 \times 35$ (C) x36 CAM BOLT spare:3	 (D) x4 SLIDE	 $\Phi 7 \times \Phi 3.5 \times 12$ (E) x12 SCREW spare:2
 $\Phi 7 \times 38$ (F) x2 SCREW spare:1	 M4 (G) x1 ALLEN KEY	 (H) x4 PLASTIC PIN	 (I) x2 METAL CORNER	 $\Phi 8 \times \Phi 4 \times 12$ (J) x6 SCREW spare:1
 $\Phi 8 \times 3.5 \times 12$ (K) x32 SCREW spare:3	 (L) x2 WALL ANCHOR	 $\Phi 8 \times \Phi 4 \times 60$ (M) x2 SCREW	 N1 N2 (N1) x2 (N2) x2 LEFT RIGHT	 $\Phi 7 \times \Phi 3.5 \times 20 \text{mm}$ (O) x12 SCREW spare:2
 $\Phi 6 \times \Phi 3 \times 16 \text{mm}$ (P) x12 SCREW spare:2	 (Q) x2 HANDLE	 (R) x4 CIRCLE AXIS	 $\Phi 8 \times \Phi 4 \times 14 \text{mm}$ (S) x4 SCREW spare:1	 $\Phi 8 \times \Phi 4 \times 30 \text{mm}$ (T) x8 SCREW spare:1
 $\Phi 15 \times 9$ (U) x8 CAM LOCK spare:1	 (V) x2 HANDLE	 M4x10 (W) x2 BOLT	 (X) x4 DRAWER STOPPER	 (Y) x1 SCREW DRIVE

Part List


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.


1



2




3




The opening must point toward the edge of the board

4








Board Identification





Not actual size



STEP1












STEP2






Proper orientation of CAM LOCK

STEP3




STEP4






			
$\Phi 7 \times 38$		M4	
F	x2	G	x1







STEP5



STEP6




STEP 7





Proper orientation of CAM LOCK




STEP8







STEP9



STEP10




STEP11





Cabinet must permanently fixed to the wall with included anti-tipping device to prevent the cabinet from tipping over.


- .Mark the drill position on the wall with a pencil.
- .Drill holes on the marked position using a bit.
- Gently insert the wall anchor (L) into the drilled hole with the help of a hammer.
- .Fixed the cabinet to the wall with provided screws (M).





STEP12






	
N1	x2

	
N2	x2

	
Ø7xØ3.5x20mm	
O	x4






STEP13




x 2





STEP14







 Ø7xØ3.5x20mm	
	x4






STEP15







STEP16
















STEP17



STEP18






STEP19



Proper orientation of CAM LOCK

STEP20



Attention: Drawer 14 is on the left and drawer 15 is on the right.

STEP21

