

## SET UP INSTRUCTIONS 3526 – 41" OPEN CROSS FOUNTAIN

Open the bag containing the pump kit P13019. In the kit you will find:

1 - 40160 (160 gallon per hour pump) 1 - 2-hole rubber stopper 1 - hose clamp

1 –1/2" clear tubing 13" long 1 - LED light kit (WHITE) 1 – tube of silicone

- 1. Place the fountain base on a firm and level area where the fountain will remain. On a padded surface tip the fountain base on its side. Position the groove in the bottom of the fountain base facing towards the electrical outlet.
- 2. Located inside the fountain base and centered in the floor there is a PVC insert. Remove any tape and or dirt from inside the PVC insert before you insert the rubber stopper. Find the pump and the LED light and run the plug end on both power cords down the PVC insert. Leave about 24" of slack on both power cords inside the fountain base.

Find the 1/2" clear tubing and cut to 7 1/2" long. Attach one end of the 1/2" clear tubing to the outlet of the pump with the hose clamp. Adjust the dial type flow control located on the front of the pump to the 4 to 5 o'clock position.

3. Find the 2-hole rubber stopper and the tube of silicone. Fill both holes in the rubber stopper with silicone. Slip the rubber stopper onto the power cords about 12" from the body of the pump and about 14" from the LED light with the smaller end of the rubber stopper facing away from the pump and the LED light.

Apply silicone around the inside edge of the PVC insert located in the floor inside the fountain base and the outside edge of the rubber stopper. Retrieve both power cords from under the fountain base and place both in the groove running out the back of the fountain. Insert the rubber stopper snugly into the PVC insert. Tip the fountain base back into position in the area where the fountain is to be displayed. Apply more silicone on top and around the rubber stopper and the power cords. **Don't skimp on the silicone you want a watertight seal.** 

- 4. Attach the 1/2" barb fitting on the LED light to the opposite end of the 1/2" clear tubing.
- 5. Find the open cross finial and place it in the fountain base. Carefully tip the open cross finial enough to get your hand into the fountain base and feed the LED light head into the hole that is in the middle of the open cross finial.
- 6. Fill the fountain base with about 6" of tap water. Connect the power cord on the LED light to the transformer. Plug the power cord of the pump and the LED light transformer into a 110VAC GFCI protected outlet. If necessary, adjust the water flow using the dial type flow control located on the front of the pump

3526sup 6/21/17