

## SET UP INSTRUCTIONS 3695 76" PAVASA FOUNTAIN 3707 66" PAVASA FOUNTAIN

Open bag containing the pump kit **P40008**. In the kit you will find:

- 1 40400 (400 gallon per hour pump)
- 1 48" long piece of 3/4" clear tubing
- 1 5" long piece of 1" clear tubing

1 - rubber stopper

- 1. Place the pedestal base on a firm and level surface where fountain will remain. Place the pedestal on the pumphouse base and level. To level pedestal, place level on the top rim of the pedestal. Level in (2) Two directions left to right and front to back. Shim as needed. Place the largest shell on the pedestal.
- 2. Find the pump, the piece of 3/4" clear tubing 48" long and the rubber stopper. Attach the piece of 3/4" clear tubing 48" long onto the outlet side of the pump. Place pump in the pump house in the center of the shell and run the plug end of the electrical cord down the PVC pipe in the pump house and down into the pedestal base. Retrieve cord from inside the pedestal base. Run the power cord out on the left side and position the pedestal base plug in the pedestal base. Slip the rubber stopper onto the power cord about 15" from the pump with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house.
- 3. Position the largest shell on pedestal and level. To level shell, place level on the top rim of the pump house in the center of shell. Level in (2) Two directions left to right and front to back. Shim as needed.
- 4. Find the spacer. Run the 3/4" clear tubing through the center hole in spacer. Position the spacer on top of pumphouse in center of shell and level as stated in step #3.
- 5. Find the second shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position shell on top of the spacer and level. To level shell, place level on the outside rim of the shell. Level as stated in step #3.
- 6. This step is for the #3707 66" PAVASA FOUNTAIN

Cut the 3/4" clear tubing 10 1/2" above the top surface of the center housing on the second shell. **Find the piece of 1**" clear tubing 5" long. Slip the 3/4" clear tubing all the way into the 1" clear tubing until both ends are even. Find the finial. In the center of the finial you will see a PVC pipe. Insert the 1" clear tubing into the PVC pipe in the bottom of the finial and slide the finial down onto the center housing of the second shell. Position the finial on the fountain. **Go to step #8.** 

## 7. This step is for the #3695 76" PAVASA FOUNTAIN

Find the third shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position shell on top of the second shell and level. To level shell, place level on the outside rim of the shell. Level as stated in step #3. Cut the 3/4" clear tubing 9" above the top surface of the center housing on the third shell. Find the finial. In the center of the finial you will see a PVC pipe. Insert the 3/4" clear tubing into the PVC pipe in the

bottom of the finial and slide the finial down onto the center housing of the second shell. Position the finial on the fountain.

- 8. Find the drain plugs and insert snugly into the drain inserts located in the two shells of the fountain. Remove any tape and or dirt from the drain insert before you insert the drain plug.
- 9. Fill shells with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the finial using the dial type flow control located on the front of the pump until the desired result is achieved.