



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3710 80" THREE TIER PETAL LEAF FOUNTAIN

Open bag containing the pump kit **P40008**. In the kit you will find:

- | | |
|---|----------------------|
| 1 - 40400 (400 gallon per hour pump) | 1 - rubber stopper |
| 1 - 48" long piece of 3/4" clear tubing | 1 - tube of silicone |
| 1 - 5" long piece of 1" clear tubing | |

1. Place the pumphouse base on a firm and level surface where fountain will remain. Place the pedestal on the pumphouse base and level. To level pedestal, place level on the top rim of the pedestal. Level in (2) Two directions left to right and front to back. Shim as needed. Place the largest shell on the ground near the pedestal.
2. Find the pump and the rubber stopper. Place pump in the center of the large shell and run the plug end of the power cord down the hole in the center of the shell. Retrieve the power cord from under shell. Run the power cord down the hole that is through the pedestal into the pumphouse base. Retrieve the power cord from inside the pumphouse base. Run the power cord out on the right side of the opening and position the pumphouse base plug in the pumphouse base. Place the largest shell on the pedestal. While placing the shell on the pedestal carefully pull the remainder of the power cord until all is hidden inside the fountain. Slip the rubber stopper onto the power cord about 15" from the pump. Insert the rubber stopper snugly into the hole in the center of the shell.
3. Position the largest shell on pedestal and level. To level shell, place level on the floor of the shell. Level in (2) Two directions left to right and front to back. Shim as needed.
4. Find the pumphouse spacer. Carefully position the pumphouse spacer in the center of the large shell and level. To level the pumphouse spacer, place the level on the top of the pumphouse spacer. Level as stated in step #3.
5. Find the second shell. Position shell on top of the pumphouse spacer and level. Level as stated in step #3.
6. Find the third shell and the tube of silicone. In the bottom of the third shell you will see PVC pipe. Clean this PVC pipe as best as you can. Remove any tape and or excess concrete from this PVC pipe. Apply the clear silicone around the outside surface of the PVC pipe. In the middle of the second shell there is a hole. Apply the clear silicone around the inside of the hole. Carefully line up the PVC pipe in the bottom of the third shell with the hole that is in the center of the second shell and insert the PVC pipe into the hole. Rotate the third shell 45 degree so silicone will seal the two shells together.
7. Find the piece of 3/4" clear tubing 48" long. Run one end of the 3/4" clear tubing down the hole that is in the center of the third shell down into the large shell. Reach into the opening in the pumphouse spacer and connect the 3/4" clear tubing to the outlet of the pump. Cut the 3/4" clear tubing 9" above the top surface of the center housing on the third shell.
8. Find the finial. In the center of the finial you will see a PVC pipe. Insert the 3/4" clear tubing into the PVC pipe in the bottom of the finial and slide the finial down onto the center housing of the second shell. Position the finial on the fountain.
Find the pumphouse spacer plug and install into the opening in the pumphouse spacer.
9. Find the drain plugs and insert snugly into the drain inserts located in the two shells of the fountain. Remove any tape and or dirt from the drain insert before you insert the drain plug.
10. Fill shells with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the finial using the dial type flow control located on the front of the pump until the desired result is achieved.