

Have someone help you with measurements. Measurements should be taken from the front. Look forward and stand up straight with your feet about 12 inches apart. Take measurements in street clothes. DO NOT make allowances for insulation layers under the suit. Kokatat patterns are designed to allow for adequate layering under dry suits. All circumferences should be taken at the widest point. Provide measurements in your preferred unit of measurement and we will make conversions.

HEIGHT:

WEIGHT:

SHOE SIZE: (indicate Women's or Men's)

NECK:

WRIST:

CALF: Measure around widest point of calf

CHEST: Take this measurement at the widest point. This is usually at the nipple area. Do not hold your breath, just relax. If the person is muscular, take a second measurement at the armpit area, across the upper chest. Use the larger of the two measurements.

WAIST: At the widest point, usually across the navel. Relax and breathe normally.

BELLY: For men, we also need your belly dimension (at largest place between belt and chest, or say "less than waist" if slim there).

HIPS: For women, we also need your hip dimension (Be honest or you'll be miserable.). Take this measurement from the side to ensure the correct placement of the tape. Place the tape around the hips and across the widest point of the buttocks. Make sure that all pockets are empty.

INSEAM: This is also referred to as the "crotch to ankle bone" measurement. Have the person stand with legs straight and feet about 12" apart. Have them hold their hand to the side, with palm facing out. Place the end of the measuring tape between their first two fingers. Ask them to place the hand with the tape in their crotch area, snug up against the body.

GIRTH: This measurement is for the entire torso length. Place the tape at the base of the neck on top of the shoulder. Run the tape down the front, through the crotch and up the back to the starting point on the shoulder.

This final measurement should be taken on the backside:

SPINE TO WRIST: Hold arm directly out to the side, parallel to the floor, palm down. Bend the elbow forward, stop hand in front of nose. Place the tape at the base of the neck, starting at the spine. Run tape along the arm, turn at the elbow, measuring to the wrist bone.

MODEL, MATERIAL, COLOR:

OPTIONS: Front relief (men's or women's) or drop seat (women's only), relief zipper cover, sleeve pockets, suspenders, hood (option for GFE suit only) and reflective tape.

DATE DESIRED: (custom sizing takes extra 4-8 weeks, depending on what's needed, plus shipping)

COMMENTS: