INSTRUCTION GUIDE

CT500 MONITOR

I COPYRIGHT

The contents of this manual are subject to change without notice to improve quality. © 2023 JLL Fitness Ltd

JLL Fitness Ltd owns the copyright for this manual.

Use or reproduction of this manual in parts or entirety without the authorization of JLL Fitness Ltd is prohibited.

CONTENTS

- Safety precautions	p. 4
- Cleaning	p. 5
- Installation	p. 6
- Operation	p. 7
Exiting scan mode	p. 7
Setting target programs	p. 7
Resetting your monitor	p. 7
- Data readouts	p. 8
- Troubleshoot	p. 9
- Contact details	p. 10

SAFETY PRECAUTIONS

The monitor on this machine has been tested to the required standards, each of those passed regulations are shown via the following symbols:

WEEE - Waste Electrical and Electronic Equipment Recycling.

ABS - Acrylonitrile Butadiene Styrene often referred to as ABS is a type of plastic that is an opaque thermoplastic.

CE - The product conforms with relevant EU directives regarding health and safety or environmental protection.

QC Pass - A product which has fulfilled the requirements of a technical control and passed the outgoing exams.

ROHS - This is an abbreviation for "Restriction of (the use of certain) Hazardous Substances in electrical and electronic Equipment".

WEEE Symbol

ABS Recycling Symbol

Quality Control Symbol









I CLEANING

Please take care when cleaning this monitor as the LCD screen can easily be scratched.

You will need a soft dry cloth

Do not spray cleaning chemicals directly onto the monitor

Do not apply water to the monitor as it is electrical and may damage the internal components





IINSTALLATION

STEP 1



Insert the batteries, making sure they are the correct way round.

STEP 3



Connect the male to female wires from the base to the monitor.

STEP 2



Remove the four screws from the back of the

monitor.

STEP 4



Secure the monitor to the base using the four screws previously removed.

OPERATION

The CT500 monitor has a total of 6 readouts, displaying:

TimeSpeedDistanceHeart RateCaloriesOdometerWhen first powered on, the monitor will automatically be in 'Scan' mode. This means the digits in the largest segment
on the screen will change every few seconds between time, distance, speed etc. This will allow you to have an overview
while training without pressing any buttons. When the machine is in use you will also see a cycling icon in the top left
corner, when you stop exercising the icon will disappear.

EXITING SCAN MODE

Press 'MODE' to exit scan mode and continuously press it to view each readout. If you are within scan mode, there will be a scan icon in the bottom left to indicate this.

SETTING TARGET PROGRAMS

On this monitor your are able to set a target **time**, **distance**, **pulse** and **calories**.

- Start by pressing 'MODE' until your chosen setting flashes.
- Then press 'SET' to change the digits to your desired target.
- Once set, begin your workout by pedalling and you will see the digits begin to change.

RESETTING YOUR MONITOR

Press and hold the 'RESET' button until all the digits come up and return to zero,



DATA READOUTS

Readout	Measurement
Time	Minutes : Seconds
Speed	KM/H
Distance	Kilometres
Pulse	BPM (Beats Per Minute)
Odometer	Kilometres

TROUBLESHOOT

Issue	Resolutions
No power to the monitor	 Make sure the batteries are fully inserted and the correct way round. Check your connection wires from the monitor to the base. They must not be trapped, fully connected and the pins must be straight.
No pulse reading	 Make sure the pulse plates are clean and dry. Do not have any lotion on your hands. Sweat can affect the reading. Make sure both hands are fully gripping each plate.

I CONTACT DETAILS

Tel: 0121 328 7507



Live Chat: WWW.JLLFITNESS.CO.UK

@JLLFITNESS 🖬 🎔 💿 in 🕒 🖗

