



NU REPUBLIC

sonicpop 50

wireless speaker



User Manual

1. power on/off

to power on/off, long press the power button and see a RGB light flash.

2. wireless connection

1. to connect with BT, turn on the BT speaker, use the BT function of the mobile phone, scan the speaker and wait for pairing. click connect with model number (NuR_sonicpop 50)

2.it will be automatically connected and saved to pair next time.

3. music play

1. when playing music, short click the power button to pause the music and then click power button again to restart to play,

2. when playing music, press "-" to play the previous song,

3. when playing music, press "+" to play the next song,

4. long press "-" the volume will decrease,

5. long press "+" the volume will increase.

4. mode switch

1.when power on, the speaker will enter wireless BT mode,

2.insert the TF card to automatically enter the TF card playback.

3.click the "*" button to switch the light



5.TWS function:

turn on two speakers at the same time. when they are in BT mode, long press M button. wait for the speakers to connect. final connect with your BT device.

6. radio mode:

Press the "M" button to enter the FM mode. Click the "M" button to search channels automatically. After the searching is completed, press +/- to switch the radio channel.

7. charging

1. the product has built-in non-removable rechargeable battery, which can be charged by c-type cable.
2. when speaker charging, the red light on. lights will be off when it is fully charged
3. repeat charging and discharging will lead to the decline of battery life, which is a normal phenomenon for all possible rechargeable batteries.

8. RGB light:

press "*" button to change the light mode/ turn on and turn off the light

9. calling:

click the power button to answer/hang up the phone call, double click the power button to reject the phone call.

notice:

1. use the product for its intended purpose only;
2. pls store and use this product at room temperature;
3. do not expose this product to rain or wet conditions;
4. do not drop, to avoid the fall of the product damage
5. do not disassemble and repair the product by yourself;
6. the product built-in lithium battery, do not casually discard or put in the fire, so as not to cause danger!

WARRANTY TERMS AND CONDITIONS

- 1.** Nu Republic thanks you for showing confidence in our products and becoming our valued customers.
- 2.** To ensure a delightful product experience, Nu Republic recommends reading the User Manual carefully and contacting our customer care helpline to understand the warranty period and conditions.
- 3.** Nu Republic warrants that the product at the time of its original purchase free of defects in material and workmanship.

This Warranty is subject to following terms:

- 1.** The warranty is given only to the original purchaser of the product
- 2.** The warranty will be applicable for 6 months from date of original purchase or 12 months from date of import as mentioned in the import sticker on the box whichever is earlier.
- 3.** The customer has to present PROOF OF PURCHASE/INVOICE for claiming any warranty.
- 4.** For the entire Warranty Period, Nu Republic or its authorized representative will at their discretion repair or replace defective product. Repair or replacement may involve the use of the same or equivalent reconditioned unit.
- 5.** Nu Republic will return the repaired product or can replace it with another same or equivalent product to the customer in full working condition. All replaced & faulty parts or components will become the property of Nu Republic.
- 6.** The details of the service locations can be taken from our service helpline, It is the responsibility of the Customer to bring the product to the Nu Republic Service Location at his/her own risk and expenses.

7. For any product repaired or replaced during warranty period, the repaired or replaced product shall continue to be within period of the original product.
8. For any product repaired or replaced during warranty period, the repaired or replaced product shall continue to be within warranty period for the remaining time of the original warranty period of the original product.
9. In case a service center is not available at customer location, the customer will have to courier the product to the nearest NuWorld Retail Center Service at his own cost.
10. One way courier cost from Customer to service centers would be borne by Customer & NuWorld will bear the return courier/shipment delivery cost from the service center to Customers across all regions.

Who Pays for What

1. NuWorld will pay all labor and material expenses for all repairs covered by the warranty.
2. The customer is responsible for transporting the product for repair or arranging for its transportation and for payment of any initial shipping charges.
3. NuWorld will pay the return shipping charges if repairs are covered by the warranty.

The warranty will not be applicable under the following circumstances:

- The product code/serial number or warranty seal has been removed, erased defaced, altered or is illegible.
- Deterioration of the product due to normal wear and tear.

- Use other than in accordance with the user manual - rough handling, ingress of/exposure to any kind of liquid (water, sweat, beverages, oils etc.) exposure to moisture, dampness or exposure to extreme environmental conditions, corrosion, unauthorized repairs, use of unauthorized spare parts, accidents, forces of nature or other actions beyond reasonable control of Nu Republic unless the defect was caused directly by defects in material or workmanship.
- The warranty will also not cover any physical damage to surface of the product but not limited to scratches on the body parts.
- Any defects caused by the fact that the battery has been short circuited or by the fact that the seals of the casing have been tampered with or any evidence of tampering or the product is used for equipment other than for which it is certified.
- **INTENDED USE/LIABILITY** - Nu Republic does not accept any liability from any damage arising out of misuse of the product as prescribed by this User Manual.

Process to be followed to claim warranty

- The customer will raise an escalation by mailing hello@nurepublic.co, or call our helpline +918826257630
- The customer will ship the product, the accessories, the original box, and the original sales invoice.
- The After Sales Service Center will receive the product and check the product for any abuse, damage, scratches, breakages wear and tear
- Once approved, the Authorized Service Centre will send a repaired/replacement product free of cost to the customer
- In absence of the same product, a similar product of better value may be offered to the customer.

General Terms

FOR ANY CLAIM UNDER THE WARRANTY IS SUBJECT TO NOTIFICATION TO NU REPUBLIC FOR THE ALLEGED DEFECT WITHIN A REASONABLE TIME OF ITS OCCURRENCE AND NOT IN ANY WAY LATER THAN EXPIRY OF WARRANTY PERIOD. NU REPUBLIC/AUTHORIZED PARTNER WILL NOT BE RESPONSIBLE FOR ANY KIND OF LOSSES DIRECT OR INDIRECT RESULTING DUE TO ANY LOSS OF CUSTOMER DUE TO NON FUNCTIONING. NU REPUBLIC'S OBLIGATION UNDER THIS WARRANTY SHALL BE LIMITED TO REPAIR OR PROVIDING REPLACEMENT OF PARTS ONLY THE MAXIMUM CLAIM ENTERTAINED BY NU REPUBLIC WILL BE SUBJECT TO MAXIMUM RETAIL PRICE OF THE PRODUCT OR PURCHASE PRICE (AS PER INVOICE) WHICH EVER ONE IS LOWER.

In event of any unforeseen circumstances, there is unavailability of certain spare parts, prevailing depreciation rules will be binding on the purchaser to accept as a commercial solution in lieu of repairs

For detailed terms and conditions please visit our website www.nurepublic.co or mail us at hello@nurepublic.co. We are also reachable on our Helpline Number: +918826257630

Working Hours: Monday to Friday 10:30 AM - 6:30 PM (except national and public holidays)



NU REPUBLIC