


STEP 1:


Assemble (3) Post Support Tubes to Cart Base as shown below.
Note: DO NOT tighten completely.



STEP 2:


Assemble Post Clip Assembly to Post Support Tubes using (3) H1-M6X50mm Allen Head Bolts and (3) H4-M6 Flat Washers. Note: DO NOT tighten completely.

Note: DO NOT tighten completely. See step below.




STEP 3:

Assemble Base Support Tube & Plate to Cart Base as shown below.




STEP 5:

Assemble Handle Upper Section to Handle Bottom Section as shown below using H3 - M6X10mm Allen Head Bolt and H4-M6 flat washer.




STEP 4:

Remove H2 Bolt from frame.
Assemble Handle Bottom Section to
Cart Base as shown below using
H2 - M8X100mm Allen Head Bolt.




STEP 6:

For Plastic "Snap In" Post Only:
Align Hand Removal Tool with holes
located in bottom of plastic stanchion
post. Once aligned, push removal
tool inward by hand until stanchion
post disengages from the base.




STEP 7:

The Rover Stanchion Cart is made to hold stanchion post(s) as shown below.



STEP 8:

The Rover Stanchion Cart is made to hold stanchion base(s) as shown below.



STEP 9:

To engage Brake push down with foot. To release Brake lift up.

