

Low-Pro Frame

Assembly Instructions

PN10834 - 4'x4' Low-Pro Frame
 PN10835 - 4'x8' Low-Pro Frame

RECOMMENDED TOOLS



Wrenches or sockets:
 M14 (or 9/16")
 M15 (or 5/8")



Cordless Drill




Work Gloves

A. EACH FRAME PACKAGE COMPONENTS

	Part Number	Description	Qty
L	10835-1	SIDE TUBE	2
M	10835-2	CENTER TUBE	1
N	10835-3	END TUBE	2
O	10835-4	STRINGER TUBE	2
P	10835-5	ANGLE 5	4
Q	10835-6	ANGLE 6	2
R	10835-7	ANGLE 7 (Gusset)	4
	NA	FRAME ASSEMBLY HARDWARE KIT	


B. EACH 4ft FRAME PACKAGE COMPONENTS

	Part Number	Description	Qty
S	10834-1	SIDE TUBE	2
T	10834-2	CENTER TUBE	1
U	10834-3	END TUBE	2
V	10834-4	STRINGER TUBE	1
W	10834-5	ANGLE BRACKET	6
	NA	FRAME ASSEMBLY HARDWARE KIT	




8' Frame Assembly:

Lay out the pieces as shown in the diagram below. Use M10x60mm bolts/nuts, assemble frame using angles.



A. EACH FRAME PACKAGE COMPONENTS

	Part Number	Description	Qty
L	10835-1	SIDE TUBE	2
M	10835-2	CENTER TUBE	1
N	10835-3	END TUBE	2
O	10835-4	STRINGER TUBE	2
P	10835-5	ANGLE 5	4
Q	10835-6	ANGLE 6	2
R	10835-7	ANGLE 7 (GUSSET)	4
NA		FRAME ASSEMBLY HARDWARE	



4' Frame Assembly:

Lay out the pieces as shown in the diagram. Use M10x60mm bolts/nuts, assemble frame using angles. Each angle will work in any position. If tubing is not lining simply flip angle around. Hand tighten until final step.