



### WHAT FOR?

- ✓ Multi-purpose adhesive tape for airtight bonds indoors and outdoors in accordance with DIN 4108, SIA 180 and OENORM B8110-2.
- ✓ Windproof and water tight bonds of subroofs and façades

### WHERE TO APPLY?

pro clima TESCON VANA is used to form a secure and permanent seal of overlaps between foil and fleece membranes (vapour checks and airtightness membranes, roof underlays and wall membranes) and joints between such membranes and smooth, non-mineral surfaces. TESCON VANA is also suitable for sealing butt joints between wood-based panels such as OSB or MDF sub-roof panels.

### ADVANTAGES

A versatile tape for almost any application

- ✓ Durable leak-proof bonding, inside and outside
- ✓ Can also be used for sealing holes
- ✓ High flexibility
- ✓ Easy to tear off by hand

[SEE OVER FOR FURTHER DETAILS](#)

>>

#### Preparation



All surfaces must be stable, dry, smooth and free of dust, silicone and grease. Sweep or vacuum clean and wipe all surfaces.

#### Sealing vapour checks indoors



Place the TESCON VANA centrally over the overlap, unroll and stick down over the joint continuously. Press firmly to secure the tape, ensuring there is sufficient back-pressure.

#### Pressing firmly to secure the tape



The TESCON VANA tape should be applied centrally and pressed down firmly using the pro clima PRESSFIX.

#### Joints to mineral surfaces



Use pro clima CONTEGA SOLIDO SL for reliable joints to gypsum based plaster. Affix fleece to the membrane with tape and use CONTEGA HF to affix it to the masonry at intervals. Embed the reinforcement and the fleece in the middle layer of gypsum based plaster.

#### Details for pipes and cables



Seal all round penetrations with KAFLEX or ROFLEX grommets. KAFLEX grommets are self-adhesive. Stick pipe grommets to the substrate with TESCON VANA to form an air-tight seal. Press firmly to secure the adhesive tape.

#### Details for taping corners



Seal corners using pro clima TESCON PROFIL tape. Remove one strip of the split release paper and press down the first piece. Then remove the second strip of the release paper and press down the second piece.

# TESCON® **Vana**

## Multi-purpose adhesive tape

Taping roof underlay



7  
TESCON VANA is suitable for sealing overlaps of the roofing underlay. Place the tape centrally over the overlap, unroll and stick down over the joint continuously. Press firmly to secure the tape, ensuring there is sufficient back-pressure.

Taping Sub-and-Top membrane



8  
To tape a vapour check used for restoration (e.g. pro clima DASATOP) place TESCON VANA centrally over the overlap, unroll, and carefully position it in the corners, then stick down. Press firmly to secure the tape ensuring there is sufficient back-pressure.

Sealing sarking boards



9  
Sarking boards made from wood-based panels (MDF) can be sealed with TESCON VANA. Place the tape centrally over the butt joint, unroll and stick down over the joint bit by bit. Press firmly to secure the tape. Prime woodfibre boards with TESCON PRIMER RP.

Sealing external junctions



10  
Roof underlay (e.g. pro clima SOLITEX) can be sealed to smooth, non-mineral surfaces such as fl at roof windows using TESCON VANA. Form a underlay gutter above the gap (see 12).

Details for pipes externally



11  
Pull a pro clima EPDM pipe grommet over the pipe and create a water-tight seal between it and the roof underlay using TESCON VANA. Form a underlay gutter above the penetration (see 12).

Details for underlay gutters



12  
Place a strip of underlay in the overlap of the closest uninterrupted roofing membrane and seal to the roofing membrane. Fold the unattached end of the underlay gutter over and affix it to the lathing to drain the moisture to the next section of the roof using an interrupted counter batten.

## COMPOSITION

pro clima TESCON VANA adhesive tape is made of a non-ageing acrylate which is free of solvents or softeners. This, combined with high temperature resistance, ensures a strong, durable bond. The high final strength of the bond is reached within 24 hours.

## SURFACES

All surfaces must be suitable for permanent, airtight adhesion with air sealing adhesive tape, and must be stable, dry, smooth and free of dust, silicone and grease. Adhesion to frozen surfaces is not possible.

Further information about application and construction is given in the pro clima planning documentation.

(Please also take note of the recommendations contained in the current pro clima application matrix.)

Optimum results for the safety of the building are achieved by using high quality vapour checks and airtightness membranes, for example made of PE, PA, PP and aluminium foil, as well as sheathing paper or wood-based panels (e.g. OSB). Check the suitability of the substrate. Adhesion tests may be necessary.

## CONDITIONS

The bonds should not be subjected to tensile strain. If the tape is used to stick vapour checks, the weight of the insulating material must be borne by lathing. If necessary, support the bond with shutter boards. Press firmly to secure the adhesive tape.

Ensure there is sufficient back-pressure. Airtight seals can only be achieved with vapour checks that have been laid without any folds or creases. Ventilate the interior space regularly to prevent build-up of excessive humidity.

The information provided here is based on the current state of the art and our own experience. We reserve the right to make changes to the recommendations given or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

If you have any questions, please call the pro clima technical hotline Ireland and UK:

Phone: 800-995-6329  
web: [www.foursevenfive.com](http://www.foursevenfive.com)  
email: [info@foursevenfive.com](mailto:info@foursevenfive.com)

Temperature resistance	Long term from -40 °F to +194 °F
Application temperature	over 14 °F (-10 °C)
Available as	Roll length: 98 ft (30 m) Roll width: 2-3/8"/-3"/-6"/-8"
Storage	Cool and dry

[www.proclima.com](http://www.proclima.com)  
...and the insulation is perfect



475 High Performance Building Supply

Brooklyn, NY/ Clackemas, OR Delta, BC  
[info@foursevenfive.com](mailto:info@foursevenfive.com)  
[www.foursevenfive.com](http://www.foursevenfive.com)  
800-995-6329

