



**FIFINE TECHNOLOGY**  
**K668**  
**USER'S GUIDE**



B2B Version:22-07

97.00 mm

291.00 mm

142.00 mm

284.00 mm

**CONTENTS**

COMPUTER SETUP ..... 2-7

RECORDING SOFTWARE SETTINGS ..... 7-9

STAND INSTALLATION & ADJUSTMENT ..... 9

IMPORTANT NOTICE ..... 9-10

**WHAT'S IN THE BOX?**

1 X Anti Wind Foam Cap

1 X Metal Tripod Stand

1 X User Manual

1 X USB Microphone with Cable

**SPECIFICATION**

Model: K668

Sensitivity: -47dB±3dB

Operation Voltage: 5V

Frequency Response: 50Hz-16KHz

S/N ratio: More than 70dB

Operating Current: 50mA

**SPECIFICATION**

The top of the microphone should face the sound source. No matter how you adjust the angle or position of the mic, make sure the top of mic is pointing at your mouth in order to achieve the best pick up effect.

**COMPUTER SETUP**

**Apple MAC OS**

1. Plug the free end of the provided USB cable into the USB port on your computer. Your computer will automatically recognize the USB device and install a driver.
2. To select the K668 as your audio input, first, open your System Preferences.



3. Next, click Sound to display the Sound preference pane.

1

4. Click the output tab and make certain "USB PnP Audio Device" is selected as the default input device. Drag progress bar to adjust volume of output.



5. If you need output your voice from 3.5mm headphone jack of Macbook, choose the output from "Internal Speaker" option. Drag progress bar to adjust volume of output.



3

**NOTICE:**

- If you want to monitor your voice when using Macbook, you must turn on any recording software first(Audacity for example), make sure to click "Software Playthrough(on)", then click the Record button to begin, otherwise, you can not hear any sound when you speak to the mic. If the computer is not able to identify this USB device, please restart the computer and replug the mic into other USB ports.
- If your Mac only has USB C port, you will need a genuine Apple USB-C to USB female adapter for connection. And pls plug the USB adapter into your Mac first, then connect the mic with the adapter.

**Windows**

Please wait for a few secs when first time operation, since driver of microphone takes time to automatically install. There may be no pop-up window or message though. (If plugging receiver in a different USB port, driver installs again).

After installation, you can test the mic by speaking to it. If the mic picks up no sound, please follow procedures below.

1. Right-click the speaker icon at the bottom right of the screen. Click "Sounds".



4

- 2) Click the Sound control panel.



2. Confirm the loudspeaker is open.




Click the loudspeaker is being used-"Properties"--"levels", drag progress bar to adjust volume of output




5

3. Select the Recording tab, and choose "USB PnP Audio Device" as the default device. When you speak to mic, bar-type icon will turn green and bounce. If it remains unchanged, please reset computer and replug in the USB port. If there's still no "USB PnP Audio Device", please contact FIFINE after service.




4. If you want to directly monitor your recording, click Microphone "USB PnP Audio Device"- "Properties"- "Listen"- click "Listen to this device"- "Apply". No sound can be heard through earphone, if you don't follow this procedure. NOTE: Click off "Listen to this device" when you are using any recording software or chatting software (Skype).



6

5. Double click on the "USB PnP Audio Device" icon to open the Microphone Properties window. Click the speaker icon under the Levels tab. Select the Levels tab (14-20db) when the speaker output maximum volume to adjust microphone level.




**Note:(Applicable for MAC and Windows)**

1. If computer prompts that it's unable to identify USB devices, please restart computer and replug the microphone into other USB port.
2. If mic recognized but no sound comes out, please check whether System Sound is mute and whether you have turned volume control on microphone to minimum.
3. If mic recognized but not sound out, and your computer runs windows 10, please go to settings-privacy-microphone and click the Allow apps to access the microphone to ON then restart.

**Recording Software Settings**

1. Make sure you have the correct input/output selected. Notice: logging out of AUDACITY (or other recording


software) if you find usb microphone is unavailable. And then plug in mic first, secondly log in software again.



input : USB PnP Audio Device

output : Pls choose your output device as needed

2. Make sure to click off listen to device in your computer system when you are using any recording software, or else you would hear duet of yourself just like too much echo.




8

3. There are several ways to improve the usage. Come to our website, find Technical Support under the "SUPPORT" tab or directly search the Technical Support solution for your interested subject.
4. For windows computers, we recommend audacity, and for Apple computers, you can use Apple's own QuickTime player to test the recording.

**STAND INSTALLATION AND ADJUSTMENT**

Install the tripod stand with the silver mount of the mic and clockwise rotation the stand to adjust the angle.



**IMPORTANT NOTICE**

- Setting your software levels

Correct adjustment of microphone level is important for optimum performance. Ideally, the microphone level should be

9

as high as possible without overloading the input of your computer. If you hear distortion, or if your recording program shows levels that are consistently overloaded (at peak levels), turn the microphone volume (or level) down, either through your control panel (or system preferences) settings, or through your recording software. If your recording program shows insufficient level, you can increase the microphone gain either from the control panel (or system preferences) settings or through your recording program.

- Selecting software

Many recording software can be chosen. Audacity, available for free online is a widely used software. If you plug in the mic AFTER you load Audacity, it may not recognize the mic while it may still record, the results will be unsatisfactory. If that happens, restart Audacity AFTER plugging the USB into your computer.

- Monitor setting


If you want to listening to yourself, pls click listen to device in your computer system. (Windows system). Remember to click off listen to device in your computer system when you are using any recording software or chatting software (Skype), or else you would hear duet of yourself just like too much echo.


- Protecting your microphone

Avoid leaving your microphone in the open sun or in areas where temperatures exceed 110° F (43° C) for extended periods. Extremely high humidity should also be avoided.

10

**CONTACT US**

Get Social:  Facebook page: <http://bit.ly/FifinePage>

Contact Info:  E-mail: [web@fifine.cc](mailto:web@fifine.cc)

More product inquiries can be found on the website. Company Website: <https://fifinemicrophone.com/>

**WARRANTY**

Fifine microphone warrants its hardware product defects in materials and workmanship for a period of one year from the date of original retail purchase, provided the purchase was made from authorized Fifine microphone dealer. This warranty is void if the equipment is altered, misused, mishandled, suffers excessive wear or is serviced by any parties not authorized by Fifine Microphone. For warranty service, contact your local distributor or [web@fifine.cc](mailto:web@fifine.cc).

11