

65.00 mm
195.00 mm

125.00 mm


WELCOME TO FIFINE

Thank you for showing your confidence in us by purchasing headphone amplifier N6. This 4-channel stereo headphone amplifier is designed for use with all types of headphones and therefore provides maximum flexibility. Its high-power stereo amplifiers guarantee the highest sonic quality even at maximum volume. The ultra low-noise operational amplifiers ensure outstanding audio performance.

WHAT'S IN THE BOX?

1. N6 Headphone Amplifier
2. Power Adapter
3. User's Manual

CONNECTORS AND CONTROL ELEMENTS



N6 connectors and control elements


1

- ① Connect the power supply unit to your N6 using the 12v connector. Connecting the power supply unit to the mains automatically switches the N6 on. To disconnect the unit from the mains, pull out the main cord plug.
Note: When installing the products, ensure that the plug is easily accessible. If mounting in a rack, ensure that the mains can be easily disconnected by a plug or by an all-pole disconnect switch on or near the rack.
- ② Connect up to 4 headphones to these 1/4" TRS connectors.
Always plug your headphones in N6 with your headphones off. Plug your headphones in, then put them on.
- ③ The signal source has to be connected to this 1/4" TRS connector (INPUT).
Note: In case the volume level of the signal source is set too high, the N6 may produce distortion!
You must use the cable or adapter with 1/4" TRS (3 pins) plug to connect your devices to the input and output of the N6 amp, otherwise you will get mono only.
- ④ This ON LED is illuminated as soon as the unit is connected to the power.
- ⑤ Using the LEVEL controls you can set the volume level of each headphone output.
Note: High volume levels can damage your hearing or your headphones. Please turn down all volume controls to zero(all the way to the left)before you power up the amp. Always make sure your use appropriate volume levels.

2

APPLICATIONS

The following figure shows an example of how to use the N6.



SPECIFICATIONS

INPUT
Type 1/4" TRS connector: stereo
Impedance: 47k
Max.input level: +16dBu

HEADPHONE OUTPUTS
Type 1/4" TRS connector: stereo
Impedance: approx 47
Max.output level: +16dBu

POWER SUPPLY
External power supply: 12V/1A
Max.output level: approx 50mW

DIMENSIONS/WEIGHT
Dimension(HxDxW): approx 1.57"x 2.36"x4.72"
(approx 40mm x 60mm x 120mm)
Weight: approx.0.43 lbs (217g)

3

FEATURES


- 4 independent stereo high-power amplifier sections. Each output channel can be adjusted volume individually.
- Compact size and metal shell, lightweight and durable. Perfect for both on-stage and in-studio performances or applications
- Highest audio quality with virtually all types of headphones even at maximum volume
- Ultra-compact headphone amplifier system for studio and stage applications.


SAFETY INSTRUCTIONS

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 10) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

4

CONTACT US


Get Social: 
Facebook page: <http://bit.ly/FifinePage>


Contact Info: 
E-mail: web@fifine.cc

More product inquiries can be found on the website.
Company Website: <https://fifinemicrophone.com/>

WARRANTY

Fifine microphone warrants its hardware product defects in materials and workmanship for a period of one year from the date of original retail purchase, provided the purchase was made from authorized Fifine microphone dealer. This warranty is void if the equipment is altered, misused, mishandled, suffers excessive wear or is serviced by any parties not authorized by Fifine Microphone. For warranty service, contact your local distributor or web@fifine.cc.





B2B Version: 22-07