

## **INSTRUCTIONS FOR USE**

ANKLE STABILIZER, AI






**1.** Release the top circumferential locking straps (E&F), then unlock the stirrup straps from the underliner (C&D). Place your heel deep into the neoprene underliner. Close the Velcro tab (A) firmly across the forefoot.



**2.** Close the upper shin tab (B) across the front lower leg.




**3.** Raise your foot toward your knee, (dorsiflexion). Lift the inside medial stirrup (C) while applying mild tension.


## **INSTRUCTIONS FOR USE**

ANKLE STABILIZER, A1





**4.** Lift the outside lateral stirrup (D), so that the outside or lateral side of the foot is elevated or everted. Adjust the tension to the desired level of support.



**5.** Close the two top circumferential Velcro straps (E&F). This will lock medial and lateral stirrups into place.