



Arctic Cat Wildcat DOOR INSERT

Step 1: Remove your 3SI UTV DOOR INSERT kit from the shipping box.

Contents: 2 – DOOR INSERTS

10 – LARGE WASHERS

Note: Remove any existing front Roll Bar upright hardware from your vehicle that will interfere with the installation of your new 3SI UTV DOOR INSERT. You will need someone to help hold the Windshield in place while hardware is being fastened.

Before Installing your 3SI UTV DOOR INSERT Kit you will need to Install your 3SI UTV Full Cab Enclosure, Windshield Top Enclosure or Door / Rear Window Enclosure as the front Windshield Enclosure tabs go under the DOOR INSERT.

Step 2: Remove plastic door panels from UTV. Remove factory bolts in the small door frame. Use these factory bolts to secure door insert to door frame.



Step 3: line the door kits slot holes up with the factory drilled holes in the door frame.

Step 4: Put bolts with large washer through the plastic door insert and then tighten firmly into place. Do not over tighten.

Periodic cleaning using



3 STAR INDUSTRIES

correct procedures can help to prolong service life. For care and cleaning, it is recommended that the following instructions be adhered to:

Lexan Cleaning Recommendations

- Gently wash Lexan with a solution of mild soap and lukewarm water, using a soft, grid-free cloth or sponge to loosen any dirt or grime.
- Fresh paint splashes, grease and smeared glazing compounds can be removed easily before drying by rubbing lightly with a soft cloth using petroleum ether (BP65), hexane or heptanes. Afterwards, wash the sheet using mild soap and lukewarm water.
- Scratches and minor abrasions can be minimized by using a mild automobile polish. We suggest that a test be made on a small area of the Lexan sheet with the polish selected and that the polish manufacturer's instructions be followed, prior to using the polish on the entire sheet.
- Finally, thoroughly rinse with clean water to remove any cleaner residue and dry the surface with a soft cloth to prevent water spotting.

Important Instructions

- Never use abrasive or highly alkaline cleaner on Lexan polycarbonate materials.
- Never use aromatic or halogenated solvents like toluene, benzene, gasoline, acetone or carbon tetrachloride on Lexan polycarbonate materials.
- Use of incompatible cleaning materials with Lexan sheet can cause structural and/or surface damage.
- Contact with harsh solvents such as methyl ethyl ketone (MEK) or hydrochloric acid can result in surface degradation and possible crazing of Lexan sheet.
- Never scrub with brushes, steel wool or other abrasive materials.
- Never use squeegees, razorblades or other sharp instruments to remove deposits or spots.
- Do not clean Lexan polycarbonate in direct sunlight or at high temperatures as this can lead to staining.
- For all mentioned chemicals consult the manufacturer's material safety datasheet (MSDS) for proper safety precautions.