



ARCTIC CAT XX

WINDSHIELD

**DO NOT REMOVE
PROTECTIVE PAPER FROM
WINDSHIELD THIS WILL BE
YOUR LAST INSTALLATION
STEP!**

STEP 1

Assemble wingnut, neoprene washer and bolt.



STEP 2

Wrap loop clamps around the roll bar, flat part of the clamp facing outward and resting on the windshield.

Part	Qty	Description
	4	1 3/4" Loop clamp
	4	Neoprene Washer
	4	1 1/2" Bolt
	4	Wingnut
	4	Small Washer
	4	Lock Nut



STEP 3

Set windshield on the hood line, peel back protective paper enough to expose the clamp holes, line up holes in windshield with holes in clamps.



STEP 4

Insert wingnut, neoprene washer and bolt assembly through the front of the windshield, then through the clamps holes.



STEP 5

Secure with small washer and lock nut. Repeat these steps for both bottom clamp holes. Hand tighten only at this time.



STEP 6

Tighten all hardware and remove the protective paper from both sides of the windshield.



Periodic cleaning using correct procedures can help to prolong service life. For care and cleaning, it is recommended that the following instructions be adhered to:

Lexan Cleaning Recommendations

- Gently wash Lexan with a solution of mild soap and lukewarm water, using a soft, grid-free cloth or sponge to loosen any dirt or grime.
- Fresh paint splashes, grease and smeared glazing compounds can be removed easily before drying by rubbing lightly with a soft cloth using petroleum ether (BP65), hexane or heptanes. Afterwards, wash the sheet using mild soap and lukewarm water.
- Scratches and minor abrasions can be minimized by using a mild automobile polish. We suggest that a test be made on a small area of the Lexan sheet with the polish selected and that the polish manufacturer's instructions be followed, prior to using the polish on the entire sheet.
- Finally, thoroughly rinse with clean water to remove any cleaner residue and dry the surface with a soft cloth to prevent water spotting.

Important Instructions

- Never use abrasive or highly alkaline cleaner on Lexan polycarbonate materials.
- Never use aromatic or halogenated solvents like toluene, benzene, gasoline, acetone or carbon tetrachloride on Lexan polycarbonate materials.
- Use of incompatible cleaning materials with Lexan sheet can cause structural and/or surface damage.
- Contact with harsh solvents such as methyl ethyl ketone (MEK) or hydrochloric acid can result in surface degradation and possible crazing of Lexan sheet.
- Never scrub with brushes, steel wool or other abrasive materials.
- Never use squeegees, razorblades or other sharp instruments to remove deposits or spots.
- Do not clean Lexan polycarbonate in direct sunlight or at high temperatures as this can lead to staining.
- For all mentioned chemicals consult the manufacturer's material safety datasheet (MSDS) for proper safety precautions.