



## Installation Instructions

Thank you for purchasing a UTV enclosure manufactured in the USA with pride by 3SI UTV. Your enclosure is made of heavy duty fabric that is water repellent and resistant to mildew, ultra-violet rays and abrasion. With proper installation and care you can expect many years of service from your 3SI UTV enclosure.

### SOME IMPORTANT NOTES BEFORE GETTING STARTED....

- The enclosure attaches to your UTV's cab frame with Velcro. The technical term for Velcro is hook and loop. Loop is the soft side and hook, the rough side. Loop has been sewn into the enclosure at various points. Adhesive hook has been supplied to attach to your cab frame, corresponding to the sewn-in loop. If you struggle with placement of the adhesive hook, with the enclosure held to the cab frame, note the locations of the sewn-in loop. The adhesive hook is attached to the cab frame at those locations.
- The adhesive hook should be applied at a temperature of 60 degrees or above. **For maximum adhesion, when the adhesive hook is in place, allow the adhesive to cure for 24 hours before attaching the loop to the hook.**
- Clean the surfaces the adhesive hook will be attached to before beginning installation. A light cleaning with mild soap and water is best. A little rubbing alcohol works great. Do NOT wax or clean with a compound that leaves the frame slick. The adhesive hook will not stick to a slick surface. Again, a light cleaning is best.
- Your enclosure is not a "one size fits all" product. The enclosure was designed and manufactured specifically for your model UTV. As a result, the enclosure should fit square and snug to the cab frame.
- Periodic cleaning of your enclosure with mild soap and water is recommended to minimize accumulations of dirt.
- Clean the vinyl windows with mild soap, water, and a soft cloth to avoid scratches. DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS OR CHEMICALS TO CLEAN VINYL WINDOWS.
- Clean your enclosure and allow it to dry before removing for storage. **Never fold your enclosure to store.** Roll the enclosure to avoid creasing the vinyl windows. Creases in the vinyl windows cannot be removed. **CREASING THE VINYL WINDOWS VOIDS ALL WARRANTIES AND GUARANTEES.**
- The only enclosures manufactured by 3SI UTV that can be hauled when installed are Lexan windshields, full cab enclosures, and door/rear window combos with top and windshield installed. However, the enclosures should be tied down before hauling. Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. REMOVE ALL OTHER ENCLOSURES BEFORE HAULING.

**PLEASE READ AND FOLLOW THE DETAILED INSTRUCTIONS THAT ARE ATTACHED.**



## Arctic Cat Prowler (Square Bars)

### Full Cab for Hard Windshield

Before installing, please review the notes below that are specific to the Arctic Cat Prowler square bar enclosure:

- The enclosure is “semi-modular”. The door panels and back panel zip to the top panel. This “semi-modular” feature allows you to ride without doors or a back panel if you prefer during warmer months.
- Install the top/front wings, followed by the back panel, and finally the door panels.

**Step 1:** Remove the cab enclosure and adhesive hook kit from the shipping box. Contents are as follows:

- Top / Front Wings
- Back Panel
- Door Panels

**Step 2:** Begin installation of the adhesive hook to the cab frame. If you struggle with placement, hold the enclosure to the cab frame and match the adhesive hook to the sewn-in loop. The following tables show the size and placement of the adhesive hook strips. The tables are followed by pictures showing the approximate location to attach the adhesive hook strips.

Top / Front Wings		
Reference	Quantity/Size	Placement
A	2-9"	Wrap horizontally around the bottom of the front roll bars corresponding to the sewn-in double-sided hook/loop straps. Wrap the double-sided straps around the adhesive strip.
B	2 – 10" (Top) & 2 – 4" (Bottom)	Attach vertically to the outside edge of the front roll bars corresponding to the sewn-in webbing/loop tabs on either side of the windshield. Use the webbing/loop tabs to pull the windshield tight from side to side. Attach the sewn-in loop in the tabs to the adhesive strips.



**\*Full Cab with Vinyl Windshield Shown**

Reference	Quantity/Size	Placement
C	2-9"	Attach horizontally to the bottom of the rear roll bars. Wrap the double-sided straps located at the bottom of the tension straps around the adhesive hook strips. If needed, loosen the tension strap to allow the bottom to reach the adhesive strips.



**Step 3:** If not already done, drape the top / front wings combo over the roll bars. Align the top / front wings square to the roll bars. Begin attaching the sewn-in loop strips to the adhesive hook strips as indicated in the tables above.

**Step 5:** When the top / front wings are aligned, pull the tension strap on the back corners down to tighten the top to the frame.

Back Panel		
Reference	Quantity/Size	Placement
D	2-12"	Attach vertically to the outside edge of the rear roll bars corresponding to the sewn-in webbing/loop tabs on either side of the rear window. Use the webbing/loop tabs to pull the rear panel tight from side to side. Attach the sewn-in loop in the tabs to the adhesive strips.
E	2-9"	Wrap horizontally around the rear roll bars corresponding to the sewn-in double-sided hook/loop straps just below the tabs in reference D. Wrap the double-sided straps around the adhesive strip.
F	2-9"	Wrap horizontally around the rear roll bars corresponding to the sewn-in double-sided hook/loop straps just above the tabs in reference D. Wrap the double-sided straps around the adhesive strip.
No Ref	2-6"	Raise the bed. Wrap horizontally around the bars near the bottom of the back panel corresponding to the sewn-in double-sided hook/loop straps. Wrap the double-sided straps around the adhesive strip.




**Step 6:** If not done, zip the back panel to the windshield/top.

**Step 7:** Attach the sewn-in loop to the adhesive hook strips.

## Door Panels

Reference	Quantity/Size	Placement
G	2-12"	ONLY NEEDED IF BACK PANEL IS NOT INSTALLED. Attach vertically to the back side of the rear roll bars corresponding to the sewn-in webbing/loop tabs on the rear panel of the doors. Attach the sewn-in loop in the tabs to the adhesive strips.
H	2-10"	Attach vertically to the outside edge of the rear roll bars corresponding to the sewn-in loop strip on the rear door panel. Attach the sewn-in loop to the adhesive hook strip.
I	2-20"	Attach to the vehicle body corresponding to the sewn-in loop strip on the bottom of the rear door panel. Attach the sewn-in loop to the adhesive hook strip.
J	2-30"	Attach to the vehicle body corresponding to the sewn-in loop strip on the bottom of the door panel. Attach the sewn-in loop to the adhesive hook strip.
K	2-3.5"	Attach to the vehicle body corresponding to the sewn-in loop strip on the bottom of the wing panel. Attach the sewn-in loop to the adhesive hook strip.
L	2-20"	Attach to the vehicle body corresponding to the sewn-in loop strip on the front of the wing panel. Attach the sewn-in loop to the adhesive hook strip.
M	4-3.5"	Attach 2 strips of adhesive hook to the body corresponding to the sewn-in loop strips at the front of the door panels. Attach the sewn-in loop to the adhesive hook strip.



**Step 8:** Zip the door panels to the windshield/top and back panel.

**Step 9:** Attach the sewn-in loop to the adhesive hook strips.

**Step 10:** Repeat any steps necessary to achieve a tight fit to the roll bar frame as shown below.



**\*Full Cab with Vinyl Windshield Shown**

**See enclosed Product Care sheet for instructions on how to properly care for your 3SI UTV Enclosure.**



## Care Instructions

### Heavy Duty Marine and Mil-Spec Military Fabric Cleaning

All 3SI UTV Enclosure Heavy Duty Marine and Military Camo fabrics are guaranteed against excessive loss of color or strength under normal exposure and use conditions. Periodic cleaning with a solution of 4 ounces of bleach and 2 ounces of soap (NOT DETERGENTS) in one gallon of water is recommended to minimize accumulations of dirt, bird droppings and other contaminants which can support surface mildew and stain fabric.

### Soft Vinyl Window Cleaning

3SI UTV Enclosure Vinyl Windows will remain clear and provide great visibility under normal exposure conditions if properly cleaned. Periodic cleaning with a solution of 1 ounce of soap in one gallon of water is all that is needed to maintain good window cleanliness and visibility. Caution: DO NOT USE ANY DETERGENTS, WINDOW CLEANERS, SOLVENTS or CHEMICALS OF ANY KIND TO CLEAN VINYL WINDOWS AS THESE WILL CLOUD THE WINDOWS. ALSO, NEVER RUB WINDOWS WITH A DRY CLOTH OR RAG.

### Storage Recommendations

Before removing the 3SI UTV Enclosure from your vehicle for storage, clean the Fabric and Vinyl Windows thoroughly as indicated above. Any dirt remaining on the Enclosure may scratch Vinyl Windows while in storage. Once the Enclosure has been cleaned it should be placed on a large flat surface. Lay the Enclosure out so that Vinyl Windows are in a flat position. Fold the doors over the rear panel first then fold the top and windshield on top of the doors keeping the Vinyl Windows flat. Caution: **FOLDING VINYL WINDOWS WILL CAUSE PERMANENT CREASE DAMAGE AND WILL VOID ALL WARRANTIES.** Once the Enclosure is folded keeping all Vinyl Windows flat, begin rolling the Enclosure into an 8" roll. Place the 8" roll into a box and store at normal room temperature. To ensure long life of your enclosure it is best not to store in extreme temperatures.

### Hauling

The ONLY products manufactured by 3SI UTV that can be hauled while installed are the hard windshields, full cab enclosures, and door/rear window combos with top and windshield installed. **However, the full cab enclosures and door/rear window combos should be tied down before hauling.** Speed should not exceed 55 mph while hauling to prevent ripping and shredding of the material and zippers. NEVER HAUL INSTALLED SOFT TOPS, WINDSHIELD TOP COMBOS, AND SUMMER CABS. **REMOVE BEFORE HAULING.**