



3 STAR INDUSTRIES

ARCTIC CAT PROWLER PRO

1 Pc Polycarbonate Windshield

Installation Instructions

You have just purchased the best Polycarbonate Windshield for your Utility Terrain Vehicle available on the market today. Your Windshield is made of ¼" gauge polycarbonate (Lexan) that is almost unbreakable. With proper installation and care you can expect many years of service life from your **3SI UTV Polycarbonate Windshield**.

Step 1: Remove your 3SI UTV Polycarbonate windshield kit from the shipping box. **DO NOT REMOVE PROTECTIVE PLASTIC PAPER FROM THE WINDSHIELD AT THIS TIME. THIS SHOULD BE YOUR LAST INSTALLATION STEP.**

- Contents:
- Polycarbonate Windshield
 - 6 – CC CLAMPS, 1-1/2" Bolts and Thumb Screws
 - 1 – Metal Bracket
 - 3 – 1" Bolts
 - 9 – Lock Nuts
 - 7 – Neoprene Washer
 - 11 – Small Washers

Step 2: Install metal bracket, insert bolts through the metal brackets and then through factory drilled holes in the visor of the UTV. Secure with washer and lock nut.

Step 3: Set windshield on the UTV, install bolt and neoprene washer through the outside of the windshield through the metal bracket, secure with small washer and lock nut.





Step 4: Install C Clamps, hook clamp on to the pro-fit cage and push the flat part towards the windshield. Take a wingnut and slide it over the bolt, then slide the neoprene washer over the bolt and insert through the outside of the lexan windshield and through the hole in the C Clamp. Secure with small washer and lock nut.





Periodic cleaning using correct procedures can help to prolong service life. For care and cleaning, it is recommended that the following instructions be adhered to:

Lexan Cleaning Recommendations

- Gently wash Lexan with a solution of mild soap and lukewarm water, using a soft, grid-free cloth or sponge to loosen any dirt or grime.
- Fresh paint splashes, grease and smeared glazing compounds can be removed easily before drying by rubbing lightly with a soft cloth using petroleum ether (BP65), hexane or heptanes. Afterwards, wash the sheet using mild soap and lukewarm water.
- Scratches and minor abrasions can be minimized by using a mild automobile polish. We suggest that a test be made on a small area of the Lexan sheet with the polish selected and that the polish manufacturer's instructions be followed, prior to using the polish on the entire sheet.
- Finally, thoroughly rinse with clean water to remove any cleaner residue and dry the surface with a soft cloth to prevent water spotting.

Important Instructions

- Never use abrasive or highly alkaline cleaner on Lexan polycarbonate materials.
- Never use aromatic or halogenated solvents like toluene, benzene, gasoline, acetone or carbon tetrachloride on Lexan polycarbonate materials.
- Use of incompatible cleaning materials with Lexan sheet can cause structural and/or surface damage.
- Contact with harsh solvents such as methyl ethyl ketone (MEK) or hydrochloric acid can result in surface degradation and possible crazing of Lexan sheet.
- Never scrub with brushes, steel wool or other abrasive materials.
- Never use squeegees, razorblades or other sharp instruments to remove deposits or spots.
- Do not clean Lexan polycarbonate in direct sunlight or at high temperatures as this can lead to staining.
- For all mentioned chemicals consult the manufacturer's material safety datasheet (MSDS) for proper safety precautions.